# **Owner's Manual**

## 2023 RDX

## California Proposition 65 Warning

**WARNING:** Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passengervehicle.

#### **Event Data Recorders**

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

The data belongs to the vehicle owner and may not be accessed by anyone else except as legally required or with the permission of the vehicle owner.

#### Service Diagnostic Recorders

This vehicle is equipped with service-related devices that record information about powertrain performance. The data can be used to verify emissions law requirements and/or help technicians diagnose and solve service problems. It may also be combined with data from other sources for research purposes, but it remains confidential. Some diagnostic and maintenance information is uploaded to Acura upon vehicle start up.

#### **California Perchlorate Contamination Prevention Act**

The airbags, seat belt tensioners, and CR type batteries in this vehicle may contain perchlorate materials - special handling may apply. See *www.dtsc.ca.gov/hazardouswaste/perchlorate/* 

As you read this manual, you will find information that is preceded by a **NOTICE** symbol. This information is intended to help you avoid damage to your vehicle, other property, or the environment.

#### Software End User License Agreement

Your vehicle comes equipped with software, which is governed by the End User License Agreement in this Owner's Manual, and which contains a binding arbitration clause. Please refer to the End User License Agreement for the terms and conditions governing your use of the installed software, as well as the applications, services, functions, and content provided through the software. Your use of the installed software will serve as your consent to the terms and conditions of the End User License Agreement. You may opt out within 30 days of your initial use of the Software by sending a signed, written notice to Acura at American Honda Motor Co., Inc., Acura Client Relations, Mail Stop CHI-4, 1919 Torrance Blvd., Torrance, CA 90501-2746.

#### **Privacy Notice**

This vehicle may share location and usage information. To manage this setting, visit *www.acuralink.com/vehicle-data-choices*.

To learn more about how we collect and use Personal Information, please read our Privacy Policy, accessible at *www.acura.com*.

#### System Updates Terms and Conditions

#### General

Your vehicle has an application that allows your 10.25-in. Color Touchscreen to automatically search for Acura software updates that are specific to your 10.25-in. Color Touchscreen and its connected devices (initially every one (1) week via Wi-Fi or every four (4) weeks via Telematics Control Unit (TCU)\*, gueries may occur more or less frequently due to internet outages, retries, direct user action, WAP push from the server or a change in guery policy on the Honda servers). This application periodically transmits to our servers a limited amount of vehicle and device information (Vehicle Identification Number (VIN), the Model Type (MT) Identification Number, Hardware and Software Part Number, Serial Number, Software Version, preferred language, Internet Protocol (IP) address, Transaction Log (alert or update viewing, update download and installation, software status), etc.). When the application finds an update from the server, the application initially asks permission to download and install the update. Where available, in your settings menu you may elect to automatically download and install these updates or you may elect to manually update the system.

When your 10.25-in. Color Touchscreen searches our servers for updates or alerts, we will automatically provide you with the opportunity to update your devices or transmit the update or alert directly to your 10.25-in. Color Touchscreen. We will also maintain on our servers a log of the updates or alerts that are installed.

#### Your Personal Data

Should the aforementioned information transmitted to Honda constitute personal information in your region, please note that this information will be treated in strict accordance with the rules and regulations outlined in this notice as well as applicable data protection law.

The terms of our privacy policy are incorporated into these terms by reference and your use of system updates will be subject to the privacy policy. Our privacy policy sets out information about how we and any named third parties will process any personal data we collect from you or that you provide to us, via the application. For further details, see Acura's connected product privacy policy at: U.S.: www.acura.com

Canada: www.honda.ca/privacy/vehicledata

Honda collects, uses and stores your personal data for the reasons set out below:

- to deliver the system updates and related services to you;
- to allow us to improve and optimize the system updates products and services;
- to respond to user questions and complaints; and for internal record keeping.
- where necessary for Honda's legitimate interests, as listed below, and where our interests are not overridden by your data protection rights.

Protecting our legitimate business interests and legal rights includes, but is not limited to, use in connection with compliance, regulatory, auditing, legal claims (including disclosure of such information in connection with legal process or litigation) and other ethics and compliance reporting requirements.

Honda will also convert personal data into anonymous data and use it (normally on an aggregated statistical basis) for uses such as market research and analysis, to improve the system updates, to analyze trends, and to assess the success of software update releases. Aggregated personal information does not personally identify you or any other user of the system updates.

Honda may share this data with Honda's worldwide support organization or affiliated Honda companies or other third parties engaged by Honda for the purposes of rendering support services in connection with system support.

\* Not available on all models

## A Few Words About Safety

Your safety, and the safety of others, is very important. And operating this vehicle safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all the hazards associated with operating or maintaining your vehicle. You must use your own good judgment.

You will find this important safety information in a variety of forms, including:

- Safety Labels on the vehicle.
- Safety Messages preceded by a safety alert symbol A and one of three signal words: DANGER, WARNING, or CAUTION. These signal words mean:

You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

**A**CAUTION

You CAN be HURT if you don't follow instructions.

- Safety Headings such as Important Safety Precautions.
- Safety Section such as Safe Driving.
- Instructions how to use this vehicle correctly and safely.

This entire book is filled with important safety information - please read it carefully.

This owner's manual should be considered a permanent part of the vehicle and should remain with the vehicle when it is sold.

The Navigation Manual is available online at *owners.acura.com* (U.S.) or *acura.ca* (Canada). If you are the first registered owner of your vehicle, you may request a complimentary printed copy of the Navigation Manual within the first six months of vehicle purchase. To request a copy, visit *owners.acura.com*. In Canada, please request a copy from your Acura dealer.

This owner's manual covers all models of your vehicle. You may find descriptions of equipment and features that are not on your particular model.

Images throughout this owner's manual (including the front cover) represent features and equipment that are available on some, but not all, models. Your particular model may not have some of these features.

This owner's manual is for vehicles sold in the United States and Canada.


The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd. reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation.


Safe Driving P. 31						
For Safe Driving P. 32	Seat Belts P.	37	Airbags P. 46			
Instrument Panel F	P. 79					
Indicators P. 80	Gauges and I	Displays P. 136	i			
Controls P. 153						
Clock P. 154	Locking and	Locking and Unlocking the Doors P. 156				
Panoramic Roof P. 189 Seats P. 216						
Features P. 253						
Audio System P. 254		Audio System Basic Operation P. 260				
Customized Features P. 35	9	HomeLink® U	Iniversal Transceiver P. 386			
Driving P. 429						
Before Driving P. 430		Towing a Trailer P. 435				
Braking P. 545		Parking Your Vehicle P. 555				
Fuel Economy and CO <sub>2</sub> Em	iissions P. 578	Turbo Engine	Vehicle P. 579			
Maintenance P. 58	1					
Before Performing Mainter Checking and Maintaining			Minder™ P. 585			
Climate Control System M	aintenance P. 6	27	Cleaning P. 629			
Handling the Unex	pected P. 63	39				
Tools P. 640		If a Tire Goes Flat P. 641				
Overheating P. 669		Indicator, Coming On/Blinking P. 671				
If You Cannot Unlock the	Fuel Fill Door P.	686				
► Information P. 689	I					
Specifications P. 690			Numbers P. 692			
Warranty Coverages P. 69	7	Authorized Manuals P. 700				

## Contents


						/ · · · · · · ·
				Quick Reference Guide	P. 6	6
Child Safety P. 64	Exhaust Gas Hazard P. 77	Safety Labels P. 78	- 'Yh, I			
				Safe Driving	P. 1	31
				Instrument Panel	P. 7	70
Tailgate P. 173 Operating the Switches Around the Steerir	····	Windows P. 186 Mirrors P. 213				
Interior Convenience Items P. 230	-	Climate Control System P. 247	J.	Controlle		
				Controls	Ρ. ΄	153
-	General Information on the Audio System	. P. 336				
Bluetooth <sup>®</sup> HandsFreeLink <sup>®</sup> P. 389	AcuraLink <sup>®</sup> P. 419		The second se	Features	P. 2	253
5 , 5	When Driving P. 443 Surround View Camera System*P. 567	AcuraWatch™ P. 483 Refueling P. 575		Driving	P. 4	429
	Surfound view current system 1. 507	Nerdening 1. 575				
				Maintenance	D	581
Maintenance Under the Hood P. 592	Replacing Light Bulbs P. 605					
Checking and Maintaining Tires P. 614 Accessories and Modifications P. 636	Battery P. 623	Remote Transmitter Care P. 625				
				Handling the Unexpected	P. 6	639
Handling of the Jack P. 663 Fuses P. 678	Engine Does Not Start P. 664 Emergency Towing P. 685	If the Battery Is Dead P. 667		Information	P. 6	689
	Refueling P. 688					
				Index	D -	702
Devices that Emit Radio Waves P. 693	Reporting Safety Defects P. 694	Emissions Testing P. 695	. I			/ 02
Client Service Information P. 701						
						/


## **Visual Index**






## **Visual Index**






## **Visual Index**



## **Auto Idle Stop Function**

To improve fuel economy, the engine stops and then restarts as detailed below. When Auto Idle Stop is on, the Auto Idle Stop indicator (green) comes on.




## Safe Driving



 Your vehicle is fitted with airbags to help protect you and your passengers during a moderate-to-severe collision.

### - Child Safety CR64

- All children 12 and younger should be seated in the rear seat.
- Smaller children should be properly restrained in a forward-facing child seat.
- Infants must be properly restrained in a rear-facing child seat.



### Exhaust Gas Hazard

• Your vehicle emits dangerous exhaust gases that contain carbon monoxide. Do not run the engine in confined spaces where carbon monoxide gas can accumulate.

## Seat Belts CR37

- Fasten your seat belt and sit upright well back in the seat.
- Check that your passengers are wearing their seat belts correctly.




Fasten your lap belt as low as possible.

## Before Driving Checklist 2836

 Before driving, check that the front seats, head restraints, steering wheel, and mirrors have been properly adjusted.

## Instrument Panel CEEP

## Indicators (Gauges (Multi-Information Display (Head-Up Display\* (TR 148)



## Controls CONTROL


## Clock CP. 154

The clock is automatically updated through the audio system.

You can adjust the time using the A-zone touchpad.



1 Press the 🟦 (home) button.



3 Select System.



- Select Date & Time.
- 5 Select Set Date & Time.
- 6 Select Automatic Date & Time.
- 7 Select Off.
- 8
  - Select Set Date or Set Time.
  - Select  $\pm/$  to adjust the dates, hours and minutes.
- Press the (back) button to set the date or time.

## ENGINE START/STOP Button

Press the button to change the vehicle's power mode.




## Turn Signals CR 196

Turn Signal Control Lever



## Lights CR 197

Light Control Switches



## Wipers and Washers

#### **₽**. 204

Wiper/Washer Control Lever Adjustment Ring □: Low Sensitivity\*1 : Lower speed, fewer sweeps\*2 ⊡: High Sensitivity\*1 : Higher speed, more sweeps\*2 ↓ Higher speed, more sweeps\*2 ↓ Pull toward you to spray washer fluid.

OFF AUTO<sup>\*1</sup>: Wiper speed varies automatically INT<sup>\*2</sup>: Low speed with intermittent LO: Low speed wipe HI: High speed wipe

\*1: Models with automatic intermittent wipers

\*2: Models without automatic intermittent wipers

#### Models with automatic intermittent wipers

**AUTO** should always be turned **OFF** before the following situations in order to prevent severe damage to the wiper system:

- Cleaning the windshield
- Driving through a car wash
- No rain present

## Steering Wheel CR212

• To adjust, push the adjustment lever down, adjust to the desired position, then lock the lever back in place.



### Unlocking the Front Doors from the Inside

#### ►**P**. 170

• Pull either front door inner handle to unlock and open it at the same time.




### Tailgate CR173




- Press the tailgate outer handle to unlock and open the tailgate when you have the keyless remote on you.
- Press the power tailgate button on the driver's door.
- Press the power tailgate button on the remote transmitter.

#### Models with Hands Free Access

Use a forward and back kicking motion under the center of the rear bumper to open or close the power tailgate while carrying the keyless remote.






### **Power Door Mirrors**

#### ►P. 214


- With the power mode in ON, move the selector switch to L or R.
- Push the appropriate edge of the adjustment switch to adjust the mirror.
- Press the folding button\* to fold in and out the door mirrors.




Adjustment Switch -

## Power Windows CR 186


- With the power mode in ON, open and close the power windows.
- If the power window lock button is in the off position, each passenger's window can be opened and closed with its own switch.
- If the power window lock button is in the on position (indicator on), each passenger's window switch is disabled.






### Climate Control System CR247

- Press the AUTO button to activate the climate control system.
- Press the SOFF button to turn the system on or off.
- Press the  $\frac{1}{1000}$  button to defrost the windshield.



## Features CIRES


## Audio Remote Controls



VOL+/VOL- (Volume) Switch

- VOL+/VOL- (Volume) Switch Press up or down to adjust the volume.
- (Power) Button Press to turn the audio system on and off.
- Left Selector Wheel When selecting the audio mode Press the APPS button, then roll up or down to select an item on the multiinformation display or the head-up display\*, and then press the left selector wheel.

**Roll up or down:** To cycle through the following items, roll up or down and then press the left selector wheel:




You can add or remove the items and change their order on multi-information display or the head-up display<sup>\*</sup>.

- When listening to the radio Move to a side to change the favorite radio station or channel.
- When listening to an iPod, USB flash drive, *Bluetooth*<sup>®</sup> Audio, or Smartphone Connection

Move to a side to skip to the beginning of the next song or return to the beginning of the current or previous song.

### Audio System CR 260

For navigation system operation **See** the Navigation System Manual



## Driving (19429)

## Automatic Transmission CR451

• Select **P** and depress the brake pedal when starting the engine.

### Shifting





#### Park

Reverse

Press the P button. Used when parking, before turning off or start the engine. Transmission is locked.

## R



Neutral Press the N button. Transmission is not locked.

Pull back the R button.

Used when reversing.

## D/S

#### **Drive/S Position**

Each time you press the D/S button, the mode switches between Drive and S Position mode.

#### Drive

- Normal driving (gears change between 1st and 10th automatically)
- Temporarily driving in the sequential mode

#### S Position

- Automatically changing gears between 1st and 8th (8th gear is used only at high speed)
- Driving in the sequential mode

### Sequential Mode P.457 Paddle shifters allow you to shift gears much like a manual transmission (1st through 10th). This is useful for engine braking. When the transmission is in D • The transmission will shift back to Gear Position Indicator automatic mode once the system detects that the vehicle is cruising. M Indicator When the transmission is in S • Holds the selected gear, and the M (sequential mode) indicator comes on. • The sequential mode gear Selected Gear Number selection is shown in the instrument panel. Shift Down – Shift Up + Paddle Shifter Paddle Shifter

22

## CMBS<sup>™</sup> On and Off

#### ► P. 490

- When a possible frontal collision is likely unavoidable, the CMBS<sup>™</sup> can reduce the vehicle speed and the severity of the collision.
- The CMBS<sup>™</sup> is turned on every time you start the engine.
- To turn the CMBS<sup>™</sup> on or off, use the safety support switch.

## VSA<sup>®</sup> On and Off CAR 472

- The Vehicle Stability Assist™ (VSA®) system helps stabilize the vehicle during cornering and helps maintain traction while accelerating on loose or slippery road surfaces.
- VSA<sup>®</sup> comes on automatically every time you start the engine.
- To partially disable or fully restore VSA® function, press and hold the 2. (VSA® OFF) button until you hear a beep.

## Tire Pressure Monitoring System (TPMS) with Tire Fill Assist CP: 475

- The TPMS monitors tire pressure.
- TPMS is turned on automatically every time you start the engine.
- TPMS fill assist provides audible and visual guidance during tire pressure adjustment.

## Refueling CR575


Fuel recommendation: Unleaded premium gasoline, pump octane number 91 or higher


Fuel tank capacity: 17.1 US gal (64.7 L)

Unlock the driver's door.



Press on the edge of the fuel fill door to make it pop up slightly.






## AcuraWatch<sup>™</sup> ⊂

#### Models without Low Speed Braking Control


AcuraWatch<sup>™</sup> is a driver support system which employs the use of two distinctly different kinds of sensors, a radar sensor located behind the emblem, and a front sensor camera mounted to the interior side of the windshield, behind the rearview mirror.

Models with Low Speed Braking Control AcuraWatch<sup>™</sup> is a driver support system which employs the use of three distinctly different kinds of sensors, a radar sensor located behind the emblem, a front sensor camera mounted to the interior side of the windshield, behind the rearview mirror, and the sonar sensors located in the front and rear bumpers.





#### Models with Low Speed Braking Control



## **Collision Mitigation** Braking System<sup>™</sup>

The system can assist you when it determines there is a possibility of your vehicle colliding with a vehicle or a pedestrian detected in front of your vehicle. The CMBS<sup>™</sup> is designed to alert you when the potential for a collision is determined, as well as to reduce your vehicle speed to help minimize collision severity when a collision is deemed unavoidable.

## Low Speed Braking Control\*

Using sonar sensors located on the front and rear bumpers, the vehicle can detect if there is danger of a potential collision with a wall or other obstacle. The system is designed to alert you when a potential collision is determined, as well as assist in reducing speed, avoiding collisions, and reducing collision severity.

## Adaptive Cruise Control (ACC) with Low Speed Follow CR502

Helps maintain a constant vehicle speed and a set following-interval behind a vehicle detected ahead of yours and, if the detected vehicle comes to a stop, can decelerate and stop your vehicle, without you having to keep your foot on the brake or the accelerator.

## Lane Keeping Assist System (LKAS)

Provides steering input to help keep the vehicle in the middle of a detected lane and provides tactile and visual alerts if the vehicle is detected drifting out of its lane.

## Road Departure Mitigation System CR530

Alerts and helps to assist you when the system detects a possibility of your vehicle unintentionally crossing over detected lane markings and/or leaving the roadway altogether.

## Traffic Sign Recognition System

Reminds you of road sign information, such as the current speed limit your vehicle has just passed through, showing it on the multi-information display and the head-up display\*.

## Maintenance CZEED

### Under the Hood CTR592

- Check engine oil, engine coolant, and windshield washer fluid. Add when necessary.
- Check brake fluid.
- Check the battery condition monthly.



1

Pull the hood release handle under the corner of the dashboard.





Locate the hood latch lever, push it to the side, and then raise the hood. Once you have raised the hood slightly, you can release the lever.



When finished, close the hood and make sure it is firmly locked in place.



• Install snow tires for winter driving.

- Lights CP.605
- Inspect all lights regularly.

## Handling the Unexpected COMP

### Flat Tire P. 641

#### Vehicles with tire repair kit

• Park in a safe location and repair the flat tire using the tire repair kit.

Vehicles with a compact spare tire

 Park in a safe location and replace the flat tire with the compact spare tire located under the cargo area.



### Indicators Come On CREAT

• Identify the indicator and consult the owner's manual.



## Engine Won't Start CPR 664

• If the battery is dead, jump start using a booster battery.




• Park in a safe location. If you do not see steam under the hood, open the hood, and let the engine cool down.



### Blown Fuse P. 678

• Check for a blown fuse if an electrical device does not operate.



### Emergency Towing CTR685

• Call a professional towing service if you need to tow your vehicle.



## What to Do If

Why does the brake pedal pulsate slightly when applying the brakes?




This can occur when the ABS activates and does not indicate a problem. Apply firm, steady pressure on the brake pedal. Never pump the brake pedal.

Anti-lock Brake System (ABS)

The rear door cannot be opened from inside the vehicle. Why?

A

Check if the childproof lock is in the lock position. If so, open the rear door with the outside door handle. To cancel this function, slide the lever up to the unlock position.





Why do the doors lock after I unlocked the doors?



If you do not open the doors within 30 seconds, the doors are relocked automatically for security.



Why does the beeper sound when I open the driver's door? The beeper sounds when:

- The newer mode is in ACCES
- The power mode is in ACCESSORY.
- The exterior lights are left on.
- The Auto Idle Stop is in operation.



Why does a beeper sound when I walk away from the vehicle after I close the door?



The beeper sounds if you move outside the walk away auto lock operating range before the door completely closes. ► Locking the doors and tailgate (Walk away auto lock®) <- P. 163



Why does the beeper sound when I start driving?

The beeper sounds when the driver and/or front passenger are not wearing their seat belts.



Pulling the electric parking brake switch does not release the parking brake. Why?



Pull the electric parking brake switch with the brake pedal depressed.



I'm seeing an amber indicator of a tire with an exclamation point. What is that?



- The Tire Pressure Monitoring System (TPMS) needs attention.
- Check tire pressure.
  - If the Low Tire Pressure/TPMS Indicator Comes On or Blinks



Depressing the accelerator pedal does not release the parking brake automatically. Why?



- Fasten the driver's seat belt.
- Check if the transmission is in P or N. If so, select any other position.

Why does the gear position automatically change to P when I open the driver's door to check for parking space lines when reversing?



• Fasten the driver's seat belt.

• Close the driver's door and manually change the gear position.

➡ When opening the driver's door ► P.454



Why do I hear a screeching sound when I apply the brake pedal?



The brake pads may need to be replaced. Have your vehicle inspected by a dealer.



Unleaded gasoline with a Pump Octane Number (PON) of 91 or higher is recommended. Is it possible to use unleaded gasoline with a Pump Octane Number (PON) of 87 or lower on this vehicle?



Use of a lower octane gasoline can cause occasional metallic knocking noise in the engine and will result in decreased engine performance.

Use of a gasoline with a pump octane less than 87 can lead to engine damage.

# Safe Driving

You can find many safety recommendations throughout this chapter, and throughout this manual.

#### For Safe Driving

Important Safety Precautions	32
Important Handling Information	34
Your Vehicle's Safety Features	35
Safety Checklist	36
Seat Belts	
About Your Seat Belts	37
Fastening a Seat Belt	42
Seat Belt Inspection	45

#### Airbags

Airbag System Components 4	16
Types of Airbags	19

54
57
59
50
53
54
56
75

#### **Exhaust Gas Hazard**

Carbon Monoxide Gas ......77

#### Safety Labels

The following pages explain your vehicle's safety features and how to use them properly. The safety precautions below are ones that we consider to be among the most important.

### **Important Safety Precautions**

#### Always wear your seat belt

A seat belt is your best protection in all types of collisions. Airbags are designed to supplement seat belts, not replace them. So even though your vehicle is equipped with airbags, make sure you and your passengers always wear your seat belts, and wear them properly.

#### Restrain all children

Children ages 12 and under should ride properly restrained in a back seat, not the front seat. Infants and small children should be restrained in a child seat. Larger children should use a booster seat and a lap/shoulder seat belt until they can use the belt properly without a booster seat.

#### Be aware of airbag hazards

While airbags can save lives, they can cause serious or fatal injuries to occupants who sit too close to them, or are not properly restrained. Infants, young children, and short adults are at the greatest risk. Be sure to follow all instructions and warnings in this manual.

#### Don't drink and drive

Alcohol and driving don't mix. Even one drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. So don't drink and drive, and don't let your friends drink and drive, either.

#### ➢Important Safety Precautions

Some states, provinces and territories prohibit the use of cell phones other than hands-free devices by the driver while driving.

#### ■ Pay appropriate attention to the task of driving safely

Engaging in cell phone conversation or other activities that keep you from paying close attention to the road, other vehicles, and pedestrians could lead to a crash. Remember, situations can change quickly, and only you can decide when it is safe to divert some attention away from driving.

#### Control your speed

Excessive speed is a major factor in crash injuries and deaths. Generally, the higher the speed, the greater the risk, but serious injuries can also occur at lower speeds. Never drive faster than is safe for current conditions, regardless of the maximum speed posted.

#### ■ Keep your vehicle in safe condition

Having a tire blowout or a mechanical failure can be extremely hazardous. To reduce the possibility of such problems, check your tire pressures and condition frequently, and perform all regularly scheduled maintenance.

#### Do not leave children unattended in the vehicle

Children, pets, and people needing assistance left unattended in the vehicle may be injured if they activate one or more of the vehicle controls. They may also cause the vehicle to move, resulting in a crash in which they and/or another person(s) can be injured or killed. Also, depending on the ambient temperature, the temperature of the interior may reach extreme levels, which can result in harm or death. Even if the climate control system is on, never leave them in the vehicle unattended as the climate control system can shut off at any time.

### **Important Handling Information**

Your vehicle has higher ground clearance than a passenger vehicle designed for use only on pavement. Higher ground clearance has many advantages for off-highway driving. It allows you to travel over bumps, obstacles, and rough terrain. It also provides good visibility so you can anticipate problems earlier.

These advantages come at some cost. Because your vehicle is taller and rides higher off the ground, it has a higher center gravity making it more susceptible to tipping or rollover if you make abrupt turns. Utility vehicles have a significantly higher rollover rate than other types of vehicles. In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt. As a reminder, make sure you and your passengers always wear seat belts.

#### Important Handling Information


For information on how to reduce the risk of rollover, read:

- Driving Guidelines for Your Utility Vehicle P. 449
- Diff-Highway Driving Guidelines P. 441

Failure to operate your vehicle correctly might result in a crash or a rollover.

Safe Driving

# Your Vehicle's Safety Features



The following checklist will help you take an active role in protecting yourself and your passengers.

## ➢Your Vehicle's Safety Features

Your vehicle is equipped with many features that work together to help protect you and your passengers during a crash.

Some features do not require any action on your part. These include a strong steel framework that forms a safety cage around the passenger compartment, front and rear crush zones, a collapsible steering column, and tensioners that tighten the front and outer rear seat belts in a sufficient crash.

However, you and your passengers cannot take full advantage of these features unless you remain seated in the correct position and always wear your seat belts. In fact, some safety features can contribute to injuries if they are not used properly.

# Safety Checklist

For the safety of you and your passengers, make a habit of checking these items each time before you drive.

• After everyone has entered the vehicle, be sure all doors and the tailgate are closed and locked. Locking the doors and the tailgate helps prevent an occupant from being ejected and an outsider from unexpectedly opening a door or the tailgate.

## Locking/Unlocking the Doors from the Inside P. 169

• Adjust your seat to a position suitable for driving. Be sure the front seats are adjusted as far to the rear as possible while allowing the driver to control the vehicle. Sitting too close to a front airbag can result in serious or fatal injury in a crash.

**Seats** P. 216

• Adjust head restraints to the proper position. Head restraints are most effective when the center of the head restraint aligns with the center of your head. Taller persons should adjust their head restraint to the highest position.

## **Adjusting the Front and Rear Outer Head Restraint Positions** P. 225

• Always wear your seat belt, and make sure you wear it properly. Confirm that any passengers are properly belted as well.

## Fastening a Seat Belt P. 42

• Protect children by using seat belts or child seats according to a child's age, height, and weight.

Child Safety P. 64

#### Safety Checklist

If the door and/or tailgate open message appears on the multi-information display, a door and/or the tailgate is not completely closed. Close all doors and the tailgate tightly until the message disappears.

## Multi-Information Display Warning and Information Messages P. 107



# Seat Belts

# **About Your Seat Belts**

Seat belts are the single most effective safety device because they keep you connected to the vehicle so that you can take advantage of many built-in safety features. They also help keep you from being thrown against the inside of the vehicle, against any passengers, or out of the vehicle. When worn properly, seat belts also keep your body properly positioned in a crash so that you can take full advantage of the additional protection provided by the airbags.

In addition, seat belts help protect you in almost every type of crash, including:

- frontal impacts
- side impacts
- rear impacts
- rollovers

# Lap/shoulder seat belts

All five seating positions are equipped with lap/shoulder seat belts with emergency locking retractors. In normal driving, the retractor lets you move freely while keeping some tension on the belt. During a collision or sudden stop, the retractor locks to restrain your body.

The front passenger's and rear seat belts also have a lockable retractor for use with child seats.

Installing a Child Seat with a Lap/Shoulder Seat Belt P. 71

#### ➢About Your Seat Belts

# 

Not wearing a seat belt properly increases the chance of serious injury or death in a crash, even though your vehicle has airbags.

Be sure you and your passengers always wear seat belts and wear them properly.

If you extend the seat belt too quickly, it will lock in place. If this happens, slightly retract the seat belt, then extend it slowly.

Seat belts cannot completely protect you in every crash. But in most cases, seat belts can reduce your risk of serious injury.

Most states and all Canadian provinces and territories require you to wear seat belts.

# Proper use of seat belts

Follow these guidelines for proper use:

- All occupants should sit upright, well back in the seat, and remain in that position for the duration of the trip. Slouching and leaning reduce the effectiveness of the belt and can increase the chance of serious injury in a crash.
- Never place the shoulder part of a lap/shoulder seat belt under your arm or behind your back. This could cause very serious injuries in a crash.
- Two people should never use the same seat belt. If they do, they could be very seriously injured in a crash.
- Do not put any accessories on the seat belts. Devices intended to improve comfort or reposition the shoulder part of a seat belt can reduce the protective capability and increase the chance of serious injury in a crash.

#### ➢About Your Seat Belts

If a passenger moves around and extends the seat belt, the lockable retractor may activate. If this happens, release the retractor by unfastening the seat belt and allow the belt to retract completely. Then, refasten the belt.

# Seat Belt Reminder



## Front seats

The seat belt system includes an indicator on the instrument panel to remind the driver or a front passenger or both to fasten their seat belts.

If you set the power mode to ON and a seat belt is not fastened, a beeper will sound and the indicator will blink. After a few seconds, the beeper will stop and the indicator will come on and remain illuminated until the seat belt is fastened.

When the vehicle is moving, the beeper will sound and the indicator will blink for a while until the seat belt is fastened.

Then, the beeper will stop and the indicator will stay on.

#### ≫Seat Belt Reminder

The indicator will also come on if a front passenger does not fasten their seat belt after the power mode is set to ON.

When no one is sitting in the front passenger's seat, the indicator will not come on and the beeper will not sound.

The indicator also may not come on and the beeper may not sound when the occupant is not heavy enough to trigger the weight sensor. Such occupants (e.g., infants and smaller children) should be moved to the rear seat as a deploying front airbag likely will injure or kill them.

## Protecting Child Passengers P. 64

The multi-information display uses colors to aid the driver in checking the status of the passengers. For the front seating positions:

- Green indicates the seat belt is fastened.
- An unfastened gray graphic indicates the seat belt is not fastened and an occupant has not been detected.
- An unfastened red graphic indicates the seat belt is unfastened and an occupant has been detected.



## Rear seats

Your vehicle monitors rear seat belt use. The multi-information display notifies you if any of the rear seat belts are unfastened after they were previously fastened.

In order to encourage the driver to evaluate rear seat belt usage, the display appears when:

- Any of the rear passenger seat belts are unfastened when the power mode is set to ON.
- A rear door is opened and then closed.
- Any of the rear passengers fasten or unfasten their seat belt.

The seat belt reminder indicator blinks and the beeper sounds if any rear passenger seat belts are unfastened while driving.

#### ≫Seat Belt Reminder

The system will not detect a passenger in the rear seats who has not fastened the seat belt. The driver should check the status of the rear passengers' seat belts at the start of each trip and each time a passenger is seated in the rear seats, using the multi-information display as an aid. An alert will sound if a passenger in the rear seats unfastens the seat belt while the vehicle is in motion or if motion resumes while the graphic is red.

The multi-information display uses colors to aid the driver in checking the status of the passengers. For the rear seating positions:

- Green indicates the seat belt is fastened.
- An unfastened gray graphic indicates the seat belt has not been fastened recently.
- An unfastened red graphic indicates the seat belt was unfastened recently.


The system does not monitor harnesses that are part of a child seat, nor the anchors of the LATCH system. While the system can inform you that a seat belt is fastened, it cannot determine whether a child seat is properly installed or used.

Protecting Child Passengers P. 64

# Automatic Seat Belt Tensioners

The front seats and the outer rear seats are equipped with automatic seat belt tensioners to enhance safety.

The tensioners automatically tighten the front seat belts and the outer rear seat belts during a moderate-to-severe frontal collision, sometimes even if the collision is not severe enough to inflate the front airbags or the knee airbags.



#### Mutomatic Seat Belt Tensioners

The seat belt tensioners can only operate once. If a tensioner is activated, the SRS indicator will come on. Have a dealer replace the tensioner and thoroughly inspect the seat belt system as it may not offer protection in a subsequent crash.

During a moderate-to-severe side impact, the tensioner on that side of the vehicle also activates.

# **Fastening a Seat Belt**

After adjusting a front seat to the proper position, and while sitting upright and well back in the seat:

**Seats** P. 216



Buckle

**1.** Pull the seat belt out slowly.

- **2.** Insert the latch plate into the buckle, then tug on the belt to make sure the buckle is secure.
  - Make sure that the belt is not twisted or caught on anything.

#### ➢Fastening a Seat Belt

No one should sit in a seat with an inoperative seat belt or one that does not appear to be working correctly. Using a seat belt that is not working properly may not protect the occupant in a crash. Have a dealer check the belt as soon as possible.

Never insert any foreign objects into the buckle or retractor mechanism.

If the seat belt appears to be locked in a fully retracted position, firmly pull out on the shoulder belt once, then push it back in.

Then, smoothly pull it out of the retractor and fasten. If you are unable to release the seat belt from a fully retracted position, do not allow anyone to sit in the seat, and take your vehicle to a dealer for repair.

About Your Seat Belts P. 37
 Seat Belt Inspection P. 45



- **3.** Position the lap part of the belt as low as possible across your hips, then pull up on the shoulder part of the belt so the lap part fits snugly. This lets your strong pelvic bones take the force of a crash and reduces the chance of internal injuries.
- **4.** If necessary, pull up on the belt again to remove any slack, then check that the belt rests across the center of your chest and over your shoulder. This spreads the forces of a crash over the strongest bones in your upper body.

#### Fastening a Seat Belt

# 

Improperly positioning the seat belts can cause serious injury or death in a crash.

Make sure all seat belts are properly positioned before driving.

To release the belt, push the red **PRESS** button and then guide the belt by hand until it has retracted completely.

When exiting the vehicle, be sure the belt is properly stowed so that it will not get caught in the closing door.

#### Maliusting the Shoulder Anchor

The shoulder anchor height can be adjusted to four levels. If the belt contacts your neck, lower the height one level at a time.

After an adjustment, make sure that the shoulder anchor position is secure.

# Adjusting the Shoulder Anchor

The front seats have adjustable shoulder anchors to accommodate taller and shorter occupants.



- **1.** Move the anchor up and down while holding the release button.
- **2.** Position the anchor so that the belt rests across the center of your chest and over your shoulder.

# Advice for Pregnant Women

If you are pregnant, the best way to protect yourself and your unborn child when driving or riding in a vehicle is to always wear a seat belt and keep the lap part of the belt as low as possible across the hips.

Wear the shoulder belt across the chest avoiding the abdomen.



Wear the lap part of the belt as low as possible across the hips.

#### ➢Advice for Pregnant Women

Each time you have a checkup, ask your doctor if it is okay for you to drive.

To reduce the risk of injuries to both you and your unborn child that can be caused by an inflating front airbag:

- When driving, sit upright and adjust the seat as far back as possible while allowing full control of the vehicle.
- When sitting in the front passenger's seat, adjust the seat as far back as possible.

# **Seat Belt Inspection**

Regularly check the condition of your seat belts as follows:

- Pull each belt out fully, and look for frays, cuts, burns, and wear.
- Check that the latch plates and buckles work smoothly and the belts retract easily.
  - ▶ If a belt does not retract easily, cleaning the belt may correct the problem. Only use a mild soap and warm water. Do not use bleach or cleaning solvents. Make sure the belt is completely dry before allowing it to retract.

Any belt that is not in good condition or working properly will not provide proper protection and should be replaced as soon as possible.

A belt that has been worn during a crash may not provide the same level of protection in a subsequent crash. Have your seat belts inspected by a dealer after any collision.


## Seat Belt Inspection

# 

Not checking or maintaining seat belts can result in serious injury or death if the seat belts do not work properly when needed.

Check your seat belts regularly and have any problem corrected as soon as possible.

# Airbag System Components



The front, driver's knee, front passenger's knee, side, and side curtain airbags are deployed according to the direction and severity of impact. Both side curtain airbags are deployed in a rollover. The airbag system includes:

- Two SRS (Supplemental Restraint System) front airbags. The driver's airbag is stored in the center of the steering wheel; the front passenger's airbag is stored in the dashboard. Both are marked SRS AIRBAG.
- Two knee airbags. The driver's knee airbag is stored under the steering column; the front passenger's knee airbag is stored under the glove box. Both are marked SRS AIRBAG.
- Two side airbags, one for the driver and one for the front passenger. The airbags are stored in the outer edges of the seatbacks. Both are marked SIDE AIRBAG.

- Two side curtain airbags, one for each side of the vehicle. The airbags are stored in the ceiling, above the side windows. The front and rear pillars are marked SIDE CURTAIN AIRBAG.
- An electronic control unit that, when the power mode is in ON, continually monitors information about the various impact sensors, seat and buckle sensors, rollover sensor, airbag activators, seat belt tensioners, and other vehicle information. During a crash event the unit can record such information.
- Seat belt tensioners for the front seats and outer rear seats. In addition, the driver's and front passenger's seat belt buckles incorporate sensors that detect whether or not the belts are fastened.
- Driver's seat position sensor. This sensor detects the driver's seat slide position to help determine the optimal deployment of the driver's airbag.

- Weight sensors in the front passenger's seat. The sensors are used for occupant classification to activate or deactivate the front passenger's airbag.
- Impact sensors that can detect a moderate-to-severe front or side impact.
- O An indicator on the center console that alerts you that the front passenger's front airbag has been turned off.
- An indicator on the instrument panel that alerts you to a possible problem with your airbag system or seat belt tensioners.
- A rollover sensor that can detect if your vehicle is about to roll over and signal the control unit to deploy both side curtain airbags.

Safe Driving

# Important Facts About Your Airbags

Airbags can pose serious hazards. To do their job, airbags must inflate with tremendous force. So, while airbags help save lives, they can cause burns, bruises, and other minor injuries, sometimes even fatal ones if occupants are not wearing their seat belts properly and sitting correctly.

**What you should do:** Always wear your seat belt properly and sit upright and as far back from the steering wheel as possible while allowing full control of the vehicle. A front passenger should move their seat as far back from the dashboard as possible.

Remember, however, that no safety system can prevent all injuries or deaths that can occur in a severe crash, even when seat belts are properly worn and the airbags deploy.

## Do not place hard or sharp objects between yourself and a front airbag.

Carrying hard or sharp objects on your lap, or driving with a pipe or other sharp object in your mouth, can result in injuries if your front airbag inflates.

Do not attach or place objects on the front, driver's knee and front passenger's knee airbag covers. Objects on the covers marked SRS AIRBAG could interfere with the proper operation of the airbags or be propelled inside the vehicle and hurt someone if the airbags inflate.

#### ➢Important Facts About Your Airbags

Do not attempt to deactivate your airbags. Together, airbags and seat belts provide the best protection.

When driving, keep hands and arms out of the deployment path of the front airbag by holding each side of the steering wheel. Do not cross an arm over the airbag cover.

# **Types of Airbags**

Your vehicle is equipped with four types of airbags:

- Front airbags: Airbags in front of the driver's and front passenger's seats.
- Knee airbags: Airbags under the steering column and under the glove box.
- Side airbags: Airbags in the driver's and front passenger's seat-backs.
- Side curtain airbags: Airbags above the side windows.

Each is discussed in the following pages.

# Front Airbags (SRS)

The front SRS airbags inflate in a moderate-to-severe frontal collision to help protect the head and chest of the driver and/or front passenger.

**SRS** (Supplemental Restraint System) indicates that the airbags are designed to supplement seat belts, not replace them. Seat belts are the occupant's primary restraint system.

# Housing Locations

The front airbags are housed in the center of the steering wheel for the driver, and in the dashboard for the front passenger. Both airbags are marked **SRS AIRBAG**.

## Types of Airbags

The airbags can inflate whenever the power mode is in ON.


After an airbag inflates in a crash, you may see a small amount of smoke. This is from the combustion process of the inflator material and is not harmful. People with respiratory problems may experience some temporary discomfort. If this occurs, get out of the vehicle as soon as it is safe to do so.

# ≥Front Airbags (SRS)

During a frontal crash severe enough to cause one or both front airbags to deploy, the airbags can inflate at different rates, depending on the severity of the crash, whether or not the seat belts are latched, and/ or other factors. Frontal airbags are designed to supplement the seat belts to help reduce the likelihood of head and chest injuries in frontal crashes. Front airbags are designed to inflate during moderate-to-severe frontal collisions. When the vehicle decelerates suddenly, the sensors send information to the control unit which signals one or both front airbags to inflate.

A frontal collision can be either head-on or angled between two vehicles, or when a vehicle crashes into a stationary object, such as a concrete wall.

# How the Front Airbags Work



While your seat belt restrains your torso, the front airbag provides supplemental protection for your head and chest.

The front airbags deflate immediately so that they won't interfere with the driver's visibility or the ability to steer or operate other controls.

The total time for inflation and deflation is so fast that most occupants are not aware that the airbags deployed until they see them lying in front of them.

## ➢How the Front Airbags Work

Although the driver's and front passenger's airbags normally inflate within a split second of each other, it is possible for only one airbag to deploy. This can happen if the severity of a collision is at the margin, or threshold, that determines whether or not the airbags will deploy. In such cases, the seat belt will provide sufficient protection, and the supplemental protection offered by the airbag would be minimal.

# When front airbags should not deploy

**Minor frontal crashes:** Front airbags were designed to supplement seat belts and help save lives, not to prevent minor scrapes, or even broken bones that might occur during a less than moderate-to-severe frontal crash.

**Side impacts:** Front airbags can provide protection when a sudden deceleration causes a driver or front passenger to move toward the front of the vehicle. Side airbags and side curtain airbags have been specifically designed to help reduce the severity of injuries that can occur during a moderate-to-severe side impact which can cause the driver or passenger to move toward the side of the vehicle.

**Rear impacts:** Head restraints and seat belts are your best protection during a rear impact. Front airbags cannot provide any significant protection and are not designed to deploy in such collisions.

**Rollovers:** In a rollover, your best form of protection is a seat belt or, if your vehicle is equipped with a rollover sensor, both a seat belt and a side curtain airbag. Front airbags, however, are not designed to deploy in a rollover as they would provide little if any protection.

# ■ When front airbags deploy with little or no visible damage

Because the airbag system senses sudden deceleration, a strong impact to the vehicle framework or suspension might cause one or more of the airbags to deploy. Examples include running into a curb, the edge of a hole, or other low fixed object that causes a sudden deceleration in the vehicle chassis. Since the impact is underneath the vehicle, damage may not be readily apparent.

# When front airbags may not deploy, even though exterior damage appears severe

Since crushable body parts absorb crash energy during an impact, the amount of visible damage does not always indicate proper airbag operation. In fact, some collisions can result in severe damage but no airbag deployment because the airbags would not have been needed or would not have provided protection even if they had deployed.

# Advanced Airbags

The airbags have advanced features to help reduce the likelihood of airbag related injuries to smaller occupants.

Driver's Seat Position Sensor The driver's advanced airbag system includes a seat position sensor.

Based on information from this sensor and the severity of the impact, the advanced airbag system determines the optimal deployment of the driver's airbag.

The front passenger's advanced airbag system has weight sensors. The sensors are used for occupant classification to activate or deactivate the front passenger's airbag.

For adult size occupants, the system will automatically activate the front passenger's airbag. If a small adult sits in the front passenger seat and the system does not recognize him/her as an adult, see

Passenger Airbag Off Indicator P. 61


#### Advanced Airbags

If there is a problem with the driver's seat position sensor or the passenger's seat weight sensors, the SRS indicator will come on, and in the event of a crash, the airbag will deploy (regardless of the driver's seating position or passenger's occupant classification) with a force corresponding to the severity of the impact.

Supplemental Restraint System (SRS) Indicator P. 60

For the advanced front airbags to work properly, confirm that:

- The occupant is sitting in an upright position, wearing the seat belt properly and the seat-back is not excessively reclined.
- The occupant is not leaning against the door or center console.
- The occupant's feet are placed on the floor in front of them.
- There are no objects hanging from the front passenger's seat.
- Only small, lightweight objects are in the seat-back pocket.
- The steering wheel and passenger's side dashboard are not obstructed by any object.
- No liquid has been spilled on or under the seat.



52

We advise against allowing a child age 12 or under to ride in the front passenger's seat. However, if you do allow a small child or infant to ride in the front passenger's seat, the system is designed to automatically deactivate the front passenger's airbag. Do not let a small child or infant ride in the front passenger's seat if the airbag does not automatically deactivate.

## Advanced Airbags

- There is no child seat or other object pressing against the rear of the seat or seat-back.
- There is no rear passenger pushing or pulling on the back of the front passenger's seat.
- There are no objects placed under or beside the front passenger's seat. Improperly positioned objects can interfere with the advanced airbag sensors.
- The head restraint is not contacting the roof.
   Passenger Airbag Off Indicator P. 61
- The floor mat behind the front passenger's seat is set in the correct position evenly on the floor. An improperly placed mat can interfere with the advanced airbag sensors.


Floor Mats P. 630

# **Knee Airbags**

The knee SRS airbags inflate in a moderate-to-severe frontal collision to help keep the driver and/or front passenger in the proper position and to help maximize the benefit provided by the vehicle's other safety features.

**SRS** (Supplemental Restraint System) indicates that the airbag is designed to supplement seat belts, not replace them. Seat belts are the occupant's primary restraint system.

# Housing Locations



The knee airbag for the driver and the one for the front passenger are housed under the steering column and the glove box respectively.


Both are marked SRS AIRBAG.

#### ➢Knee Airbags

Do not attach accessories on or near a knee airbag as they can interfere with the proper operation of the airbag, or even hurt someone if the airbag inflates.

The driver and front passenger should not store any items under the seat or behind their feet. The items can interfere with proper airbag deployment in the event of a moderate to severe frontal collision and may result in inadequate protection.

# Operation



The driver's and front passenger's knee airbag deploy at the same time as the driver's and front passenger's airbag, respectively.

Even if the collision is not severe enough to deploy the front airbags, the knee airbags may inflate alone.

## ■ When knee airbags deploy with little or no visible damage

Because the airbag system senses sudden deceleration, a strong impact to the vehicle framework or suspension might cause one or more of the airbags to deploy. Examples include running into a curb, the edge of a hole, or other low fixed objects that cause a sudden deceleration in the vehicle chassis. Since the impact is underneath the vehicle, damage may not be readily apparent.

# ■ When knee airbags may not deploy, even though exterior damage appears severe

Since crushable body parts absorb crash energy during an impact, the amount of visible damage does not always indicate proper airbag operation. In fact, some collisions can result in severe damage but no airbag deployment because the airbags would not have been needed or would not have provided protection even if they had deployed.

# **Side Airbags**

The side airbags help protect the torso and pelvis of the driver or a front passenger during a moderate-to-severe side impact.

# Housing Locations



The side airbags are housed in the outside edge of the driver's and passenger's seat-backs.

Both are marked **SIDE AIRBAG**.

## ≥Side Airbags


Make sure you and your front seat passenger always sit upright. Leaning into the path of a side airbag can prevent the airbag from deploying properly and increases your risk of serious injury.

Do not attach accessories on or near the side airbags. They can interfere with the proper operation of the airbags, or hurt someone if an airbag inflates.

Do not cover or replace the front seat-back covers without consulting a dealer.

Improperly replacing or covering front seat-back covers can prevent your side airbags from properly deploying during a side impact.

# Operation



When the sensors detect a moderate-tosevere side impact, the control unit signals the side airbag on the impact side to immediately inflate.

## ■ When a side airbag deploys with little or no visible damage

Because the airbag system senses sudden acceleration, a strong impact to the side of the vehicle's framework can cause a side airbag to deploy. In such cases, there may be little or no damage, but the side impact sensors detected a severe enough impact to deploy the airbag.


# When a side airbag may not deploy, even though visible damage appears severe

It is possible for a side airbag not to deploy during an impact that results in apparently severe damage. This can occur when the point of impact was toward the far front or rear of the vehicle, or when the vehicle's crushable body parts absorbed most of the crash energy. In either case, the side airbag would not have been needed nor provided protection even if it had deployed.

# Side Curtain Airbags

The side curtain airbags help protect the heads of the driver and passengers in the outer seating positions during a moderate-to-severe side impact. The side curtain airbags equipped in this vehicle are also designed to help reduce the likelihood of partial and complete ejection of vehicle occupants through side windows in crashes, particularly rollover crashes.

# Housing Locations



The side curtain airbags are located in the ceiling above the side windows on both sides of the vehicle.

## Side Curtain Airbags


To get the best protection from the side curtain airbags, occupants should wear their seat belts properly and sit upright and well back in their seats.

Do not attach any objects to the side windows or roof pillars as they can interfere with the proper operation of the side curtain airbags.

If the impact is on the passenger's side, the passenger's side curtain airbag deploys even if there are no occupants on that side of the vehicle.

If the SRS control unit senses that your vehicle is about to rollover, it immediately deploys both side curtain airbags and activates the seat belt tensioners for the front seats and outer rear seats.

# Operation



The side curtain airbag is designed to deploy in a rollover or a moderate-to-severe side impact.

# When side curtain airbags deploy in a frontal collision

One or both side curtain airbags may also inflate in a moderate-to-severe angled frontal collision.

# Airbag System Indicators

If a problem occurs in the airbag system, the SRS indicator will come on and a message appears on the multi-information display.

# Supplemental Restraint System (SRS) Indicator



■ When the power mode is set to ON The indicator comes on for a few seconds, then goes off. This tells you the system is working properly. Supplemental Restraint System (SRS) Indicator


# 

Ignoring the SRS indicator can result in serious injury or death if the airbag systems or tensioners do not work properly.

Have your vehicle checked by a dealer as soon as possible if the SRS indicator alerts you to a possible problem.

If the indicator comes on at any other time, or does not come on at all, have the system checked by a dealer as soon as possible. If you don't, your airbags and seat belt tensioners may not work properly when they are needed.

# Passenger Airbag Off Indicator



# When the passenger airbag off indicator comes on

The indicator comes on to alert you that the passenger's airbag has been turned off.

This occurs if the seat is empty or when the weight sensors determine that a small child or infant is on the passenger seat.

Children age 12 or under should always ride properly restrained in a back seat. ➡ Child Safety P. 64

If the indicator is on, in the event of a crash the passenger's airbag will not deploy. The passenger's knee airbag will not deploy, either.

When you set the power mode to ON, the indicator comes on and goes off a few seconds later to indicate that system checks are being performed. After that, the indicator comes on or off depending on the passenger's occupant classification.

## Passenger Airbag Off Indicator

To ensure the passenger is detected properly, confirm that:

- The occupant is sitting in an upright position, wearing the seat belt properly and the seat-back is not excessively reclined.
- The occupant is not leaning against the door or center console.
- The occupant's feet are placed on the floor in front of them.
- There are no objects hanging from the front passenger's seat.
- Only small, lightweight objects are in the seat-back pocket.
- No liquid has been spilled on or under the seat.
- There is no child seat or other object pressing against the rear of the seat or seat-back.
- There is no rear passenger pushing or pulling on the back of the front passenger's seat.
- There are no objects placed under or beside the front passenger's seat. Improperly positioned objects can interfere with the advanced airbag sensors.
- The floor mat behind the front passenger's seat is set in the correct position evenly on the floor. An improperly placed mat can interfere with the advanced airbag sensors.
- The head restraint is not contacting the roof.

#### ≥Passenger Airbag Off Indicator

The passenger airbag off indicator may come on and go off periodically if the total weight on the seat is near the airbag cutoff threshold. For a small adult, depending on physique and posture, the system may not recognize him/her as an adult and thus deactivate the passenger's airbag.

If this occurs, please confirm that the conditions set forth in the above bullet points on the previous page are met.

If the above conditions are met and the indicator is still on, then with the transmission in park, set the power mode to OFF and back to ON.

Have your vehicle checked by a dealer as soon as possible if:

- All of the above conditions are met, and the indicator comes on with an adult seated in the front passenger seat.
- The seat is empty and the indicator is off.
- The indicator does not come on and go off after setting the power mode to ON as described. Do not allow an adult passenger to ride in the front seat when the indicator is on.

# Airbag Care

You do not need to, and should not, perform any maintenance on or replace any airbag system components yourself. However, you should have your vehicle inspected by a dealer in the following situations:

## When the airbags have deployed

If an airbag has inflated, the control unit and other related parts must be replaced. Similarly, once an automatic seat belt tensioner has been activated, it must be replaced.

## When the vehicle has been in a moderate-to-severe collision

Even if the airbags did not inflate, have your dealer inspect the following: the driver's seat position sensor, weight sensors in the passenger's seat, seat belt tensioners for the front seats and outer rear seats, and each seat belt that was worn during the crash.

# ■ Do not remove or modify a front seat without consulting a dealer

This would likely disable or affect the proper operation of the driver's seat position sensor or the weight sensors in the passenger's seat. If it is necessary to remove or modify a front seat to accommodate a person with disabilities, contact an Acura dealer, or for U.S. vehicles, Acura Client Relations at 1-800-382-2238 and for Canadian vehicles, Acura Client Services at 1-888-9-ACURA-9.

## ≫Airbag Care

We recommend against the use of salvaged airbag system components, including the airbag, tensioners, sensors, and control unit.

# **Child Safety**

# **Protecting Child Passengers**

Each year, many children are injured or killed in vehicle crashes because they are either unrestrained or not properly restrained. In fact, vehicle crashes are the number one cause of death of children ages 12 and under.

To reduce the number of child deaths and injuries, every state, Canadian province and territory requires that infants and children be properly restrained when they ride in a vehicle.

## Children should sit properly restrained in a rear seat. This is because:



- An inflating front airbag can injure or kill a child sitting in the front seat.
- A child in the front seat is more likely to interfere with the driver's ability to safely control the vehicle.
- Statistics show that children of all sizes and ages are safer when they are properly restrained in a rear seat.

#### ➢Protecting Child Passengers

# 

Children who are unrestrained or improperly restrained can be seriously injured or killed in a crash.

Any child too small for a seat belt should be properly restrained in a child seat. A larger child should be properly restrained with a seat belt, using a booster seat if necessary.

The National Highway Traffic Safety Administration and Transport Canada recommend that all children ages 12 and under be properly restrained in a rear seat. Some states or provinces/territories have laws restricting where children may ride.

- Never hold a child on your lap because it is impossible to protect them in the event of a collision.
- Never put a seat belt over yourself and a child. During a crash, the belt would likely press deep into the child and cause serious or fatal injuries.
- Never let two children use the same seat belt. Both children could be very seriously injured in a crash.
- Any child who is too small to wear a seat belt correctly must be restrained in an approved child seat that is properly secured to the vehicle using either the seat belt or the lower anchors of the LATCH system.
- Do not allow children to operate the doors, windows, or seat adjustments.
- Do not leave children in the vehicle unattended, especially in hot weather when the inside of the vehicle can get hot enough to kill them. They could also activate vehicle controls causing it to move unexpectedly.

#### Protecting Child Passengers

# 

Allowing a child to play with a seat belt or wrap one around their neck can result in serious injury or death.

Instruct children not to play with any seat belt and make sure any unused seat belt a child can reach is buckled, fully retracted, and locked.

To deactivate a lockable retractor, release the buckle and allow the seat belt to wind up all the way.

To remind you of the passenger's front airbag hazards and child safety, your vehicle has warning labels on the dashboard (U.S. models) and on the front visors. Please read and follow the instructions on these labels.

Safety Labels P. 78

# Safety of Infants and Small Children

# Protecting Infants

An infant must be properly restrained in a rear-facing child seat until the infant reaches the seat manufacturer's weight or height limit for the seat.



■ Positioning a rear-facing child seat Child seats must be placed and secured in a rear seating position.

When properly installed, a rear-facing child seat may prevent the driver or a front passenger from moving their seat all the way back, or from locking their seat-back in the desired position. Make sure that there is no contact between the child seat and the seat in front of it.

It can also interfere with proper operation of the passenger's advanced front airbag system.

## Airbags P. 46

If this occurs, we recommend that you install the child seat directly behind the front passenger's seat, move the seat as far forward as needed, and leave it unoccupied. Or, you may wish to get a smaller rear-facing child seat.

#### ➢Protecting Infants

# 

Placing a rear-facing child seat in the front seat can result in serious injury or death during a crash.

Always place a rear-facing child seat in the rear seat, not the front.

Experts recommend use of a rear-facing seat for a child so long as the child's height and weight are appropriate for a rear-facing seat.

Infants should never be seated in a forward-facing position.

Always refer to the child seat manufacturer's instructions before installation.

Do not allow a front seat to rest against a child seat installed in a rear seating position: The weight sensor in the front seat may not correctly detect the actual weight of the occupant.

# Protecting Smaller Children

If a child has exceeded the weight and height limitations of a rear-facing child seat, the child should be properly restrained in a firmly secured forward-facing child seat until they exceed the weight and height limitations for the forward-facing child seat.



■ Forward-facing child seat placement We strongly recommend placing a forwardfacing child seat in a rear seating position.

Placing a forward-facing child seat in the front seat can be hazardous, even with advanced front airbags that automatically turn the passenger's front airbag off. A rear seat is the safest place for a child.

#### ➢Protecting Smaller Children

# 

Placing a forward-facing child seat in the front seat can result in serious injury or death if the front airbag inflates.

If you must place a forward-facing child seat in front, move the vehicle seat as far back as possible, and properly restrain the child.

Educate yourself about the laws and regulations regarding child seat use where you are driving, and follow the child seat manufacturer's instructions.

# Selecting a Child Seat

Most child seats are LATCH-compatible (Lower Anchors and Tethers for Children). Some have a rigid-type connector, while others have a flexible-type connector. Both are equally easy to use. Some existing and previously owned child seats can only be installed using the seat belt. Whichever type you choose, follow the child seat manufacturer's use and care instructions including recommended expiration dates as well as the instructions in this manual. Proper installation is key to maximizing your child's safety.

In seating positions and vehicles not equipped with LATCH, a LATCH-compatible child seat can be installed using the seat belt and a top tether for added security. This is because all child seats are required to be designed so that they can be secured with a lap belt or the lap part of a lap/shoulder belt. In addition, the child seat manufacturer may advise that a seat belt be used to attach a LATCH-compatible seat once a child reaches a specified weight. Please read the child seat owner's manual for proper installation instructions.

## Important consideration when selecting a child seat

Make sure the child seat meets the following three requirements:

- The child seat is the correct type and size for the child.
- The child seat is the correct type for the seating position.
- The child seat is compliant with Federal Motor Vehicle Safety Standard 213 or Canadian Motor Vehicle Safety Standard 213.

#### Selecting a Child Seat


Installation of a LATCH-compatible child seat is simple.

LATCH-compatible child seats have been developed to simplify the installation process and reduce the likelihood of injuries caused by incorrect installation.

# Installing a LATCH-Compatible Child Seat

A LATCH-compatible child seat can be installed in either of the two outer rear seats. A child seat is attached to the lower anchors with either the rigid or flexible type of connectors.

Marks
Cover



- **1.** Raise the head restraint to its highest position.
- **2.** Locate the anchor marks affixed to the base of the seat cushion.
- **3.** Pull out the anchor covers with the marks to expose the lower anchors.
- **4.** Place the child seat on the vehicle seat, then attach the child seat to the lower anchors according to the instructions that came with the child seat.
  - When installing the child seat, make sure that the lower anchors are not obstructed by the seat belt or any other object.

Installing a LATCH-Compatible Child Seat

# 

Never attach two child seats to the same anchor. In a collision, one anchor may not be strong enough to hold two child seat attachments and may break, causing serious injury or death.

For your child's safety, when using a child seat installed using the LATCH system, make sure that the child seat is properly secured to the vehicle. A child seat that is not properly secured will not adequately protect a child in a crash and may cause injury to the child or other vehicle occupants.



# Straight Top Tether Type Tether Strap Hook Anchor Other Top Tether Type Tether Strap Hook

#### Straight Top Tether Type

**5.** Route the tether strap between the head restraint legs.

Make sure the strap is not twisted.

## Other Top Tether Type

**5.** Route the tether strap outside the head restraint legs.

Make sure the strap is not twisted.

## All Types

- **6.** Secure the tether strap hook to the anchor.
- **7.** Tighten the tether strap as instructed by the child seat manufacturer.
- **8.** Make sure the child seat is firmly secured by rocking it forward and back and side to side; little movement should be felt.

#### ➢Installing a LATCH-Compatible Child Seat

# 

Using the outer rear seats' inner anchors to secure a LATCH-compatible child seat in the center seating position may result in failure of the child seat, causing injury or death.

Only use the outer rear seats' inner anchors to install a child seat in the center seating position if the manufacturer's instructions expressly permit.

# Installing a LATCH-compatible child seat in the rear center seat

Each outer rear seat is equipped with a pair of lower anchors which are used to secure a LATCHcompatible child seat. The rear center seat, however, is not equipped with anchors of any kind. The inner and outer anchors are spaced apart at a standard distance of 11 inches (280 mm). The distance between the two inner anchors is 16.3 inches (415 mm). LATCH-compatible restraint systems that are fitted with rigid-type attachments cannot be installed in the rear center seat. However, a system fitted with flexible-type attachments can be installed in the center seat, provided that the manufacturer's instructions for that system permit the use of the inner anchors with the stated spacing. Before seating a child, make sure that the system is properly attached to both the lower anchors and tether anchors

## Installing a Child Seat with a Lap/Shoulder Seat Belt

A child seat can be installed with a lap/shoulder belt in any rear seat or, if absolutely necessary, the front passenger seat.





- **1.** Place the child seat on the vehicle seat.
- **2.** Route the seat belt through the child seat according to the seat manufacturer's instructions, and insert the latch plate into the buckle.
  - ▶ Insert the latch plate fully until it clicks.
- **3.** Slowly pull the shoulder part of the belt all the way out until it stops. This activates the lockable retractor.
- **4.** Let the seat belt retract a few inches and check that the retractor has switched modes by pulling on the webbing. It should not pull out again until it is reset by removing the latch plate from the buckle.
  - If you are able to pull the shoulder belt out, the lockable retractor is not activated. Slowly pull the seat belt all the way out, and repeat steps 3 – 4.

#### Installing a Child Seat with a Lap/Shoulder Seat Belt

A child seat that is not properly secured will not adequately protect a child in a crash and may cause injury to the child or other vehicle occupants.





- **5.** Grab the shoulder part of the seat belt near the buckle, and pull up to remove any slack from the lap part of the belt.
  - When doing this, place your weight on the child seat and push it into the vehicle seat.
- **6.** Make sure the child seat is firmly secured by rocking it forward and back and side to side; less than one inch of movement should occur near the seat belt.
- **7.** Make sure any unused seat belt that a child can reach is buckled, the lockable retractor is activated, and the belt is fully retracted and locked.

Installing a Child Seat with a Lap/Shoulder Seat Belt

To deactivate a lockable retractor, release the buckle and allow the seat belt to wind up all the way.

## Adding Security with a Tether





A tether anchor point is provided behind each rear seating position.

If you have a child seat that comes with a tether but can be installed with a seat belt, the tether may be used for additional security.

#### Using an outer anchor Straight Top Tether Type

**1.** Put the head restraint to its upper-most position, then route the tether strap through the head restraint legs. Make sure the strap is not twisted.

#### Other Top Tether Type


**1.** Put the head restraint to its upper-most position, then route the tether strap outside the head restraint legs. Make sure the strap is not twisted.

#### All Types

- **2.** Secure the tether strap hook to the anchor.
- **3.** Tighten the tether strap as instructed by the child seat manufacturer.

#### Moding Security with a Tether

Always use a tether for forward-facing child seats whether using the seat belt or lower anchors.



#### Using the center anchor

**1.** Lower the head restraint to its lowest position.

#### Straight Top Tether Type

**2.** Route the tether strap over the head restraint. Make sure the strap is not twisted.

## Other Top Tether Type

**2.** Route the tether strap outside the head restraint. Make sure the strap is not twisted.

## All Types

- **3.** Secure the tether strap hook to the anchor.
- **4.** Tighten the tether strap as instructed by the child seat manufacturer.

# Safety of Larger Children

# Protecting Larger Children

The following pages give instructions on how to check proper seat belt fit, what kind of booster seat to use if one is needed, and important precautions for a child who must sit in front.

# Checking Seat Belt Fit

When a child is too big for a child seat, secure the child in a rear seat using the lap/ shoulder seat belt. Have the child sit upright and all the way back, then answer the following questions.



## Checklist

- Do the child's knees bend comfortably over the edge of the seat?
- Does the shoulder belt cross between the child's neck and arm?
- Is the lap part of the seat belt as low as possible, touching the child's thighs?
- Will the child be able to stay seated like this for the whole trip?

If you answer yes to all these questions, the child is ready to wear the lap/shoulder seat belt correctly. If you answer no to any question, the child needs to ride on a booster seat until the seat belt fits properly without a booster seat.

#### Safety of Larger Children

# 

Allowing a child age 12 or under to sit in front can result in injury or death if the passenger's front airbag inflates.

If a larger child must ride in front, move the vehicle seat as far to the rear as possible, have the child sit up properly and wear the seat belt properly, using a booster seat if needed.

## **Booster Seats**



If a lap/shoulder seat belt cannot be used properly, position the child in a booster seat in the rear seat. For the child's safety, check that the child meets the booster seat manufacturer's recommendations.

## Protecting Larger Children-Final Checks

Your vehicle has a rear seat where children can be properly restrained. If you ever have to carry a group of children, and a child must ride in front:

- Make sure you read and fully understand the instructions and safety information in this manual.
- Move the front passenger seat as far back as possible.
- Have the child sit upright and well back in the seat.
- Check that the seat belt is properly positioned so that the child is secure in the seat.

#### Monitoring child passengers

We strongly recommend that you keep an eye on child passengers. Even older, more mature children sometimes need to be reminded to fasten their seat belts and sit up properly.

#### Booster Seats

When installing a booster seat, make sure to read the instructions that came with it, and install the seat accordingly.

There are high- and low-type booster seats. Choose a booster seat that allows the child to wear the seat belt correctly.

Some U.S. states and Canadian provinces and territories require children to use a booster seat until they reach a given age or weight (e.g., 6 years or 60 lbs). Be sure to check current laws in the state or province, or territory where you intend to drive.

# **Carbon Monoxide Gas**

The engine exhaust from this vehicle contains carbon monoxide, a colorless, odorless, and highly toxic gas. As long as you properly maintain your vehicle, carbon monoxide gas will not get into the interior.

### Have the exhaust system inspected for leaks whenever

- The exhaust system is making an unusual noise.
- The exhaust system may have been damaged.
- The vehicle is raised for an oil change.

When you operate a vehicle with the tailgate open, airflow can pull exhaust gas into the interior and create a hazardous condition. If you must drive with the tailgate open, open all the windows and set the climate control system as shown below.

- **1.** Select the fresh air mode.
- 2. Select the 👬 mode.
- **3.** Set the fan speed to high.
- 4. Set the temperature control to a comfortable setting.

Adjust the climate control system in the same manner if you sit in your parked vehicle with the engine running.

■Carbon Monoxide Gas

# 

Carbon monoxide gas is toxic.

Breathing it can cause unconsciousness and even kill you.

Avoid any enclosed areas or activities that expose you to carbon monoxide.


An enclosed area such as a garage can quickly fill up with carbon monoxide gas.

Do not run the engine with the garage door closed. Even when the garage door is open, drive out of the garage immediately after starting the engine.


# **Label Locations**

These labels are in the locations shown. They warn you of potential hazards that can cause serious injury or death. Read these labels carefully.

If a label comes off or becomes hard to read (except for the U.S. dashboard label which may be removed by the owner), contact a dealer for a replacement.



This chapter describes the buttons, indicators, and gauges that are used while driving.



# Indicators

Instrument Pane

BRAKE *1 U.S. (①) *1 Canada	Parking Brake and Brake System Indicator (Red)	→ P. 81
BRAKE *1 SYSTEM U.S. (1) *1 Canada	Parking Brake and Brake System Indicator (Amber)	→ P. 83
BRAKE HOLD	Automatic Brake Hold System Indicator	→ P. 85
HOLD U.S. (A) Canada	Automatic Brake Hold Indicator	→ P. 85
*1	Malfunction Indicator Lamp	→ P. 86
- + *1	Charging System Indicator	→ P. 87
D	Gear Position Indicator	→ P. 87
™2	M (sequential mode) Indicator/Gear Selection Indicator	→ P. 87
$\mathbb{R}$	Transmission System Indicator	→ P. 88
Å	Seat Belt Reminder Indicator	→ P. 93
	Low Fuel Indicator (Amber)	→ P. 94

(AB) *1	Anti-lock Brake System (ABS) Indicator	→ P. 94
*1	Supplemental Restraint System Indicator	→ P. 95
<b>•!</b> *1	Electric Power Steering (EPS) System Indicator	<b>→</b> P. 95
<b>R</b> *1	Vehicle Stability Assist™ (VSA®) System Indicator	→ P. 96
OFF *1	Vehicle Stability Assist™ (VSA®) <b>OFF</b> Indicator	→ P. 96
(!) *1	Low Tire Pressure/TPMS Indicator	→ P. 97
<b>+</b> +	Turn Signal and Hazard Warning Indicators	→ P. 98
∋0 <i>0</i> ∈	Lights On Indicator	→ P. 98
	High Beam Indicator	→ P. 98
≣@ *1	Auto High-Beam Indicator	→ P. 98
朷	Fog Light Indicator*	→ P. 98
3	Cruise Mode Indicator (White/Green)	→ P. 101
<b>i</b>	System Message Indicator	→ P. 100
*1	Maintenance Minder Indicator	→ P. 101

<b>AWD</b> *1	Super Handling-All Wheel Drive™ ( <b>SH-AWD®</b> ) System Indicator <sup>*</sup>	→ P. 101
(A) OFF	Auto Idle Stop <b>OFF</b> Indicator	→ P. 90
(Å)	Auto Idle Stop Suspend Indicator	→ P. 90
(A) *1	Auto Idle Stop System Indicator (Amber)	→ P. 90
(A)	Auto Idle Stop Indicator (Green)	→ P. 90
0	Immobilizer System Indicator	→ P. 99
0	Security System Alarm Indicator	→ P. 99
*1	Adaptive Cruise Control (ACC) with Low Speed Follow Indicator (Amber)	→ P. 102
2	Adaptive Cruise Control (ACC) with Low Speed Follow Indicator (White/ Green)	→ P. 102
×1	Lane Keeping Assist System (LKAS) Indicator (Amber)	→ P. 102
6	Lane Keeping Assist System (LKAS) Indicator (White/ Green)	→ P. 102
	Safety Support Indicator (Amber)	→ P. 103
	Safety Support Indicator (Green/Gray)	→ P. 106

\*1: When you set the power mode to ON, these indicators come on to indicate that system checks are being performed. They go off a few seconds later or after the engine has started. If an indicator does not come on or turn off, there may be a malfunction in the corresponding system. To resolve the issue, follow the instructions in the owner's manual.

Indicator	Name	On/Blinking	Explanation	Message
U.S.		<ul> <li>Comes on when the parking brake is applied, and goes off when it is released.</li> </ul>	<ul> <li>The beeper sounds and the indicator comes on if you drive with the parking brake applied.</li> <li>Comes on for about 30 seconds when you apply the electric parking brake while the power mode is in ACCESSORY or VEHICLE OFF, then goes off.</li> <li>Stays on for about 30 seconds when you set the power mode to VEHICLE OFF while the electric parking brake is applied, then goes off.</li> </ul>	EBARE Release Parking Brake
BRAKE Canada (Red)	Parking Brake and Brake System Indicator (Red)	• Comes on if there is a problem with the brake system.	<ul> <li>Comes on along with the Parking Brake and Brake System Indicator (amber) - Immediately stop in a safe place. Contact a dealer for repair. The brake pedal becomes harder to operate. Depress the pedal further than you normally do.</li> <li>If the Brake System Indicator (Red) Comes On or Blinks at the Same Time When the Brake System Indicator (Amber) Comes On P. 675</li> <li>Comes on along with the ABS indicator - Have your vehicle checked by a dealer.</li> <li>If the Brake System Indicator (Red) Comes On or Blinks P. 673</li> </ul>	RAKE Brake System Problem. Brake Performance May Be Reduced. See Your Dealer.

Indicator	Name	On/Blinking	Explanation	Message
U.S. BRAKE Canada	Parking Brake and Brake System Indicator (Red)	• Comes on if there is a problem with the brake system.	<ul> <li>Blinks and the Parking Brake and Brake System Indicator (amber) comes on at the same time - There is a problem with the electric parking brake system. The parking brake may not be set. Avoid using the parking brake and have your vehicle checked by a dealer immediately.</li> <li>If the Brake System Indicator (Red) Comes On or Blinks at the Same Time When the Brake System Indicator (Amber) Comes On P. 675</li> </ul>	Brake System Problem Brake System Problem Brake Performance May Be Reduced See Your Dealer.
(Red)		• Comes on when the brake fluid level is low.	<ul> <li>Comes on while driving - Make sure the parking brake is released. Stop in a safe place and check the brake fluid level.</li> <li>What to do when the indicator comes on while driving P. 673</li> </ul>	BRAKE Brake Fluid Low, Do Not Drive. Check Fluid Level.

Indicator	Name	On/Blinking	Explanation	Message
Canada	Parking Brake and Brake System Indicator (Amber)	• Comes on if there is a problem with a system related to braking other than the conventional brake system.	<ul> <li>Comes on while driving - Avoid high speeds and sudden braking. Take the vehicle to a dealer immediately.</li> </ul>	U.S. BRAKE SYSTEM Brake System Problem Brake System Problem See Your Dealer Canada

Indicator	Name	On/Blinking	Explanation	Message
Canada	Parking Brake and Brake System Indicator (Amber)	<ul> <li>Comes on if there is a problem with the electric parking brake system and/or the automatic brake hold system.</li> </ul>	<ul> <li>Stays on constantly - Avoid using the parking brake and have your vehicle checked by a dealer immediately.</li> </ul>	U.S. BRAKE SYSTEM Brake Hold System Problem Apply Brake When Stopped See Your Dealer. BRAKE SYSTEM Brake Not Available See Your Dealer. Canada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conada Conado

Indicator	Name	On/Blinking	Explanation	Message
U.S. BRAKE SYSTEM Canada (Amber)	Parking Brake and Brake System Indicator (Amber)	<ul> <li>Comes on if there is a problem with the radar sensor.</li> <li>Indicator may come on temporarily when the Maximum Load Limit is exceeded.</li> </ul>	<ul> <li>Make sure the total load is within the Maximum Load Limit.</li> <li>Maximum Load Limit P. 433</li> <li>Stays on constantly - Have your vehicle checked by a dealer.</li> </ul>	
BRAKE HOLD	Automatic Brake Hold System Indicator	<ul> <li>Comes on when the automatic brake hold system is on.</li> </ul>	Automatic Brake Hold P. 550	BRAKE HOLD Brake Hold System Standby
U.S. HOLD Canada	Automatic Brake Hold Indicator	<ul> <li>Comes on when the automatic brake hold is activated.</li> </ul>	Automatic Brake Hold P. 550	—

Indicator Name	On/Blinking	Explanation	Message
	• After you have set the power mode to ON, the vehicle performs system checks. However, if the readiness codes have not been set by that time, this indicator will blink five times and then go off.	<ul> <li>Readiness codes are part of the on-board diagnostics for the emissions control systems.</li> <li>Testing of Readiness Codes P. 695</li> </ul>	Emissions System Problem Power May Be Reduced. See Your Dealer.
Herein Malfunction Indicator Lamp	<ul> <li>Comes on if there is a problem with the emissions control systems.</li> <li>Blinks when a misfire in the engine's cylinders is detected.</li> </ul>	If the Malfunction Indicator Lamp Comes On or Blinks P. 672	Emission System Problem Avoid Heavy Acceleration And High Speed

Indicator	Name	On/Blinking	Explanation	Message
<u>- +</u>	Charging System Indicator	• Comes on when there is a problem with the charging system.	<ul> <li>Stop in a safe place and contact a dealer immediately.</li> <li>Checking the Battery P. 623</li> <li>If the Charging System Indicator Comes On P. 672</li> </ul>	12 Voit Battery Charging System Problem. Do Not Drive.
D	Gear Position Indicator	• Indicates the current gear selection.	Shifting P. 451	—
™2	M (sequential mode) Indicator/Gear Selection Indicator	• Comes on when the sequential mode is applied.	Sequential Mode P. 457	-

Indicator	Name	On/Blinking	Explanation	Message
		<ul> <li>The current gear selection blinks if the transmission system has a problem.</li> </ul>	<ul> <li>Blinks while driving - Avoid sudden starts and acceleration and have your vehicle checked by a dealer immediately.</li> </ul>	Transmission System Problem. Performance May Be Reduced. See Your Dealer.
178	Transmission	• The indicated current gear selection blinks if you cannot put the transmission into R due to a transmission system failure.	<ul> <li>Avoid sudden starts, sudden acceleration and high speed, and have your vehicle checked by a dealer immediately.</li> </ul>	Transmission System Problem. Reverse Gear Not Available. See Your Dealer.
Ø	System Indicator	• The indicated current gear selection blinks if the transmission system has a problem and the performance of the vehicle is reduced.	<ul> <li>Avoid sudden starts, sudden acceleration and high speed, and have your vehicle checked by a dealer immediately.</li> </ul>	Transmissian System Problem. Avoid Heavy Acceleration And Heavy Acceleration And See Your Dealer.
		• The indicated current gear selection blinks if the transmission system has a problem and the paddle shifters cannot be used.	<ul> <li>Have your vehicle checked by a dealer immediately.</li> </ul>	Transmission System Problem. Paddle Shifter: Not Available. See Your Dealer.

Indicator	Name	On/Blinking	Explanation	Message
		• The current gear position or all the gear positions blink if there is a problem with the transmission and the vehicle is no longer able to run.	<ul> <li>Immediately park your car in a safe place.</li> <li>Emergency Towing P. 685</li> <li>Have your vehicle checked by a dealer.</li> </ul>	Stop Driving When Sate. Transmission Problem. See Manual
Ø	Transmission System Indicator	<ul> <li>The current gear position or all the gear positions blink if there is a problem with the transmission and it is not possible to select P.</li> </ul>	<ul> <li>Depending on the circumstances, you can set the power mode to ON as an emergency measure.</li> <li>If the Transmission System Indicator Blinks along with the Warning Message P. 677</li> <li>While the vehicle is stopped, apply the parking brake.</li> <li>Have your vehicle checked by a dealer immediately.</li> </ul>	Transmission System Problem. Apply Parking Brake When Parked. See Your Dealer.

Indicator	Name	On/Blinking	Explanation	Message
(A)	Auto Idle Stop Indicator (Green)	• Comes on when Auto Idle Stop is in operation. The engine automatically shuts off.	Dial Auto Idle Stop P. 464	—
(A) OFF	Auto Idle Stop <b>OFF</b> Indicator	• Comes on when the Auto Idle Stop system has been turned off by the Auto Idle Stop system <b>OFF</b> button.	Auto Idle Stop System ON/OFF P. 466	Idle Stop OFF: OFF Switch Pressed. @ Intel for Status @Proof to Division
(A)	Auto Idle Stop System Indicator (Amber)	• Blinks if there is a problem with the Auto Idle Stop system.	<ul> <li>Blinks - Have your vehicle checked by a dealer.</li> </ul>	Auto Idle-Stop System Problem. See Your Dealer.
		<ul> <li>Comes on while Auto Idle Stop is temporarily suspended in the following situations.</li> </ul>	—	—
(X)	Auto Idle Stop Suspend Indicator	- Brake pedal is not fully pressed	• Depress the brake pedal firmly.	Idle Stop Temporarily Interruptot: Fully Press Brake to Enjage. () Head to Stable OFF () () Press Dirate

Indicator	Name	On/Blinking	Explanation	Message
		- The transmission is in a position other than D.		Idle Stop Temporarily Interruptot: Switch Gear to Enable Multi fue Status OFF Viet-Fuch to Denite
(Z)	Auto Idle Stop Suspend	- System charging is prioritized	Auto Idle Stop P. 464	Idle Stop Temporarily Interrupted: System Warning Up or Charging Wired for Stans off Or Feat to Stans off
	Indicator	- Climate control system is prioritized		Idle Stop Temporarily Internanced: Adjust Climate to Enable: 9 Inad the State OFF U.C. Public to Dismic
		- Engine coolant temperature is not in operating range		Kile Stop Temporarily Held ter Stand OF Held ter Stand OF Held ter Stand OF Held ter Stand OF Held Stop Temporarily Held Stop Temporarily Held Her Stand OF Held Her Stand OF Held Stop Temporarily Held Stop Temporarily

Indicator	Name	On/Blinking	Explanation	Message
Auto Idle Stu Suspend Indicator		- The Integrated Dynamics System mode is in <b>SPORT</b> or <b>SNOW</b> .	<ul> <li>Auto Idle Stop P. 464</li> <li>Acura Integrated Dynamics System P. 459</li> </ul>	Idle Stop Temporarily Interrupted: Switch Dynamic Mode to Enable: Head the Status OFF -13: Plant in Disente
		<ul> <li>The battery temperature is too low.</li> <li>Auto Idle Stop does not activate for some reason.</li> </ul>	D Auto Idle Stop P. 464	Idle Stop Temporarily Interrupted
		—	<ul> <li>If you press and hold the Auto Idle Stop OFF button, you can select whether to display the status messages or not.</li> </ul>	Idle Stop: (A) Status Messages Disabled. (A) Hald for Blanx (A) Ploofs for Reselve

Indicator	Name	On/Blinking	Explanation	Message
	Seat Belt Reminder Indicator	<ul> <li>Blinks and the beeper sounds for a few seconds if you are not wearing a seat belt when you set the power mode to ON, then the indicator comes on.</li> <li>If the front passenger is not wearing a seat belt, the indicator comes on a few seconds later.</li> <li>Comes on for a while when the rear seat belt is unfastened while the power mode in ON.</li> <li>Blinks while driving if you and/or any passenger has not fastened a seat belt. The beeper sounds and the indicator blinks at regular intervals.</li> </ul>	<ul> <li>The beeper stops and the indicator goes off when you and the passengers fasten their seat belts.</li> <li>Stays on after you and/or the passengers have fastened the seat belt(s) - A detection error may have occurred in the sensor. Have your vehicle checked by a dealer.</li> <li>Seat Belt Reminder P. 39</li> </ul>	<0+ Push to Domini

Indicator	Name	On/Blinking	Explanation	Message
	Low Fuel	• Comes on when the fuel reserve is running low (approximately 2.4 U.S. gal./9.1 Liter left).	• <b>Comes on</b> - Refuel your vehicle as soon as possible.	Fuel Low
U	Indicator (Amber)	• Blinks if there is a problem with the fuel gauge.	• Have your vehicle checked by a dealer.	Fuel Gauge System Problem: Level Not Accurate. See Your Dealer.
(ABS)	Anti-lock Brake System ( <b>ABS</b> ) Indicator	• Comes on if there is a problem with the ABS.	<ul> <li>Stays on constantly - Have your vehicle checked by a dealer. With this indicator on, your vehicle still has normal braking ability but no anti-lock function.</li> <li>Anti-lock Brake System (ABS) P. 553</li> </ul>	(ABS) Anti-Lock Brake System Problem. Brake Performance Reflaced See Your Dealer.

Indicator	Name	On/Blinking	Explanation	Message
	Supplemental Restraint System Indicator	<ul> <li>Comes on if a problem with any of the following is detected:</li> <li>Supplemental Restraint System</li> <li>Side airbag system</li> <li>Side curtain airbag system</li> <li>Seat belt tensioner</li> </ul>	<ul> <li>Stays on constantly - Have your vehicle checked by a dealer.</li> </ul>	Supplemental Restraint System Problem. See Your Dealer.
<b>@!</b>	Electric Power Steering (EPS) System Indicator	• Comes on if there is a problem with the EPS system.	<ul> <li>Stays on constantly - Have your vehicle checked by a dealer.</li> <li>Do Not Drive displays on the multi-information display - Immediately stop in a safe place and contact a dealer.</li> <li>If the Electric Power Steering (EPS) System Indicator Comes On P. 674</li> </ul>	Electric Power Steering Problem. Steering Astack Reduced. See Your Dealer. Electric Power Steering System Problem. Steering Assate Mod Available. Da Net Drive.

Indicator	Name	On/Blinking	Explanation	Message
	Vehicle Stability Assist™ (VSA®) System Indicator	<ul> <li>Blinks when VSA<sup>®</sup> is active.</li> <li>Comes on if there is a problem with the VSA<sup>®</sup> system, brake assist system, hill start assist system, starting assist brake function or agile handling assist.</li> </ul>	<ul> <li>Stays on constantly - Have your vehicle checked by a dealer.</li> <li>▶ Vehicle Stability Assist™ (VSA®), aka Electronic Stability Control (ESC), System P. 471</li> </ul>	Vehicle Stability Assist System Problem Reduced Traction And Handling. See Your Dealer. Hill Start Assist Problem. Vehicle May Roll Upon Brake Relaser, See Your Dealer.
OFF	Vehicle Stability Assist™ (VSA®) <b>OFF</b> Indicator	<ul> <li>Comes on when you partially disable VSA<sup>®</sup>.</li> </ul>	VSA <sup>®</sup> On and Off P. 472	Vehicle Stability Assist (VSA) OFF

Indicator	Name	On/Blinking	Explanation	Message
		• Comes on if the tire pressure of any of the tires becomes low.	• <b>Comes on while driving</b> - Stop in a safe place, check tire pressures, and inflate the tire(s) if necessary.	(!!)
(!)	Low Tire Pressure/TPMS Indicator	<ul> <li>Blinks for about one minute, and then stays on if there is a problem with the TPMS with Tire Fill Assist, or when a compact spare tire* is temporarily installed.</li> </ul>	<ul> <li>Blinks and remains on - Have your vehicle checked by a dealer. If the vehicle is fitted with a compact spare tire, get your regular tire repaired or replaced and put back on your vehicle as soon as you can.</li> </ul>	Tire Pressures Low

Indicator	Name	On/Blinking	Explanation	Message
<b>* *</b>	Turn Signal and Hazard Warning Indicators	<ul><li>Blinks when you operate the turn signal lever.</li><li>Blinks along with all turn signals when you press the hazard warning button.</li></ul>	Does not blink or blinks rapidly     P. 605     Replacing Light Bulbs P. 605	_
EO OE	Lights On Indicator	• Comes on when the parking, tail, and other external lights are on.	Light Switches P. 197	—
ED	High Beam Indicator	• Comes on when the high beam headlights are on.	—	—
ĒA	Auto High- Beam Indicator	• Comes on when all the operating conditions of the auto high-beam are met.	Datto High-Beam P. 201	-
钓	Fog Light Indicator*	• Comes on when the fog lights are on.	Fog Lights* P. 200	-


Indicator	Name	On/Blinking	Explanation	Message
Indicator	Immobilizer System Indicator	• Blinks if the immobilizer system cannot recognize the key information.	<ul> <li>Blinks - You cannot start the engine. Set the power mode to VEHICLE OFF, then select the ON mode again.</li> <li>Canadian models         Depress and hold the brake pedal before setting the power mode to ON.     </li> <li>Repeatedly blinks - The system may be malfunctioning. Have your vehicle checked by a dealer.</li> <li>Do not attempt to alter this system or add other devices to it. Electrical problems can occur.</li> </ul>	Canadian models Fully Release Brake + Push
Indicator	Security System Alarm Indicator	• Blinks when the security system alarm has been set.	Security System Alarm P. 183	_

Indicator	Name	On/Blinking	Explanation	Message
Ì	System Message Indicator	• Comes on along with a beep when a problem is detected. A system message on the multi-information display appears at the same time.	<ul> <li>While the indicator is on, roll the right selector wheel to see the message again.</li> <li>Switching the Display P. 139</li> <li>Refer to the Indicators information in this chapter when a system message appears on the multi-information display. Take the appropriate action for the message.</li> <li>The multi-information display does not return to the normal screen unless the warning is canceled, or the right selector wheel is pressed.</li> </ul>	_

Indicator	Name	On/Blinking	Explanation	Message
	Super Handling-All	<ul> <li>Comes on if there is a problem with the SH-AWD<sup>®</sup> system.</li> </ul>	• <b>Stays on constantly</b> - The engine drives the front wheels only in this state. Have your vehicle checked by a dealer.	AWD All Wheel Drive System Problem Only Front Wheels May Be Powered See Your Dealer.
AWD	Wheel Drive™ ( <b>SH-AWD</b> ®) Indicator*	• Blinks when the differential temperature is too high.	<ul> <li>Blinks while driving - Stop in a safe place, put the transmission into P, and idle the engine until the indicator goes off. If the indicator does not stop blinking, take your vehicle to a dealer.</li> <li>Super Handling-All Wheel Drive™ (SH-AWD®)* P. 474</li> </ul>	AWD Stop Driving When Safe All-Wheel Drive Temperature Too Hot
or	Maintenance Minder Indicator	<ul> <li>Comes on when the scheduled maintenance is due soon.</li> <li>Consequently, Maintenance Due Now and Maintenance Past Due follow.</li> </ul>	D Maintenance Minder™ P. 585	Maintenance Due Soon A 1 2 3 4 5 6 7
3	Cruise Mode Indicator (White/Green)	<ul><li>Lights up in white when you change to cruise mode.</li><li>Lights up in green when you have set a speed for cruise control.</li></ul>	To Switch ACC with Low Speed Follow to Cruise Control P. 518	—

Indicator	Name	On/Blinking	Explanation	Message
8	Adaptive Cruise Control (ACC) with Low Speed Follow Indicator (Amber)	• Comes on if there is a problem with ACC with Low Speed Follow.	• Comes on while driving - Have your vehicle checked by a dealer.	Adaptive Cruise Control System Problem. See Your Dealer.
		<ul> <li>Indicator may come on temporarily when the Maximum Load Limit is exceeded.</li> <li>ACC with Low Speed Follow has been automatically canceled.</li> </ul>	<ul> <li>Make sure the total load is within the Maximum Load Limit.</li> <li>Maximum Load Limit P. 433</li> <li>Stays on constantly - Have your vehicle checked by a dealer.</li> </ul>	
*	Adaptive Cruise Control (ACC) with Low Speed Follow Indicator (White/Green)	<ul> <li>Lights up in white when you press the  button.</li> <li>Lights up in green when you press the <b>RES/+</b> button or <b>SET/-</b> button.</li> </ul>	Adaptive Cruise Control (ACC) with Low Speed Follow P. 502	—
6	Lane Keeping Assist System (LKAS) Indicator (Amber)	• Comes on if there is a problem with the LKAS.	<ul> <li>Stays on constantly - Have your vehicle checked by a dealer.</li> </ul>	Lane Keeping Assist System Problem, See Your Dealer.
6	Lane Keeping Assist System (LKAS) Indicator (White/Green)	<ul> <li>Lights up in white when you press the LKAS button.</li> <li>Lights up in green when the LKAS is in operation.</li> </ul>	Lane Keeping Assist System (LKAS) P. 522	_

Indicator	Name	On/Blinking	Explanation	Message
		• Comes on if there is a problem with the Road Departure Mitigation system, CMBS <sup>™</sup> , Low Speed Braking Control <sup>*</sup> , or blind spot information system.	• Stays on constantly - Have your vehicle checked by a dealer.	Road Departure Mitigation System Problem See Your Dealer.
	Safety Support Indicator (Amber)	<ul> <li>Indicator may come on temporarily when the Maximum Load Limit is exceeded.</li> </ul>	<ul> <li>Make sure the total load is within the Maximum Load Limit.</li> <li>Maximum Load Limit P. 433</li> <li>Stays on constantly - Have your vehicle checked by a dealer.</li> </ul>	Collision Mitigation Braking System Problem. See Your Dealer. Low Speed Braking Control Problem. See Your Dealer. Blind Spot Information System Problem. See Your Dealer.



Indicator	Name	On/Blinking	Explanation	Message
	Safety Support Indicator (Amber)	• Comes on when the Road Departure Mitigation system, Low Speed Braking Control <sup>*</sup> and/or CMBS <sup>™</sup> shuts itself off.	<ul> <li>Indicator may come on temporarily when passing through an enclosed space, such as a tunnel.</li> <li>The area around the radar sensor is blocked by dirt, mud, etc. Stop your vehicle in a safe place and wipe the debris off with a soft cloth. Indicator may take some time to go off after the radar sensor is cleaned.</li> <li>Have your vehicle checked by a dealer if the indicator does not go off even after you have cleaned the radar sensor.</li> <li>Radar Sensor P. 543</li> </ul>	Some Driver Assist System Cannot Operate Radar Obstructed
			<ul> <li>Stays on - The temperature inside the camera is too high. Use the climate control system to cool down the camera. The system activates when the temperature inside the camera cools down.</li> <li>Front Sensor Camera P. 541</li> </ul>	Some Driver Assist Systems Cannot Operate Cannera Temperature Too High

Indicator	Name	On/Blinking	Explanation	Message
	Safety Support Indicator (Amber)	<ul> <li>Comes on when the Road Departure Mitigation system, Low Speed Braking Control* and/or CMBS<sup>™</sup> shuts itself off.</li> </ul>	<ul> <li>Stays on - The area around the camera is blocked by dirt, mud, etc. Stop your vehicle in a safe place and wipe the debris off with a soft cloth.</li> <li>Have your vehicle checked by a dealer if the indicator and message are still displayed even after you have cleaned the area around the camera.</li> <li>Front Sensor Camera P. 541</li> </ul>	Some Driver Assist Systems Cannot Operate: Clean Front Windshield
		<ul> <li>Comes on when mud, snow, or ice has accumulated in the vicinity of the blind spot information system sensor.</li> <li>Comes on when the temperature of the blind spot information system sensor is high.</li> </ul>	<ul> <li>Comes on while driving - Something may be interfering with the blind spot information system sensor. Check the vicinity of the blind spot information system sensor and remove any obstacles.</li> <li>The system will return to normal when the temperature cools down.</li> <li>Blind Spot Information System P. 479</li> </ul>	Blind Spot Information System Not Available
		<ul> <li>Models with Low Speed Braking Control</li> <li>Comes on when mud, snow, or ice accumulates in the vicinity of the sonar sensor.</li> </ul>	<ul> <li>Remove the obstacle in the vicinity of the sonar sensor.</li> <li>Low Speed Braking Control* P. 497</li> </ul>	Low Speed Braking Control Problem Parking Sensor Obstructed.

Indicator	Name	On/Blinking	Explanation	Message
( 🔂 ) Inc	afety Support dicator Green/Gray)	<ul> <li>Lights up in green when the Road Departure Mitigation system, CMBS<sup>™</sup>, Low Speed Braking Control<sup>*</sup>, and blind spot information system are on.</li> <li>Lights up in green and gray when the Road Departure Mitigation system, CMBS<sup>™</sup>, Low Speed Braking Control<sup>*</sup>, or blind spot information system, or any two or three of these systems are off.</li> <li>Lights up in gray when the Road Departure Mitigation system, CMBS<sup>™</sup>, Low Speed Braking Control<sup>*</sup>, and blind spot information system are off.</li> </ul>	<ul> <li>Road Departure Mitigation On and Off P. 532</li> <li>CMBS™ On and Off P. 490</li> <li>System On and Off P. 499</li> <li>Blind Spot Information System On and Off P. 481</li> </ul>	Road Departure Mitigation: OFF Collision Mitigation Braking Collision Mitigation Braking System OFF Low Speed Braking Control OFF Dind Spet Information System OFF

# Multi-Information Display Warning and Information Messages

The following messages appear only on the multi-information display. Roll the right selector wheel to see the message again with the system message indicator on. **■** Switching the Display P. 139

Message	Condition	Explanation
FOP Critical Failure Detected. Stop Driving When Safe. FOP Stop Driving When Safe. Stop Driving When Safe. Brake Performance Reduced. Stop Driving When Safe.	<ul> <li>Appears when the vehicle is no longer able to run due to a malfunction.</li> </ul>	• Immediately stop in a safe place.
Depress Brake Pedal And Apply Parking Brake	• Appears when there is a risk that the vehicle will move unexpectedly after you have stopped due to a malfunction with the vehicle.	<ul> <li>While the vehicle is stopped, apply the parking brake.</li> <li>Parking Brake P. 545</li> <li>Have your vehicle checked by a dealer.</li> </ul>

Message	Condition	Explanation
To Continue To Drive, Depress Brake Pedal And Push Switch	<ul> <li>Appears when you set the power mode to ON again and the vehicle is able to run.</li> </ul>	Starting the Engine P. 443
System Problem Detected Shift To Park.	<ul> <li>Appears when the engine stops without the transmission in P, and does not restart automatically.</li> <li>Appears if you open the hood while Auto Idle Stop activates.</li> </ul>	<ul> <li>If you want to set the power mode to ON, put the transmission into P.</li> <li>If you want to start the engine, follow the normal procedure.</li> <li>Starting the Engine P. 443</li> </ul>
Canadian models	• Appears when the washer fluid is low.	<ul> <li>Refill the washer fluid.</li> <li>Refilling Window Washer Fluid P. 604</li> </ul>
Cooling System Problem. Stop Engine And Allow System To Cool	• Appears if there is a problem with the cooling system.	• Drive slowly to prevent overheating and have your vehicle checked by a dealer as soon as possible.

Message	Condition	Explanation
U.S. Starter System Problem. Engine May Not Restart. See Your Dealer. Canada Starter System Problem. Engine May Not Restart. See Your Dealer.	• Appears when the starter system has a problem.	<ul> <li>As a temporary measure, press and hold the ENGINE START/STOP button for up to 15 seconds while pressing the brake pedal, manually start the engine. Have your vehicle checked by a dealer.</li> </ul>
Engine Oil Pressure Low. Stop Engine. Do Not Drive.	<ul> <li>Appears when the engine oil pressure is low.</li> </ul>	<ul> <li>Appears while driving - Immediately stop in a safe place.</li> <li>If the Engine Oil Pressure Low Warning Appears P. 671</li> </ul>
Engine Temperature Too Hot. Do Not Drive. Allow Engine To Cool.	<ul> <li>Appears when the engine coolant temperature gets abnormally high.</li> </ul>	Dverheating P. 669

Message	Condition	Explanation
U.S. TAL Date Power Tailgate System Problem. Operate Manually. See Your Dealer. Canada Power Tailgate System Problem. Operate Manually. See Your Dealer.	<ul> <li>Appears when there is a problem with the power tailgate system.</li> </ul>	<ul> <li>Manually open or close the power tailgate.</li> <li>Have the vehicle checked by a dealer.</li> </ul>
Door And Tailgate Open	<ul> <li>Appears if any door or the tailgate is not completely closed.</li> <li>Appears if any door or the tailgate is opened while driving. The beeper sounds.</li> </ul>	• Disappears when all doors and the tailgate are closed.

Message	Condition	Explanation
Automate Lighting Control System Problem Manual Controls Available See Your Dealer,	<ul> <li>Appears if there is a problem with the automatic lighting control system.</li> </ul>	<ul> <li>Appears while driving - Manually turn the lights on, and have your vehicle checked by a dealer.</li> </ul>
Headlight System Problem Headlight System Problem Headlight Performance May Be Reduced. See Your Dealer.	• Appears if there is a problem with the headlights.	• <b>Appears while driving</b> - The headlights may not be on. When conditions allow you to drive safely, have your vehicle checked by a dealer as soon as possible.
Charging System Problem	<ul> <li>Appears when there is a problem with the battery charging system.</li> </ul>	• Have your vehicle checked by a dealer.
Dynamic Mode Change Unavailable	• Appears if the dynamic mode cannot be changed due to certain situations, such as a system error or adverse driving conditions.	Acura Integrated Dynamics System P. 459

Message	Condition	Explanation
BRAKE HOLD Brake Hold System OFF	• Appears when the automatic brake hold system is turned off.	Automatic Brake Hold P. 550
To Enable Brake Hold: Seat Belt = Push	<ul> <li>Appears when the automatic brake hold button is pressed without wearing the driver's seat belt.</li> </ul>	<ul> <li>Fasten the driver's seat belt.</li> <li>Automatic Brake Hold P. 550</li> </ul>
To Disable Brake Hold: Brake + Push	• Appears when the automatic brake hold button is pressed without depressing the brake pedal while the automatic brake hold is in operation.	<ul> <li>Press the automatic brake hold button with the brake pedal depressed.</li> <li>Automatic Brake Hold P. 550</li> </ul>
BRAKE Parking Brake Engaged	• Appears when the parking brake is applied automatically while it is in operation.	<ul> <li>Automatic Brake Hold P. 550</li> <li>Parking Brake P. 545</li> </ul>

Message	Condition	Explanation
Brake Hold Disabled. Apply Brake Pedal	• Appears if the automatic brake hold is automatically canceled while it is in operation.	<ul> <li>Immediately depress the brake pedal.</li> </ul>
To Release Parking Brake Brake + Pull	• Appears when the electric parking brake switch is pulled without depressing the brake pedal while the electric parking brake is in operation.	<ul> <li>Pull the electric parking brake switch with the brake pedal depressed.</li> <li>Parking Brake P. 545</li> </ul>
Check Rear Seats	• Appears when you set the power mode to VEHICLE OFF, if the rear doors were opened shortly before or after the vehicle was powered on.	<ul> <li>Check the rear seat for passengers or items before exiting the vehicle.</li> <li>Rear Seat Reminder P. 224</li> </ul>
Keyless Access System Problem. See Your Dealer.	<ul> <li>Appears as soon as a problem is detected in the keyless access system or keyless starting system.</li> </ul>	• <b>Appears constantly</b> - Have your vehicle checked by a dealer.

Message	Condition	Explanation
Keyless Remote Nat Detected	• Appears when you close the door with the power mode in ON without the keyless remote inside the vehicle.	<ul> <li>Disappears when you bring the keyless remote back inside the vehicle and close the door.</li> <li>Keyless Remote Reminder P. 195</li> </ul>
Change Keyless Remote Battery	<ul> <li>Appears when the keyless remote battery becomes weak.</li> </ul>	Replacing the Remote Battery P. 625
<b>₽</b> ₽+©	<ul> <li>Appears after you set the power mode to ACCESSORY or ON.</li> <li>Canadian models</li> <li>Appears after you unlock and open the driver's door.</li> </ul>	Starting the Engine P. 443
To Start Engine: Brake + Puth	<ul> <li>Appears when the engine does not restart automatically due to the following reasons:</li> <li>The hood is open.</li> <li>There is a problem in the system that disables Auto Idle Stop.</li> </ul>	<ul> <li>Follow the normal procedure to start the engine.</li> <li>Starting the Engine P. 443</li> </ul>

Message	Condition	Explanation
To Switch Vehicle OFF: Push Twice	• Appears after the driver's door is opened when the power mode is in ACCESSORY.	<ul> <li>Change the power mode to VEHICLE OFF.</li> <li>ENGINE START/STOP Button P. 193</li> </ul>
Accessory Mode	• Appears when the power mode is in ACCESSORY.	_
To Start, Hold Remote Near Start Button	<ul> <li>Appears if the keyless remote's battery is too weak to start the engine or the key is not within operating range to start the engine. The beeper sounds six times.</li> </ul>	<ul> <li>Bring the back of the keyless remote into contact with the ENGINE START/STOP button.</li> <li>If the Keyless Remote Battery is Weak P. 665</li> </ul>

Message	Condition	Explanation
Pressing Button Again 2v Or Holding Will Cause Ignition OFF G Power Loss	<ul> <li>Appears if you press the ENGINE START/STOP button while the vehicle is moving.</li> </ul>	Emergency Engine Stop P. 666
To Switch Vehicle OFF Push & Hold	• Appears after the driver's door is opened when the power mode is in ACCESSORY.	<ul> <li>Press and hold the ENGINE START/STOP button with your foot off the brake pedal to change the power mode to VEHICLE OFF.</li> </ul>
Idle Stop Enabled: (A) Switch Pressod. (2) Held for Status (3) Photh to Director	<ul> <li>Appears when you turn the Auto Idle Stop system on.</li> </ul>	D Auto Idle Stop P. 464
Hood Open	• Appears when the hood is opened.	• Close the hood.

Message	Condition	Explanation
To Shift: Apply Brake Pidal	<ul> <li>Appears when you try to change the transmission without depressing the brake pedal.</li> </ul>	• Depress the brake pedal, then change the transmission.
U.S. To Shift: Release Accelerator Pedal Canada To Shift: Release Accelerator Pedal	<ul> <li>Appears when you try to change the transmission without releasing your foot off the accelerator pedal.</li> </ul>	<ul> <li>Release your foot off the accelerator pedal, then change the transmission.</li> </ul>
Door is Open. Shift To Park.	<ul> <li>Appears when you try to change the shift position after the position has automatically been changed to</li> <li>P with the driver's door open and the driver's seat belt unfastened.</li> </ul>	• Press the P button if you leave the vehicle.

Message	Condition	Explanation
	• Appears when the <b>P</b> button is pressed while the vehicle is moving.	• Make sure that the vehicle comes to a stop before operating the select button.
To Shift: Vehicle Must Be Stopped	• Appears if you put the transmission into <b>R</b> while the vehicle is moving forward, or into <b>D</b> while the vehicle is reversing.	
Transmission System Problem, Park Not Available, See Your Dealer.	• Appears when you set the power mode to OFF while driving.	• Immediately stop in a safe place, set the parking brake, then restart the engine. If the message disappears, continue driving.
Shift To Park	• Appears when the vehicle is stopped with the driver's seat belt unfastened and there is a chance that the vehicle may roll unintentionally.	<ul> <li>Press the P button before release the brake pedal when idling, parking or exiting the vehicle.</li> <li>Shift Operation P. 453</li> </ul>
To Shift From Park: Engine Must Be Running	<ul> <li>Appears when you attempt to change to another gear position with the transmission in P and the engine OFF.</li> </ul>	<ul> <li>To select another gear position while in P, the engine must be ON.</li> </ul>

Message	Condition	Explanation
Shifting To Park: Apply Brake Pedal	<ul> <li>Appears when you press the P button but it is not engaged due to low ATF temperature.</li> </ul>	• Depress the brake pedal until this message disappear.
Transmission Temperature Near Limit. Avoid Heavy Acceleration And High Speed.	<ul><li>Appears when the temperature of the transmission is starting to get too hot.</li><li>The performance of the vehicle may be reduced.</li></ul>	• Until the message disappears, reduce your speed and allow the system to cool down.
Geer Unavailable.	<ul> <li>Appears when you repeatedly change the shift position between P and other positions in short period.</li> </ul>	• Take some time before changing the shift position.
Try Again After Awhile.	• Appears when you try to take the transmission out of P immediately after you start engine.	• Try to take the transmission out of <b>P</b> again.
Gear Position is N Release Accelerator Pedal.	<ul> <li>Appears when you depress the accelerator pedal when the transmission is in N.</li> </ul>	• Remove your foot off the accelerator pedal. When driving, depress the brake pedal and operate the shift position.

Message	Condition	Explanation
N> P Neutial Hold Mode On. Shift To Park When Done.	<ul> <li>Appears when you press and hold N button for more than two seconds.</li> </ul>	<ul> <li>Disappears when you set the shift position to other than N.</li> <li>If you want to keep the transmission in N position [car wash mode] P. 455</li> </ul>
To Exit Vehicle In Neutral Press N Again & Hold For 2sec	<ul> <li>Appears for a few seconds if you have not pressed the N button long enough to initiate Neutral-Hold mode.</li> </ul>	If you want to keep the transmission in N position [car wash mode] P. 455
Neutral Hold Mode Not Available Transmission Temperature Too Hol Allow Transmission To Cool	<ul> <li>Appears when neutral hold mode is not available due to the transmission being too hot.</li> </ul>	<ul> <li>When the transmission is too hot, neutral hold mode may not be available. Let the engine idle until the transmission has cooled down.</li> <li>▶ If you want to keep the transmission in N position [car wash mode] P. 455</li> </ul>
Auto High-Beam Problem, Manual Controls Available See Your Dealer.	<ul> <li>Appears if there is a problem with the auto high- beam.</li> </ul>	<ul> <li>Manually operate the headlight switch.</li> <li>If you are driving with the high-beam headlights when this happens, the headlights are changed to low beams.</li> </ul>

Message	Condition	Explanation
OFF	<ul> <li>Appears when ACC has been automatically canceled.</li> </ul>	<ul> <li>You can resume the set speed after the condition that caused ACC to cancel improves. Press the RES/+ button.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
BRAKE	• Flashes when the system senses a likely collision with a vehicle in front of you. The beeper sounds.	<ul> <li>Take appropriate action to prevent a collision (apply the brakes, change lanes, etc.)</li> <li>Collision Mitigation Braking System™ (CMBS™)         <ul> <li>P. 486</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul> </li> <li>Models with Low Speed Braking Control         <ul> <li>Low Speed Braking Control * P. 497</li> </ul> </li> </ul>
Models with Low Speed Braking Control	• Appears when the low speed braking control system is activated.	_

Message	Condition	Explanation
Cruise Cancelled: Speed Too High	• Appears when ACC is canceled due to excessive high vehicle speed.	<ul> <li>Reduce the speed, then reset ACC.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
Cruise Cancelled: Speed Too Low	• Appears when cruise control is canceled due to excessive low vehicle speed.	<ul> <li>Raise the speed, then reset cruise control.</li> <li>To Switch ACC with Low Speed Follow to Cruise Control P. 518</li> </ul>
Cannot Set Cruise: Speed Too High	• Appears when the speed of the vehicle is too high for you to set ACC.	<ul> <li>Reduce the speed, then set ACC.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
Cannot Set Cirulse: Speed Too Low	• Appears when the speed of the vehicle is too low for you to set cruise control.	<ul> <li>Raise the speed, then set cruise control.</li> <li>To Switch ACC with Low Speed Follow to Cruise Control P. 518</li> </ul>

Message	Condition	Explanation
Cruise Cancelled: Too Close To Vehicle Ahead	<ul> <li>Appears when the distance between your vehicle and the vehicle ahead of you is too close while ACC is in operation.</li> </ul>	<ul> <li>ACC has been automatically canceled.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
Cannot Set Cruise: Too Close To Vehicle Ahead	<ul> <li>Appears when pressing the RES/+ or SET/– button while the distance between your vehicle and the vehicle ahead of you is too close.</li> </ul>	<ul> <li>ACC cannot be set.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
BRAKE Cruitse Cancelled: Parking Brake is Applied	<ul> <li>Appears when the parking brake is applied automatically while ACC is in operation.</li> </ul>	<ul> <li>ACC has been automatically canceled.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> <li>Parking Brake P. 545</li> </ul>
BRAKE Cannot Set Cruise: Parking Brake Is Applied	<ul> <li>Appears when pressing the RES/+ or SET/– button while the parking brake is applied.</li> </ul>	<ul> <li>ACC cannot be set.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> <li>Parking Brake P. 545</li> </ul>

Message	Condition	Explanation
Cruise Cancelled: Apply Brake Pedal	<ul> <li>Appears if ACC is canceled while your vehicle is automatically stopped by ACC.</li> </ul>	<ul> <li>Immediately depress the brake pedal.</li> </ul>
Cannot Set Cruise: Brake Pedal is Applied	<ul> <li>Appears when pressing the RES/+ or SET/– button while the vehicle is moving and the brake pedal is depressed.</li> </ul>	<ul> <li>ACC cannot be set.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
Cruise Cancelled: Loss Of Traction	<ul> <li>Appears if the VSA<sup>®</sup> or traction control function operates while ACC is in operation.</li> </ul>	<ul> <li>ACC has been automatically canceled.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>

Message	Condition	Explanation
Cannel Set Cruise: System Not Available	<ul> <li>Appears if ACC cannot be set due to repeated deceleration, driving on a long downward slope, or excess vehicle weight.</li> </ul>	<ul> <li>Wait awhile, then reset ACC.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
Cruise Will Cancel Soon	<ul> <li>Appears just before the ACC is automatically canceled due to repeated deceleration, driving on a long downward slope, or excess vehicle weight. (Will automatically open until the distance between your vehicle and the vehicle ahead is the maximum set in distance settings.)</li> <li>Appears when the ACC has been automatically canceled.</li> </ul>	Adaptive Cruise Control (ACC) with Low Speed Follow P. 502

Message	Condition	Explanation
Press Switch To Operate	<ul> <li>Appears when SET/–, RES/+, CANCEL, or interval button is pressed while ACC is off.</li> </ul>	<ul> <li>After pressing the R button, press the SET/-, RES/+, CANCEL, or interval button.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
Hold Switch To Operate ACC	• Appears when interval button is pressed while Cruise mode is selected.	<ul> <li>After selecting ACC, press the interval button.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
To Resume Chuise: Use "RES/4" Switch	• Appears when the vehicle ahead of you resumes driving, after your vehicle has been stopped automatically by ACC.	<ul> <li>Press the RES/+ or SET/- button or depress the accelerator pedal to resume.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>

Message	Condition	Explanation
Cruise Cancelled Fasten Seat Belt	<ul> <li>Appears when the driver's seat belt is unfastened while your vehicle is automatically stopped by ACC.</li> </ul>	<ul> <li>ACC has been automatically canceled.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
Cannet Set Cruise: Fasten Soat Belt	<ul> <li>Appears when pressing the RES/+ or SET/– button while the driver's seat belt is unfastened.</li> </ul>	<ul> <li>ACC cannot be set.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
DIS Cruise Cancelled Shift To Drive	<ul> <li>Appears when the transmission is put into any position other than D or S while ACC is in operation.</li> </ul>	<ul> <li>ACC has been automatically canceled.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
DIS Cannot Set Cruise: Shift To Drive	<ul> <li>Appears when pressing the <b>RES/+</b> or <b>SET/</b>– button while the transmission is in any position other than D or S.</li> </ul>	<ul> <li>ACC cannot be set.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>

Message	Condition	Explanation
Cruise Cancelled: Slope Too Steep Cruise Cancelled: Slope Too Steep	• Appears when the vehicle is stopped on a very steep slope while ACC is in operation.	<ul> <li>ACC has been automatically canceled.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>
Cannot Set Cruise: Slope Too Steep: Cannot Set Cruise: Slope Too Steep:	<ul> <li>Appears when pressing the RES/+ or SET/– button while the vehicle is stopped on a very steep slope.</li> </ul>	<ul> <li>ACC cannot be set.</li> <li>Adaptive Cruise Control (ACC) with Low Speed Follow P. 502</li> </ul>

Message	Condition	Explanation
Some Driver Assist System Cannot Operate: Radar Obstructed	<ul> <li>Appears if anything covers the radar sensor cover and prevents the sensor from detecting a vehicle in front.</li> <li>May appear when driving in bad weather (rain, snow, fog, etc.)</li> </ul>	<ul> <li>When the radar sensor gets dirty, stop your vehicle in a safe place, and wipe off dirt using a soft cloth. The message may take some time to go off.</li> <li>Have your vehicle checked by a dealer if the message does not disappear even after you clean the sensor cover.</li> <li> ■ Radar Sensor P. 543 ■ AcuraWatch<sup>™</sup> P. 483 </li> </ul>
Some Driver Assist Systems Cannot Operate: Camera Temperature Too High	<ul> <li>Appears if the temperature inside the front sensor camera is too high and some driver assist systems cannot be activated.</li> </ul>	<ul> <li>Use the climate control system to cool down the camera.</li> <li>Disappears - The camera has been cooled down and the systems are activated normally.</li> <li>➡ Front Sensor Camera P. 541</li> <li>➡ AcuraWatch™ P. 483</li> </ul>
Some Driver Assist Systems Cannet Operate: Clean Front Windshield	<ul> <li>Appears if the area around the front sensor camera is blocked by dirt, mud, etc. and be prevented from detecting a vehicle in front.</li> <li>May appear when driving in bad weather (rain, snow, fog, etc.)</li> </ul>	<ul> <li>When the front window gets dirty, stop your vehicle in a safe place, and wipe it off with a soft cloth.</li> <li>Have your vehicle checked by a dealer if the message does not disappear even after you cleaned the area around the camera.</li> <li>▶ Front Sensor Camera P. 541</li> <li>▶ AcuraWatch™ P. 483</li> </ul>

Message	Condition	Explanation
Lane Keeping Assist Cannot Operate	• Appears when the LKAS is in operation, or the LKAS button is pressed, but there is a problem with a system related to the LKAS. The LKAS cancels automatically. The beeper sounds simultaneously.	<ul> <li>If any other system indicators come on, such as the VSA<sup>®</sup>, ABS and brake system, take appropriate action.</li> <li>Indicators P. 80</li> </ul>

Message	Condition	Explanation
Steering Required	<ul> <li>Blinks when you fail to steer the vehicle. The beeper sounds simultaneously.</li> </ul>	• Operate the steering wheel to resume the LKAS.
	<ul><li>Lane Keeping Assist System (LKAS)</li><li>Appears when the vehicle is driving out of a detected lane. The steering wheel vibrates rapidly.</li></ul>	<ul> <li>Keep the vehicle within the lane you are driving.</li> <li>Lane Keeping Assist System (LKAS) P. 522</li> </ul>
Lane Departure	<ul> <li>Road Departure Mitigation System</li> <li>Appears when the vehicle is driving out of a detected lane.</li> <li>When you selected Warning Only</li> <li>The steering wheel vibrates rapidly when the vehicle is drifting out of a detected lane.</li> <li>When you selected Normal, Wide or Narrow</li> <li>The steering wheel vibrates rapidly when the vehicle is drifting out of a detected lane. The system also steers the vehicle to help you remain within your driving lane.</li> </ul>	<ul> <li>Keep the vehicle within the lane you are driving.</li> <li>▶ Road Departure Mitigation System P. 530</li> <li>You can change the setting for the road departure mitigation system. Normal, Wide, Warning Only and Narrow can be selected.</li> <li>▶ Customized Features P. 359</li> </ul>

Message	Condition	Explanation
Road Departure Mitigation Activated	<ul> <li>Road Departure Mitigation System</li> <li>When you selected Narrow</li> <li>Appears when the vehicle is likely to drive out of a detected lane. The Road Departure Mitigation system also steers the vehicle to help you remain within your driving lane.</li> </ul>	

Message	Condition	Explanation
Fuel Pump System Problem	<ul> <li>Appears if there is a problem with the fuel pump system.</li> </ul>	• Set the power mode to OFF for a while, then set the power mode to ON. The message disappears if there is no problem. If the message appears again, take your vehicle to a dealer.
Engine Management System Problem	<ul> <li>Appears if there is a problem with the engine management system.</li> </ul>	• Set the power mode to OFF for a while, then set the power mode to ON. The message disappears if there is no problem. If the message appears again, take your vehicle to a dealer.
Ignition System Problem	<ul> <li>Appears if there is a problem with the ignition system.</li> </ul>	• Set the power mode to OFF for a while, then set the power mode to ON. The message disappears if there is no problem. If the message appears again, take your vehicle to a dealer.
Heated Seat System Problem	• Appears if there is a problem with the seat heaters.	• Turn off the seat heaters until the message disappears. If the message appears again, take your vehicle to a dealer.

Message	Condition	Explanation
AC System Problem	• Appears if there is a problem with the climate control system.	<ul> <li>Turn off the climate control system until the message disappears. If the message appears again, take your vehicle to a dealer.</li> </ul>
Models with remote er	ngine start	
Message	Condition	Explanation
To Start Driving: Brake + Push	<ul> <li>Appears when you unlock and open the driver's door while the engine is running by remote engine start.</li> </ul>	Remote Engine Start* P. 445

### Models with head-up display

Message	Condition	Explanation
Adaptive Damper System Problem See Your Dealer.	<ul> <li>Appears if there is a problem with the adaptive damper system.</li> </ul>	• Have your vehicle checked by a dealer. Your vehicle will have normal damping ability without the adaptive damper feature.

Models with parking sensor system		
Message	Condition	Explanation
Parking Sensor System Problem	<ul> <li>Appears if there is a problem with the parking sensor system.</li> </ul>	• Check if the area around the sensor(s) is covered with mud, ice, snow, etc. If the indicator(s) stays on even after you clean the area, have the system checked by a dealer.

# Gauges and Displays

# Gauges

Gauges include the speedometer, fuel gauge, and other related indicators. They are displayed when the power mode is in ON.

## Speedometer

Displays your driving speed in mph (U.S.) or km/h (Canada).

## Tachometer

Shows the number of engine revolutions per minute.

# Fuel Gauge

Displays the amount of fuel left in the fuel tank.

# Temperature Gauge

Displays the temperature of the engine coolant.

#### ■Fuel Gauge

#### NOTICE

You should refuel when the reading approaches  $\boxed{E}$ . Running out of fuel can cause the engine to misfire, damaging the catalytic converter.

The actual amount of remaining fuel may differ from the fuel gauge reading.

#### ➢Temperature Gauge

### NOTICE


Driving with the temperature gauge reading in the upper zone can cause serious engine damage. Pull safely to the side of the road and allow engine temperature to return to normal.

Dverheating P. 669

# **Multi-Information Display**

The multi-information display shows the odometer, trip meter, outside temperature indicator, and other gauges.

It also displays important messages such as warnings and other helpful information.



# Odometer

Shows the total number of miles or kilometers that your vehicle has accumulated.

# Outside Temperature

Shows the outside temperature in Fahrenheit (U.S.) or Celsius (Canada).

# ■ Adjusting the outside temperature display

Adjust the temperature reading by up to  $\pm 5^{\circ}$ F or  $\pm 3^{\circ}$ C if the temperature reading seems incorrect.

### Outside Temperature

The temperature sensor is in the front bumper. Road heat and exhaust from another vehicle can affect the temperature reading when your vehicle speed is less than 19 mph (30 km/h).

It may take several minutes for the display to be updated after the temperature reading has stabilized.

You can adjust the temperature reading.

# Compass\*


Shows the current traveling direction of the vehicle.

# Dynamic Mode

Shows the current dynamic mode.

Acura Integrated Dynamics System P. 459

# Speed Limit Information



Shows the current speed limit based on either information compiled through the navigation system<sup>\*</sup> or speed limit signs captured by the front sensor camera.

#### Speed Limit Information

The speed limit displayed on the screen may differ to the actual speed limit.

The speed limit for some roads is not displayed.

#### Models with navigation system

You can select whether the source of the speed limit information is the front sensor camera or the navigation system.

You can also turn off speed limit information.

**Customized Features** P. 359

#### Models without navigation system

You can turn on or off the speed limit information. Customized Features P. 359

# Current Mode for ACC with Low Speed Follow and LKAS


Shows the current mode for ACC with Low Speed Follow and LKAS. To Switch ACC with Low Speed Follow to Cruise Control P. 518 Lane Keeping Assist System (LKAS) P. 522

# Switching the Display

Roll the right selector wheel to view different types of content.


#### Switching the Display

If a warning initially appears, you can - after reading it - press the right selector wheel to proceed immediately to the content or to any other warning(s).



# Trip Computer

Move the right selector wheel to the right or left to switch between trip computer A and trip computer B.



### Trip meter

Shows the total number of miles or kilometers driven since the last reset. Meters A and B can be used to measure two separate trips.

### **Resetting a trip meter**

To reset the trip meter, display it, press and hold the right selector wheel.

The trip meter is reset to **0.0**.

### Average fuel economy

Shows the estimated average fuel economy of each trip meter in mpg or I/100 km. The display is updated at set intervals. When a trip meter is reset, the average fuel economy is also reset.

### Instant fuel economy

Shows the instant fuel economy as a bar graph in mpg or I/100 km.

### Range

Shows the estimated distance you can travel on the remaining fuel. This estimated distance is based on the vehicle's current fuel economy.

# Navigation

#### Compass Shows the compass screen.

### Turn-by-Turn Directions

When driving guidance is provided by the navigation system or Android Auto, turnby-turn directions to your destination appear.

### Refer to the Navigation System Manual

Android Auto™ P. 327

#### ➢Average fuel economy

You can change when to reset the average fuel economy.

### Customized Features P. 359

### ≫Range

The driving range displayed is only an estimate and may differ to the actual distance the vehicle can travel.

#### ▶Navigation

You can cancel the driving guidance by pressing and holding the right selector wheel.

A confirmation screen appears when Apple CarPlay navigation route is active.

You can select whether to have the turn-by-turn display come on or not during the route guidance.

- Customized Features P. 359
- To Change Head-Up Display Content P. 150

Turn-by-turn directions may not be available for all apps.

## Warning

Indicators P. 80

Multi-Information Display Warning and Information Messages P. 107

### Maintenance

Shows the remaining oil life and Maintenance Minder<sup>™</sup>.

**≥ Maintenance Minder™** P. 585

### Tire Pressure Monitor

Shows each tire's pressure.

Tire Pressure Monitoring System (TPMS) with Tire Fill Assist P. 475

# Speed/Distance Units



Enables you to show another unit on the multi-information display, head-up display\* and audio/information screen and set the displayed measurements to read in either miles and mph or km and km/h.

Press the right selector wheel when you select the **Speed/Distance Units** on the multiinformation display. Roll the right selector wheel to select the unit and press it. After this, a confirmation screen will appear for a few seconds.

#### ≫Warning

If there are multiple warnings, you can move the right selector wheel to the right or left to see other warnings.

#### Tire Pressure Monitor

The following colors indicate the state of tire pressure:

- Green: Within tire pressure regulation.
- Amber: Above or Below tire pressure regulation.
- Gray: There is a problem with the system.

# Sport Gauge Settings



Press the right selector wheel when you select the **Sport Gauge Settings** on the multiinformation display. Roll the right selector wheel to select the setting and press it.


## Turbo Meter

When the turbo is producing boost, this meter indicates boost pressure is building.



# G-meter

A red circle moves around to indicate where your vehicle is currently receiving a lateral force while driving.



#### ≫G-meter

The meter does not display a lateral force larger than 1.2 G.

If there is a problem with the VSA® system, the G-meter will not track the lateral force acting on the vehicle.

# Seat Belts

Occurs, under specified conditions, when seat belts are latched or unlatched. Seat Belt Reminder P. 39

# SH-AWD<sup>®</sup> Torque Distribution Monitor\*



The indicators on the display show the amount of torque being transferred to the right front, left front, right rear, and left rear wheels.

Super Handling-All Wheel Drive™ (SH-AWD®)\* P. 474

# Safety Support

Indicates the status of the Road Departure Mitigation system, CMBS<sup>™</sup>, Low Speed Braking Control<sup>\*</sup> and blind spot information system, such as On, Off, or Failure, by color and letters.

The following colors indicate the status of any of the above-mentioned systems:

- Green: The system is on.
- Gray: The system is off.
- Amber: There is a problem with the system.

#### ≫Safety Support

If a system is indicated by the color amber, have your vehicle checked by a dealer immediately.

To turn on or off each system, first press and roll the right selector wheel to select the desired item, and then press the right selector wheel.

Road Departure Mitigation On and Off P. 532

- CMBS<sup>™</sup> On and Off P. 490
- System On and Off P. 499
- Blind Spot Information System On and Off P. 481


You can also confirm the status of each function by the color of the safety support indicator.

- Safety Support Indicator (Amber) P. 103
- Safety Support Indicator (Green/Gray) P. 106

Models with Low Speed Braking Control

Even when the Low Speed Braking Control icon is green, if the parking sensor is turned off for the rear only, the brake assist will not operate when reversing.

Turning off All Rear Sensors P. 560



# Head-Up Display\*


Shows the currently selected Driving View information, navigation, audio and phone information, etc. You can choose which items are displayed using the left selector wheel on the steering wheel. They are displayed when the power mode is in ON.

Display Content P. 150

The display can be moved up and down to become level with your eyes. **To raise or lower the head-up display**: Press and hold the  $\blacktriangle$  or  $\blacktriangledown$  button until the desired position is reached.

#### ➢Head-Up Display \*

When you unlock and open the driver's door with a remote transmitter or keyless access system, the head-up display adjusts automatically to one of the two preset positions.






The display also shows the following warnings.

- Lane Departure Warning: When your vehicle is too close to the traffic lane lines, the lane departure warning appears.
  - Lane Keeping Assist System (LKAS) P. 522
- Head-Up Warning Lights: Flash when the **BRAKE** message appears on the multi-information display.
  - Collision Mitigation Braking System™ (CMBS™) P. 486
  - Low Speed Braking Control\* P. 497
  - Adaptive Cruise Control (ACC) with Low Speed Follow P. 502

# To Change Head-Up Display Content



Press the **APPS** button and roll the left selector wheel to select **Select Driving View** and press the left selector wheel. Each time you move the left selector wheel to the right or left, the head-up display content will change.



# Vehicle Speed

Shows your driving speed in mph or km/h.

# Current Mode for ACC with Low Speed Follow and the LKAS

Shows the current mode for ACC with Low Speed Follow and the LKAS.

Adaptive Cruise Control (ACC) with Low Speed Follow P. 502

Lane Keeping Assist System (LKAS) P. 522

# Turn-by-Turn Directions

Shows you turn-by-turn driving directions to your destination linked with the navigation system or Android Auto.

Refer to the Navigation System Manual
Android Auto™ P 327

# Speed Limit Information

Shows the current speed limit based on either information compiled through the navigation system or speed limit signs captured by the front sensor camera.

#### ➢Vehicle Speed

Switch between mph and km/h by using the multiinformation display or customized features on the audio/information screen.

Speed/Distance Units P. 142
 Customized Features P. 359

#### ➢Turn-by-Turn Directions

Turn-by-turn directions may not be available for all apps.

#### Speed Limit Information

The speed limit displayed on the screen may differ to the actual speed limit.

The speed limit for some roads is not displayed.

You can select whether the source of the speed limit information is the front sensor camera or the navigation system.

You can also turn off speed limit information.

Customized Features P. 359

This page intentionally left blank.

# Controls

This chapter explains how to operate the various controls necessary for driving.

<b>Clock</b>
Locking and Unlocking the Doors
Key
Low Keyless Remote Signal Strength 159
Locking/Unlocking the Doors from the
Outside 160
Locking/Unlocking the Doors from the
Inside 169
Childproof Door Locks 171
Auto Door Locking/Unlocking 172
Tailgate
Security System
Immobilizer System 183

5
)
3
5
7
)
)
ļ

Rear Defogger/Heated Door Mirror
Button
Heated Windshield Button* 207
Driving Position Memory System 210
Adjusting the Steering Wheel 212
Mirrors
Interior Rearview Mirror 213
Power Door Mirrors 214
Seats
Interior Convenience Items
Climate Control System
Using Automatic Climate Control 247
Automatic Climate Control Sensors 252

# **Adjusting the Clock**

You can adjust the time manually in the audio/information screen with the power mode in ON.

# Adjusting the Time

You can adjust the time using the A-zone touchpad.

- True Touchpad Interface P. 261
- 1. Press the 🟦 (home) button.
- 2. Select Settings.
- 3. Select System.
- 4. Select Date & Time.
- 5. Select Set Date & Time.
- 6. Select Automatic Date & Time.
- 7. Select Off.



# To adjust time:

# 8. Select Set Time.

- **9.** Select +/-.
  - When you customize the clock display to 24 hour clock, AM/PM icon is not
    - displayed.

# Customized Features P. 359

**10.** Press the (back) button to set the time.

#### ≫Clock

The clock is automatically updated through the audio system.

#### Adjusting the Time

You can also adjust the clock by selecting the clock displayed on the right side of the display.

- 1. Press the 🔲 (cards list) button.
- 2. Select **Clock** using the B-zone touchpad.
- 3. Press the B-zone touchpad.
- 4. Select **Set Date & Time** using the A-zone touchpad.
- 5. Select Automatic Date & Time.
- 6. Select Off.
- 7. Select Set Date or Set Time.
- Select +/- to adjust the dates, hours and minutes.
- 9. Press the (back) button to set the date or time.



### To adjust date: 8. Select Set Date.

**9.** Select +/-.

10. Press the 🚺 (back) button to set the

date.

# ➢Adjusting the Time

You can customize the clock display to show the 12 hour clock or 24 hour clock.

**Customized Features** P. 359

# Key

This vehicle comes with the following keys:



Use the keys to start and stop the engine, lock and unlock all the doors and the fuel fill door, and open the tailgate.

#### ≫Key

All the keys have an immobilizer system. The immobilizer system helps to protect against vehicle theft.

### Immobilizer System P. 183

Follow the advice below to prevent damage to the keys:

- Do not leave the keys in direct sunlight, or in locations with high temperature or high humidity.
- Do not drop the keys or set heavy objects on them.
- Keep the keys away from liquids, dust and sand.
- Do not take the keys apart except for replacing the battery.

If the circuits in the keys are damaged, the engine may not start, and the remote transmitter may not work.


If the keys do not work properly, have them inspected by a dealer.

#### Models with two-way keyless remote

You can remotely start the engine using the remote engine start.

Remote Engine Start\* P. 445


# Built-in Key



The built-in key can be used to lock/unlock the doors when the keyless remote battery becomes weak and the power door lock/ unlock operation is disabled.

To remove the built-in key, pull out the key while pressing the release button. To reinstall the built-in key, push the built-in key into the keyless remote until it clicks.

# Key Number Tag



Contains a number that you will need if you purchase a replacement key.

#### ≫Key Number Tag

Keep the key number tag separate from the key in a safe place outside of your vehicle.

If you wish to purchase an additional key, contact a dealer.

If you lose your key and you cannot start the engine, contact a dealer.

# Low Keyless Remote Signal Strength

The vehicle transmits radio waves to locate the keyless remote to start engine, lock and unlock all the doors, tailgate and fuel fill door.

In the following cases, starting the engine, locking/unlocking all the doors, tailgate and fuel fill door may be inhibited or operation may be unstable:


- Strong radio waves are being transmitted by nearby equipment.
- You are carrying the keyless remote together with telecommunications equipment, laptop computers, cell phones, or wireless devices.
- A metallic object is touching or covering the keyless remote.

➢Low Keyless Remote Signal Strength

Communication between the keyless remote and the vehicle consumes the keyless remote's battery. Battery life is about two years, but this varies depending on regularity of use. The battery is consumed whenever the keyless remote is receiving strong radio waves. Avoid placing it near electrical appliances such as televisions and personal computers.

# Locking/Unlocking the Doors from the Outside

# Using the Keyless Access System



When you carry the keyless remote, you can lock/unlock the doors and fuel fill door, and open the tailgate.

You can lock/unlock the doors, fuel fill door, and tailgate within a radius of about 32 inches (80 cm) of the outside door handle or tailgate outer handle.

#### ≥Locking/Unlocking the Doors from the Outside

If the interior light switch is in the door activated position, the interior light comes on when you unlock the doors and tailgate.

No doors opened: The light fades out after 30 seconds.

Doors and tailgate relocked: The light goes off immediately.


Interior Lights P. 230


#### ≥Using the Keyless Access System


If you do not open a door or the tailgate within 30 seconds of unlocking the vehicle with the keyless access system, the doors and tailgate will automatically relock.

You can lock or unlock doors using the keyless access system only when the power mode is in VEHICLE OFF.

The keyless access system will not lock the vehicle when a door or the tailgate is open.







# Locking the doors and tailgate

Touch the door lock sensor on the front or rear<sup>\*</sup> door, or press the lock button on the tailgate.


Some exterior lights flash; the beeper sounds; all the doors, fuel fill door, and tailgate lock; and the security system sets.

#### ≥Using the Keyless Access System

- Do not leave the keyless remote in the vehicle when you get out. Carry it with you.
- Even if you are not carrying the keyless remote, you can lock/unlock the doors and tailgate while someone else with the remote is within range.
- The door may be unlocked if the door handle is covered with water in heavy rain or in a car wash if the keyless remote is within range.
- If you grip a door handle or touch a door lock sensor wearing gloves, the door sensor may be slow to respond or may not respond by unlocking or locking the doors.
- After locking the door, you have up to 2 seconds during which you can pull the door handle to confirm whether the door is locked. If you need to unlock the door immediately after locking it, wait at least 2 seconds before gripping the handle, otherwise the door will not unlock.
- The door might not open if you pull it immediately after gripping the door handle. Grip the handle again and confirm that the door is unlocked before pulling the handle.
- Even within the 32 inches (80 cm) radius, you may not be able to lock/unlock the doors and tailgate with the keyless remote if it is above or below the outside handle.
- The keyless remote may not operate if it is too close to the door, door glass and tailgate.

Lock Button





# Unlocking the doors and tailgate

Grab the driver's door handle:

- The driver's door and fuel fill door unlock.
- Some exterior lights flash twice and the beeper sounds twice.

Grab the front passenger's door or rear\* door handle:

- All doors, fuel fill door, and the tailgate unlock.
- Some exterior lights flash twice and the beeper sounds twice.

Press the tailgate outer handle:

- ► The tailgate unlocks.
- Some exterior lights flash twice and the beeper sounds.
- Dening/Closing the Tailgate P. 182

#### ■Using the Keyless Access System

The light flash, beep and door unlock mode settings can be customized using the audio/information screen.

## Customized Features P. 359

#### Models with puddle lights


When you go into the keyless access system working range with all the doors locked, the puddle lights come on for 30 seconds.


The lights do not come on if you have previously stayed within the range for more than two minutes, or the doors have been locked for a few days. The feature activates again after you open and close any door, then lock the doors.

#### All models

You can also unlock and open with the power tailgate.

Using the Tailgate Outer Handle P. 178





# ■ Locking the doors and tailgate (Walk away auto lock<sup>®</sup>)

When you walk away from the vehicle with all doors and tailgate closed and while carrying the keyless remote, the doors will automatically lock.

The auto lock function activates when all doors and tailgate are closed, or all doors are closed and tailgate begins power close operation, and the keyless remote is within about 5 feet (1.5 m) radius of the outside door handle or tailgate outer handle. Exit vehicle while carrying keyless remote and close door(s).

- **1.** While within about 5 feet (1.5 m) radius of the vehicle.
  - The beeper sounds; the auto lock function will be activated.
- **2.** Carry the keyless remote beyond about 5 feet (1.5 m) from the vehicle and remain outside this range for 2 or more seconds.
  - Some exterior lights flash; the beeper sounds; all doors and tailgate will then lock.

#### Locking the doors and tailgate (Walk away auto lock®)

The auto lock function is set to OFF as the factory default setting. The auto lock function can be set to ON using the audio/information screen. If you set the auto lock function to ON using the audio/information screen, only the remote transmitter that was used to unlock the driver's door prior to the setting change can activate auto lock.

## Customized Features P. 359

After the auto lock function has been activated, when you stay within the locking/unlocking operation range, the indicator on the keyless remote will continue to flash until the doors are locked.

When you stay beside the vehicle within the operation range, the doors will automatically lock approximately 30 seconds after the auto lock function activating beeper sounds.

When you open a door after the auto lock function activating beeper sounds, the auto lock function will be canceled.

Under the following circumstances, the auto lock function will not activate:

- The keyless remote is inside the vehicle.
   The beeper will not sound.
- The keyless remote is taken out of its operational range before all the doors and tailgate are closed.
   The beeper will sound.

To temporarily deactivate the function:

- **1.** Set the power mode to OFF.
- 2. Open the driver's door.
- **3.** Using the master door lock switch, operate the lock as follows:

 $\mathsf{Lock} \mathop{\rightarrow} \mathsf{Unlock} \mathop{\rightarrow} \mathsf{Lock} \mathop{\rightarrow} \mathsf{Unlock}.$ 

The beeper sounds, and the function is deactivated.

To restore the function:

- Set the power mode to ON.
- Lock the vehicle without using the auto lock function.
- With the keyless remote on you, move out of the auto lock function operation range.
- Open any door.

#### Locking the doors and tailgate (Walk away auto lock®)

You must wait until the power tailgate fully closes before the auto lock function will be activated.

The auto lock function does not operate when any of the following conditions are met.

- The keyless remote is inside the vehicle.
- A door or the hood is not closed.
- The power mode is set to any mode other than OFF.
- The keyless remote is not located within a radius of about 5 feet (1.5 m) from the vehicle when you get out of the vehicle and close the doors.


#### Auto lock function operation stop beeper

After the auto lock function has been activated, the auto lock operation stop beeper sounds for approximately two seconds in the following cases.

- The keyless remote is put inside the vehicle through a window.
- You are located too close to the vehicle.

• The keyless remote is put inside the tailgate. If the warning beeper sounds, check that you are carrying the keyless remote. Then, open/close a door and confirm the auto lock activation beeper sounds once.

# Using the Remote Transmitter



\*1: Checking Door Lock Status\* P. 168

\* Not available on all models

## ■ Locking the doors and tailgate Press the lock button.

### Once:

Some exterior lights flash, all the doors, tailgate, and fuel fill door lock, and the security system sets.

# Twice (within five seconds after the first push):

The beeper sounds and verifies the security system is set.

# Unlocking the doors and tailgate

Press the unlock button.

# Once:

Some exterior lights flash twice, and the driver's door and fuel fill door unlock.

### Twice:

▶ The remaining doors and tailgate unlock.

#### ■Using the Remote Transmitter

If you do not open a door or the tailgate within 30 seconds of unlocking the vehicle with the remote transmitter, the doors and tailgate will automatically relock.

- You can change the relock timer setting.
  - Customized Features P. 359

You can lock or unlock doors using the remote transmitter only when the power mode is in VEHICLE OFF.

The remote transmitter uses low-power signals, so the operating range may vary depending on the surroundings.

The remote will not lock the vehicle when a door or the tailgate is open.

If the distance at which the remote transmitter works varies, the battery is probably low. If the LED does not come on when you press a

button, the battery is dead.

Replacing the Remote Battery P. 625

# Locking/Unlocking the Doors Using a Key


If the lock or unlock button of the keyless remote does not work, use the key instead.

Replacing the Remote Battery P. 625

Fully insert the key and turn it.



When you lock the driver's door with a key, all the other doors, tailgate and fuel fill door lock at the same time. When unlocking, the driver's door unlocks first. Turn the key a second time within a few seconds to unlock the remaining doors, fuel fill door and the tailgate.



# Locking a Door Without Using a Key

If you do not have the key on you, or if for some reason you cannot lock a door using the key, you can lock the door without it.



### Locking the front doors

Push the lock tab forward ① or push the master door lock switch in the lock direction②, and close the door.

### Locking the rear doors

Push the lock tab forward and close the door.


#### Locking a Door Without Using a Key

When you lock the driver's door, all the other doors, tailgate and fuel fill door lock at the same time. Before locking a door, make sure that the key is not inside the vehicle.

# Lockout prevention system

The doors and the tailgate cannot be locked when the keyless remote is inside the vehicle.

# Checking Door Lock Status\*



You can remotely check if your vehicle's doors are all locked or any are unlocked using the keyless remote from extended distances.

#### Checking Door Lock Status\*

Operate the remote in an open space. If there are buildings or other obstacles between your vehicle and the remote, the remote may not work even within the operable range. However, the range required for unlocking the tailgate and all the doors as well as activating the panic function is the same as that required for operating the standard keyless remote.

Using the Remote Transmitter P. 165

When checking the door lock status, you can also start or stop the engine.


Remote Engine Start\* P. 445

Press the lock button, the Amber (left) LED blinks once. After three seconds, one of the following feedback will come:

- Green (center) comes on: Acknowledges that the doors are locked.
- Red (right) comes on: Acknowledges that doors are not locked, or any door is not completely closed.
- Red (right) blinks three times: The remote does not receive the door lock status from the vehicle.

# Locking/Unlocking the Doors from the Inside

# Using the Lock Tab



**Locking a door** Push the lock tab forward.


Unlocking a door Pull the lock tab rearward.

#### ■ Using the Lock Tab

When you lock the door using the lock tab on the driver's door, all of the other doors, tailgate and fuel fill door lock at the same time.

When you unlock the door using the lock tab on the driver's door, only the driver's door will unlock.

# Unlocking Using the Front Door Inner Handle



Pull the front door inner handle.

The door unlocks and opens in one motion.

Unlocking and opening the driver's door from the inner handle unlocks all the other doors.

To avoid all the doors unlocking, use the lock tab on the driver's door to unlock, then lock again before opening the door.

This setting works for one time only. If you do not want all the doors to be unlocked all the time, customize the Auto Door Unlock setting to Off using the audio/information screen. ≥Unlocking Using the Front Door Inner Handle

The front door inner handles are designed to allow front seat occupants to open the door in one motion. However, this feature requires that front seat occupants never pull a front door inner handle while the vehicle is in motion.

Children should always ride in a rear seat where childproof door locks are provided.

# Using the Master Door Lock Switch



Press the master door lock switch in as shown to lock or unlock all the doors, tailgate and fuel fill door.


#### ≥Using the Master Door Lock Switch

When you lock/unlock either front door using the master door lock switch, all the other doors, tailgate and fuel fill door lock/unlock at the same time.

# **Childproof Door Locks**

The childproof door locks prevent the rear doors from being opened from the inside regardless of the position of the lock tab.

# Setting the Childproof Door Locks



Slide the lever in the rear door to the lock position, and close the door.

### When opening the door

Open the door using the outside door handle.

### Childproof Door Locks

To open the door from the inside when the childproof door lock is on, put the lock tab in the unlock position, lower the rear window, put your hand out of the window, and pull the outside door handle.

# Auto Door Locking/Unlocking

Your vehicle locks or unlocks all doors automatically when a certain condition is met.

# Auto Door Locking

# Drive lock mode

All doors and tailgate lock when the vehicle's speed reaches about 10 mph (15 km/h).

# Auto Door Unlocking

# Driver's door open mode

All doors and tailgate unlock when the driver's door is opened.

#### ➢Auto Door Locking/Unlocking

You can turn off or change to another auto door locking/unlocking setting using the audio/ information screen.

**Customized Features** P. 359

# Precautions for Opening/Closing the Tailgate

Always make sure individuals and objects are clear of the tailgate before opening or closing it.

Keep the tailgate closed while driving to:

- Avoid possible damage.
- ▶ Prevent exhaust gas from leaking into the vehicle.
- Carbon Monoxide Gas P. 77

Precautions for Opening/Closing the Tailgate

# 

Anyone caught in the path of a tailgate that is being opened or closed can be seriously injured.

Make sure that all people are clear of the tailgate before opening or closing it.

Be careful not to hit your head on the tailgate or to put your hands between the tailgate and the cargo area when closing the tailgate.

When you are storing or picking up luggage from the cargo area or by using a forward and back kicking motion under the center of the rear bumper for hands free access\*, while the engine is idling, do not stand in front of the exhaust pipe. You may get burned.

Do not allow any passenger in the cargo space. They may get hurt during hard braking, a sudden acceleration, or a crash. The power tailgate can be operated by pressing the power tailgate button on the remote transmitter, pressing the power tailgate button on the driver's door, pressing the outer handle on the tailgate, or by using a forward and back kicking motion under the center of the rear bumper for hands free access<sup>\*</sup>.

The power tailgate can be opened/closed when the transmission is in  $\mathbf{P}$ .

#### ≥Precautions for Opening/Closing the Tailgate

#### NOTICE

Do not push or pull on the power tailgate when it is being automatically opened or closed. Forcibly opening or closing the power tailgate while in operation can deform the tailgate frame.

When operating the power tailgate, make sure there is enough space around your vehicle. People near the tailgate may be seriously hurt if the tailgate hits or closes on their heads. Be especially cautious if children are around.

The power tailgate may not open or close under the following conditions:

- You start the engine while the tailgate is automatically opening or closing.
- The vehicle is parked on a steep hill.
- The vehicle is swayed in a strong wind.
- The tailgate or the roof is covered with snow or ice.

# **Opening/Closing the Power Tailgate**

# Using the Hands Free Access\*



Use a forward and back kicking motion for about 1 second under the center of the rear bumper to open or close the power tailgate while carrying the keyless remote.

Some exterior lights will flash and a beeper will sound, then the tailgate begins to move.

#### Opening/Closing the Power Tailgate

# 

Opening or closing a power tailgate while any part of a passenger is in the tailgate's operating path can cause serious injury.

Make sure all passengers or objects are clear of the tailgate operating range before opening or closing the tailgate.

#### Models with Hands Free Access

During rain or in other instances when the vehicle becomes wet, the sensor may not properly detect your foot motion.


When performing work on or around the rear section of the vehicle, you may inadvertently open or close the tailgate.

To prevent this from happening, select Customized Features on the audio/information screen and then select OFF for the feature.

Customized Features P. 359

If you hold your foot under the bumper for too long or sweep your foot from side to side, the power tailgate does not open or close.

This function will not operate if you don't have the keyless remote on you. Please make sure you have the keyless remote on you.



# Using the Remote Transmitter



Press the power tailgate button for more than one second to operate when the power mode is in VEHICLE OFF.

Some exterior lights flash and the beeper sounds.

If you press the button again while the power tailgate is moving, it will stop. Press the button for more than one second, and the power tailgate will reverse direction.

#### Dening/Closing the Power Tailgate

If you close the power tailgate when all the doors are locked, the power tailgate locks automatically.

If you replace the battery or the power tailgate fuse while the tailgate is open, the power tailgate may be disabled. The power tailgate resumes once you manually close the tailgate.

Installing aftermarket components other than Acura genuine accessories on the power tailgate may prevent it from fully opening or closing.

Make sure the power tailgate is fully open before you get your luggage in and out.

The beeper sounds when you start driving while the power tailgate is still open, or closing.


# Customizing when to open the tailgate

**Anytime:** The power tailgate unlocks and opens at the same time. This is the default setting.

When Unlocked: The tailgate opens when all doors are unlocked.

Customized Features P. 359

# Using the Power Tailgate Button



To open or close the power tailgate, press the power tailgate button for about one second.
▶ Some exterior lights flash and the beeper sounds.

If you press the button again while the power tailgate is moving, it will stop. Press the button for about one second, and the power tailgate will reverse direction.

#### ➢Opening/Closing the Power Tailgate


If the power tailgate meets resistance while opening or closing, the auto reverse feature reverses the direction. The beeper sounds three times.

The auto reverse function stops sensing when the tailgate is almost closed to make sure that it fully closes.

Do not touch the sensors located on both sides of the tailgate. The power tailgate does not close if you touch either sensor when you are trying to close the tailgate.

Be careful not to scratch the sensors with a sharp object. If scratched, they can be damaged, and the power tailgate closing feature malfunctions.

# Using the Tailgate Outer Handle



If you press the outer handle of the tailgate for no longer than one second, the tailgate opens automatically.

- ► The beeper sounds.
- ▶ If you want to open the tailgate
- manually, press the button for more than one second and wait until you hear beeps.

Depending/Closing the Tailgate P. 182

If you are carrying the keyless remote, you do not have to unlock the tailgate before opening it.

If you press the outer handle again while the power tailgate is moving, it will stop. Press the outer handle, and the power tailgate will reverse direction.

#### Dening/Closing the Power Tailgate

- Do not leave the keyless remote in the vehicle when you get out. Carry it with you.
- Even if you are not carrying the keyless remote, you can unlock the tailgate while someone else with the remote is within range.
- Do not leave the keyless remote inside the cargo area and close the tailgate. The beeper sounds and the tailgate cannot be closed.

You can change the power tailgate operation setting on and off.

Customized Features P. 359

### Using the Tailgate Inner Button



Press the button on the tailgate to close the power tailgate.

► The beeper sounds.

If you press the button again while the power tailgate is moving, it will stop. Press and release the button again, and the power tailgate will reverse direction.

### Programming Tailgate Position



The extent to which the power tailgate automatically opens can be programed.

### To program:

**1.** Open the tailgate to the desired position.

**2.** Press and hold the tailgate inner button. You will hear one long beep, followed by two short beeps.

#### Programming Tailgate Position

If the tailgate is only slightly opened, the position cannot be programmed, even if you push the inner button.

If you want to reprogram the power tailgate to open all the way, manually raise the tailgate to its upper most position and follow the directions step 2.



### Auto-Closer

If you manually close the power tailgate, it latches automatically.

### ➢Auto-Closer

The auto-closer feature does not activate if you press and hold the tailgate outer handle while the power tailgate is closing.

Do not put any force on the tailgate while the power tailgate is latching.

Keep your hands away from the tailgate when you manually close the tailgate and let it latch automatically. It is dangerous to put your hands around the tailgate as it starts to latch itself.

### ➢Power Tailgate Fall Detection

If you try to manually close the power tailgate immediately after it fully opens, the power tailgate fall detection may activate.


Once the power tailgate fall detection activates, wait until the power tailgate fully closes. Keep away from the power tailgate when it is in motion.

If the power tailgate fall detection constantly activates, consult at a dealer.

### **Power Tailgate Fall Detection**

Automatically lowers the power tailgate when there is a possibility that the fully opened power tailgate can fall down by its own weight (for example, by snow on the tailgate). The beeper sounds while the power tailgate lowers.

### **Opening/Closing the Tailgate**





When all the doors are unlocked, the tailgate is unlocked.

Press the outer handle of the tailgate and lift open the tailgate.

If you are carrying the keyless remote, you do not have to unlock the tailgate before opening it.

To close the tailgate, grab the inner handle, pull the tailgate down, and push it closed from outside.

If you close the tailgate when the driver's door is locked, the tailgate locks automatically. Some exterior lights flash.

### ➢Opening/Closing the Tailgate

- Do not leave the keyless remote in the vehicle when you get out. Carry it with you.
- Even if you are not carrying the keyless remote, you can unlock the tailgate while someone else with the remote is within range.
- Do not leave the keyless remote inside the cargo area and close the tailgate. The beeper sounds and the tailgate cannot be closed.

### **Immobilizer System**

This system prevents a key that has not been pre-registered from starting the engine.

Pay attention to the following when pressing the **ENGINE START/STOP** button:

- Do not allow objects that emit strong radio waves near the ENGINE START/ STOP button.
- Make sure the key is not covered by or touching a metal object.
- Do not bring a key from another vehicle's immobilizer system near the **ENGINE START/STOP** button.
- Do not put the key near magnetic items. Electronic devices, such as televisions and audio systems emit strong magnetic fields. Note that even a key chain can become magnetic.

### **Security System Alarm**

The security system alarm activates when the tailgate, hood or doors are forcibly opened. The alarm does not activate if the tailgate or doors are opened with the key, remote transmitter or keyless access system.

However, the alarm activates if a door is opened with the key and then the hood is opened before the power mode is set to ON.

### When the security system alarm activates

The horn sounds intermittently and some exterior lights flash.

### ■ To deactivate the security system alarm

Unlock the vehicle using the key, remote transmitter or keyless access system or set the power mode to ON. The system, along with the horn and flashing lights, is deactivated.

#### ➢Immobilizer System

vehicle unattended.

### NOTICE

Leaving the key in the vehicle can result in theft or accidental movement of the vehicle. Always take the key with you whenever you leave the

Do not alter the system or add other devices to it. Doing so may damage the system and make your vehicle inoperable.

*Canadian models only*: Apply and hold the brake pedal before turning the vehicle on the first time after the battery has been disconnected.

#### Security System Alarm

Do not alter the system or add other devices to it. Doing so may damage the system and make your vehicle inoperable.

The security system alarm continues for a maximum of two minutes until the security system alarm deactivates.

### Setting the security system alarm

The security system alarm automatically sets when the following conditions have been met:

- The power mode is set to VEHICLE OFF.
- The hood is closed.
- All doors and the tailgate are locked from outside with the key, remote transmitter, or keyless access system.

### When the security system alarm sets

The security system alarm indicator in the instrument panel blinks and the blinking interval changes after about 15 seconds.

### ■ To cancel the security system alarm

The security system alarm is canceled when the vehicle is unlocked using the remote transmitter, keyless access system, or the power mode is set to ON. The security system alarm indicator goes off at the same time.

#### Security System Alarm

Do not set the security system alarm when someone is in the vehicle or a window is open. The system can accidentally activate when:

- Unlocking the door with the lock tab.
- Opening the hood with the hood release.

If the battery goes dead after you have set the security system alarm, the security alarm may go off once the battery is recharged or replaced. If this occurs, deactivate the security system alarm by unlocking a door using the key, remote transmitter or keyless access system.

### Panic Mode



## The panic button on the remote transmitter

If you press the panic button for approximately one second, the following will occur for about 30 seconds:

- The horn sounds.
- Some exterior lights flash.

### Canceling panic mode

- Press any button on the remote transmitter.
- Set the power mode to ON.


### **Opening/Closing the Power Windows**

The power windows can be opened and closed when the power mode is in ON, using the switches on the doors.

The driver's side switches can be used to open and close all the windows. The power window lock button on the driver's side must be switched off (indicator off) to open and close the windows from anywhere other than the driver's seat.

When the power window lock button is pressed, the indicator comes on and you can only operate the driver's window. Turn the power window lock button on if a child is in the vehicle.

### Opening/Closing the Windows with Auto-Open/Close Function



### Manual operation

**To open:** Push the switch down lightly, and hold it until the desired position is reached. **To close:** Pull the switch up lightly, and hold it until the desired position is reached.

### Automatic operation

**To open:** Push the switch down firmly. **To close:** Pull the switch up firmly.

The window opens or closes completely. To stop the window at any time, push or pull the switch briefly.

Dpening/Closing the Power Windows

### 

Closing a power window on someone's hands or fingers can cause serious injury.

Make sure your passengers are away from the windows before closing them.

The power windows can be operated for up to 10 minutes after you set the power mode to VEHICLE OFF.

Opening either front door cancels this function.


### Auto Reverse

If a power window senses resistance when closing automatically, it will stop closing and reverse direction.

The driver's window auto reverse function is disabled when you continuously pull up the switch.

The auto reverse function stops sensing when the window is almost closed to ensure that it fully closes.

### Opening the Windows with the Remote



**To open:** Press the unlock button, and then within 10 seconds, press it again and hold it.

If the windows stop midway, repeat the procedure.

### Dening/Closing the Power Windows


While driving with any of the windows open, you may hear a booming, throbbing, or helicopter-type noise or pressure. This is called wind buffeting. This is a normal occurrence that can be minimized.

If you hear a wind buffeting noise with any of the windows open, lower all of the other windows slightly or open the panoramic roof.

### Opening the Windows with the Remote

If you open the windows with the remote, the panoramic roof will open automatically along with them.

### Opening/Closing the Windows with the Key



**To open:** Unlock the driver's door with the key. Within 10 seconds of returning the key to the central position, turn the key in the unlock direction and hold it there.

**To close:** Lock the driver's door with the key. Within 10 seconds of returning the key to the central position, turn the key in the lock direction and hold it there.

Release the key to stop the windows at the desired position. If you want further adjustment, repeat the same operation.

Dening/Closing the Windows with the Key

If you open/close the windows with the key, the panoramic roof will open/close automatically along with them.

### **Opening/Closing the Panoramic Roof**

You can operate the panoramic roof and sunshade when the power mode is in ON. Use the switch in the front of the ceiling to open and close the panoramic roof and sunshade.

≥Opening/Closing the Panoramic Roof

### 

Opening or closing the panoramic roof and sunshade on someone's hands or fingers can cause serious injury.

Make sure all hands and fingers are clear of the panoramic roof and sunshade before opening or closing it.

### NOTICE

Opening the panoramic roof in below freezing temperature or when it is covered with snow or ice can damage the panoramic roof panel or motor.

The panoramic roof and sunshade can be operated for up to 10 minutes after you set the power mode to VEHICLE OFF.

Opening either front door cancels this function.


When resistance is detected, the auto reverse function causes the panoramic roof and sunshade to change directions, then stop. Auto reverse stops sensing when the panoramic roof and sunshade are almost closed to ensure that it fully closes. Make sure that all objects, including fingers, are clear of the panoramic roof and sunshade.

### ≫Panoramic Roof

You can use the remote transmitter or the key to operate the panoramic roof.

- Depending the Windows with the Remote P. 187
- Opening/Closing the Windows with the Key P. 188

### Using the Panoramic Roof Switch



### Automatic operation

**To open:** Pull the switch back firmly. **To close:** Push the switch forward firmly.

The panoramic roof automatically opens or closes all the way. To stop the panoramic roof midway, pull or push the switch briefly.

### Manual operation

**To open:** Pull the switch back lightly, and hold it until the desired position is reached. **To close:** Push the switch forward lightly, and hold it until the desired position is reached.


### ■ Tilting the panoramic roof up

**To tilt:** Push on the center of the panoramic roof switch.

The sunshade will open automatically and the panoramic roof will start to tilt up.

**To close:** Push the switch forward firmly, then release.

#### ≥Using the Panoramic Roof Switch



The panoramic roof cannot be fully opened in a single operation. The panoramic roof has a "comfort" position or wind noise reduction position at which the roof first stops. To open fully, pull the switch back again after the roof has stopped at this position.

Whenever the panoramic roof is opening, the sunshade moves along with it. However, when the panoramic roof is closing, the sunshade does not move.

When you tilt open the panoramic roof, the sunshade opens slightly to let in fresh air. When you close the panoramic roof from this position, the sunshade returns to its closed position.

### Using the Sunshade Switch



### Automatic operation

**To open:** Pull the switch back firmly. **To open half:** Push on the center of the sunshade switch. **To close:** Push the switch forward firmly.

The sunshade automatically opens or closes all the way. To stop the sunshade midway, pull or push the switch briefly.

### Manual operation

**To open:** Pull the switch back lightly, and hold it until the desired position is reached. **To close:** Push the switch forward lightly, and hold it until the desired position is reached.

#### Sunshade Switch Sunshade Switch


The sunshade can be opened or closed to adjust the amount of light that enters the cabin.

When you use the sunshade switch to open the sunshade, the panoramic roof does not move.

The sunshade cannot be fully closed if the panoramic roof is open. When you close the sunshade with the panoramic roof opened, the sunshade stops slightly before the panoramic roof glass. When you push the switch forward again, the sunshade and the panoramic roof close together.

### **ENGINE START/STOP Button**

### Changing the Power Mode



### Without pressing the brake pedal



Press the button without the transmission in P.




Press the button.

Put the transmission into P.

### ENGINE START/STOP Button

### **ENGINE START/STOP** Button Operating Range



You can start the engine when the keyless remote is inside the vehicle

The engine may also run if the keyless remote is close to the door or window, even if it is outside the vehicle

### ON mode:

The **ENGINE START/STOP** button is on (in red), if the engine is running.

If the battery of the keyless remote is getting low, the engine may not start when you push the **ENGINE START/STOP** button. If the engine does not start, refer to the following link.

If the Keyless Remote Battery is Weak P. 665

Do not leave the power mode in ACCESSORY or ON when you get out.


### Automatic Power Off

If you leave the vehicle for 30 to 60 minutes with the transmission in [P] and the power mode in ACCESSORY, the vehicle automatically goes into the mode similar to VEHICLE OFF to avoid draining the battery.

### Power Mode Reminder

If you open the driver's door when the power mode is set to ACCESSORY, a warning beep sounds.

### Keyless Remote Reminder



When the power mode is set to any mode other than OFF and you remove the keyless remote from the vehicle and shut the door, an alarm will sound. If the alarm continues to sound, place the keyless remote in another location.

### ■ When the power mode is in ACCESSORY

The alarm will sound from outside the vehicle.

### When the power mode is in ON

An alarm will sound both inside and outside the vehicle. In addition, a warning indicator will appear on the instrument panel.

#### Keyless Remote Reminder


When the keyless remote is within the system's operational range, and the driver's door is closed, the warning function cancels.

If the keyless remote is taken out of the vehicle after the engine has been started, you can no longer change the **ENGINE START/STOP** button mode or restart the engine. Always make sure if the remote is in your vehicle when you operate the **ENGINE START/STOP** button.

Removing the keyless remote from the vehicle through a window does not activate the warning buzzer.

Do not put the keyless remote on the dashboard or in the glove box. It may cause the warning buzzer to go off. Under some other conditions that can prevent the vehicle from locating the remote, the warning buzzer may also go off even if the remote is within the system's operational range.

### **Turn Signals**



The turn signals can be used when the power mode is in ON.

### ■ (A): Turn signal

Push the lever up or down based on the direction you want to turn, and the turn signal will blink.

### ■ (B): One-touch turn signal


When you lightly push the lever up or down and release it, the turn signal will blink 3 times.

### ∭Turn Signals

The turn signal indicator on the instrument panel will blink when the external turn signal blinks.

### **Light Switches**

### Manual Operation



Rotating the light switch turns the lights on and off, regardless of the power mode setting.

### High beams

Push the lever forward until you hear a click.

### Low beams

When in high beams, pull the lever back to return to low beams.

### Flashing the high beams

Pull the lever back, and release it. **■ Lights off** 

Turn the lever to **OFF** either when:

- The transmission is in **P**.
- The parking brake is applied.

To turn the lights on again, turn the lever to **OFF** to cancel the lights off mode. Even if you do not cancel the lights off mode, the lights come on automatically when:

- The transmission is taken out of **P** and the parking brake is released.
- The vehicle starts to move.

### ➢Light Switches

If you leave the power mode in VEHICLE OFF while the lights are on, a chime sounds when the driver's door is opened.

When the lights are on, the lights on indicator in the instrument panel will be on.

### Lights On Indicator P. 98

Do not leave the lights on when the engine is off because it will cause the battery to discharge.

If you sense that the level of the headlights is abnormal, have the vehicle inspected by a dealer.

### Automatic Operation (automatic lighting control)



Automatic lighting control can be used when the power mode is in ON.

When the light switch is in **AUTO**, the headlights and other exterior lights will switch on and off automatically depending on the ambient brightness.


The headlights come on when you unlock a door in dark areas with the headlight switch in **AUTO**.

Once you lock the door, the headlights will go off.

#### Automatic Operation (automatic lighting control)

We recommend that you turn on the lights manually when driving at night, in a dense fog, or in dark areas such as long tunnels or parking facilities.

The light sensor is in the location shown below. Do not cover this light sensor with anything; otherwise, the automatic lighting system may not work properly.



### Headlight Integration with Wiper

The headlights automatically come on when the wipers are used several times within a certain number of intervals with the headlight switch in **AUTO**. The headlights automatically go off a few minutes later if the wipers are stopped.

### Automatic Lighting Off Feature

The headlights, all other exterior lights, and the instrument panel lights turn off 15 seconds after you set the power mode to VEHICLE OFF, take the remote with you, and close the driver's door.

If you set the power mode to VEHICLE OFF with the headlight switch on, but do not open the door, the lights turn off after 10 minutes (3 minutes, if the switch is in the **AUTO** position).

The lights turn on again when you unlock or open the driver's door. If you unlock the door, but do not open it within 15 seconds, the lights go off. If you open the driver's door, you will hear a reminder chime alerting you that the lights are on.

#### Mutomatic Operation (automatic lighting control)

### U.S. models

You can adjust the auto light sensitivity as follows:

Setting	The exterior lights come on when the ambient light is at	
Max	Bright	
High	Bright	
Mid		
Low		
Min	Dark	
Customized Features P. 359		

### ≥Headlight Integration with Wiper

This feature activates while the headlights are off in **AUTO**.

The instrument panel brightness does not change when the headlights come on.

At dark ambient light levels, the automatic lighting control feature turns on the headlights, regardless of the number of wiper sweeps.

### Mutomatic Lighting Off Feature

You can change the headlight auto off timer setting. Customized Features P. 359

### Fog Lights\*



When the low beam headlights are on, turn the fog light switch on to use the fog lights.



# Controls

### **Chicane™ Daytime Running Lights**

The parking/daytime running lights come on when the following conditions have been met:


- The power mode is in ON.
- The headlight switch is in **AUTO**.
- The parking brake is released.

The lights remain on even if you set the parking brake. Setting the power mode to VEHICLE OFF will turn off the daytime running lights.

The daytime running lights are off once the headlight switch is turned on, or when the headlight switch is in **AUTO** and it is getting darker outside.


### **Auto High-Beam**

The front sensor camera detects the light sources ahead of the vehicle such as the lights of a preceding or oncoming vehicle, or street lights. When you are driving at night, the system automatically switches the headlights between low beam and high beam depending on the situation.



### How to Use the Auto High-Beam

When all of the following conditions have been met, the auto high-beam indicator comes on and the auto high-beam is activated.



- The power mode is in ON.
- The light switch is in **AUTO**.
- The lever is in the low beam position.
- The headlights have been automatically activated.
- It is dark outside the vehicle.

### ≫Auto High-Beam

The auto high-beam system does not always operate in every situation. This system is just for assisting the driver. Always observe your surroundings and switch the headlights between high beam and low beam manually if necessary.

If you find the timing of beam changes inconvenient for driving, change the headlight beams manually.

The range and the distance at which the camera can recognize varies depending on conditions surrounding your vehicle.

Regarding the handling of the camera mounted to the inside of the windshield, refer to the following.

Front Sensor Camera P. 541

For the auto high-beam to work properly:

- Do not place an object that reflects light on the dashboard.
- Keep the windshield around the camera clean.
- When cleaning the windshield, be careful not to apply the windshield cleanser to the camera lens.
- Do not attach an object, sticker or film to the area around the camera.
- Do not touch the camera lens.

If the camera receives a strong impact, or repairing of the area near the camera is required, consult a dealer.

If the auto high-beam indicator does not come on even when all the conditions have been met, carry out the following procedure and the indicator will come on.

• Pull the lever toward you for flashing the high beams then release it while driving.

Controls

### Automatic switching between high-beam and low-beam

When auto high-beam is active, the headlights switch between high beam and low beam based on the following conditions.

### Switching to high beam:

• There are no preceding or

or taillights turned on.

All of the following conditions must be met before the high beams turn on.

• Your vehicle speed is 25 mph (40 km/h) or more.

oncoming vehicle with headlights

• There are few street lights on the



Switching to low beam:

One of the following conditions must be met before the low beams turn on.

- Your vehicle speed is 15 mph (24 km/h) or less.
- There is a preceding or oncoming vehicle with headlights or taillights turned on.
- There are many street lights on the road ahead.

### Manual switching between high-beam and low-beam

If you want to manually switch the headlights between high beam and low beam, follow either of the procedures below. Note that when you do this, the auto high-beam indicator will turn off and the auto high-beam will be deactivated.

### Using the lever:

road ahead.

Pull the lever toward you for flashing the high beams then release it within about one second while driving.

To reactivate the auto high-beam, pull the lever toward you for flashing the high beams then release it while driving. The auto high-beam indicator will come on.

### Using the light switch:

Turn the light switch to **≣○**.

► To reactivate the auto high-beam, turn the light switch to **AUTO** when the lever is in the low beam position, the auto high-beam indicator will come on.

#### ➢How to Use the Auto High-Beam

In the following cases, the auto high-beam system may not switch the headlights properly or the switching timing may be changed. In case of the automatic switching operation does not fit for your driving habits, please switch the headlights manually.


- The brightness of the lights from the preceding or oncoming vehicle is intense or poor.
- Visibility is poor due to the weather (rain, snow, fog, windshield frost, etc.).
- Surrounding light sources, such as street lights, electric billboards and traffic lights are illuminating the road ahead.
- The brightness level of the road ahead constantly changes.
- The road is bumpy or has many curves.
- A vehicle suddenly appears in front of you, or a vehicle in front of you is not in the preceding or oncoming direction.
- Your vehicle is tilted with a heavy load in the rear.
- A traffic sign, mirror, or other reflective object ahead is reflecting strong light toward the vehicle.
- The oncoming vehicle frequently disappears under roadside trees or behind median barriers.
- The preceding or oncoming vehicle is a motorcycle, bicycle, mobility scooter, or other small vehicle.

The auto high-beam system keeps the headlight low beam when:

- Windshield wipers are operating at a high speed.
- The camera has detected a dense fog.

### How to Turn Off the Auto High-Beam

You can turn the auto high-beam system off. If you want to turn the system off or on, set the power mode to ON, then carry out the following procedures while the vehicle is stationary.



### To turn the system off:

With the light switch is in **AUTO**, pull the lever toward you and hold it for at least 40 seconds. After the auto high-beam indicator light blinks twice, release the lever.

### To turn the system on:

With the light switch is in **AUTO**, pull the lever toward you and hold it for at least 30 seconds. After the auto high-beam indicator light blinks once, release the lever.

#### How to Use the Auto High-Beam

#### If the Some Driver Assist Systems Cannot Operate: Camera Temperature Too High message appears:

- Use the climate control system to cool down the interior and, if necessary, also use defroster mode with the airflow directed toward the camera.
- Start driving the vehicle to lower the windshield temperature, which cools down the area around the camera.

#### If the Some Driver Assist Systems Cannot Operate: Clean Front Windshield message appears:

• Park your vehicle in a safe place, and clean the windshield. If the message does not disappear after you have cleaned the windshield and driven for a while, have your vehicle checked by a dealer.


#### ➢How to Turn Off the Auto High-Beam

If you turn the auto high-beam system off, the system does not operate until you turn the system on.

Park in a safe place before turning the system off or on.

### **Wipers and Washers**

### Windshield Wipers/Washers



Intermittent Time Adjustment Ring\*

- 1 MIST
- 2 OFF
- B INT<sup>\*1</sup>/AUTO<sup>\*2</sup>
- 4 LO: Low speed wipe
- 5 HI: High speed wipe

The windshield wipers and washers can be used when the power mode is in ON.

### MIST

The wipers run at high speed until you release the lever.

### ■ Wiper switch (OFF, INT\*1/AUTO\*2, LO, HI)

Move the lever up or down to change the wiper settings.

### Adjusting wiper operation\*

Turn the adjustment ring to adjust the wiper operation.

Lower speed, fewer sweeps



Higher speed, more sweeps

### Washer

Sprays while you pull the lever toward you. When you release the lever for more than one second, the spray stops, the wipers sweep two or three more times to clear the windshield, then stop.

\*1: Models with manual intermittent operation

\*2: Models with automatic intermittent operation

#### Wipers and Washers

### NOTICE

Do not use the wipers when the windshield is dry. The windshield will get scratched, or the rubber blades will get damaged.

### NOTICE

Turn the washers off if no washer fluid comes out. The pump may get damaged.

The wiper motor may stop motor operation temporarily to prevent an overload. Wiper operation will return to normal within a few minutes.

#### Models without automatic intermittent wipers

If the vehicle speeds up while the wipers are operating intermittently, the length of the wipe interval shortens.


When the vehicle speeds up, the wiper operation's shortest delay setting ( $\square$ ) and the **LO** setting become the same.

### NOTICE

In cold weather, the blades may freeze to the windshield.

Operating the wipers in this condition may damage the wipers. Use the defogger or heated windshield\* to warm the windshield, then turn the wipers on.

### Automatic Intermittent Wipers\*



When you push the lever down to **AUTO**, the windshield wipers sweep once, and go into the automatic mode.

The wipers operate intermittently, at low speed, or at high speed and stop in accordance with the amount of rainfall the rainfall sensor detects.

### Auto sensitivity adjustment

When the wiper function is set to **AUTO**, you can adjust the sensitivity of the rainfall sensor (using the adjustment ring) so that wipers will operate in accordance with your preference.

### Sensor sensitivity

Low sensitivity

### High sensitivity

#### Wipers and Washers

If the wipers stop operating due to an obstacle such as the buildup of snow, park the vehicle in a safe place.

Rotate the wiper switch to **OFF**, and set the power mode to ACCESSORY or VEHICLE OFF, then remove the obstacle.

#### ➢Automatic Intermittent Wipers<sup>∗</sup>

The rainfall sensor is in the location shown below.




### NOTICE

**AUTO** should always be turned **OFF** before the following situations in order to prevent severe damage to the wiper system:

- Cleaning the windshield
- Driving through a car wash
- No rain present

### Rear Wiper/Washer



INT: Intermittent
 ON: Continuous wipe
 OFF
 Washer

The rear wiper and washer can be used when the power mode is in ON.

### ■ Wiper switch (OFF, INT, ON)

Change the wiper switch setting according to the amount of rain.

■ Washer (() () Sprays on the rear window and rearview camera<sup>\*</sup> while you rotate the switch to this position.

Hold it to activate the rear wiper and to spray the washer. Once released, the washer spray will stop and the rear wiper will return to its selected switch setting after a few sweeps.

### Operating in reverse

When you select the transmission to  $\mathbf{R}$  with the windshield wipers activated, the rear wiper operates automatically as follows even if its switch is off.

Windshield Wiper Operation	Rear Wiper Operation
Intermittent	Intermittent
Low speed wipe High speed wipe	Continuous

### **Rear Defogger/Heated Door Mirror Button**

Press the rear defogger and heated door mirror button to defog the rear window and mirrors when the power mode is in ON.



The rear defogger and heated door mirrors automatically switch off after 10-30 minutes depending on the outside temperature.

#### ➢Rear Defogger/Heated Door Mirror Button


This system consumes a lot of power, so turn it off when the window has been defogged.

Also, do not use the system for a long time while the engine is idling. This may weaken the battery, making it difficult to start the engine.

When the power mode is set to ON and the outside temperature is below  $41^{\circ}F$  (5°C), the heated door mirror may automatically activate for 10 minutes.

### Heated Windshield Button\*

Press the heated windshield button to deice the windshield at the wiper park area and along the driver side edge of the windshield when the power mode is in ON.



The heated windshield will automatically switch off after 15 minutes.


#### ➢Heated Windshield Button\*

This system consumes a lot of power, so turn it off when the window has been deiced. Also, do not use the system for a long period when the engine is idling. This may weaken the battery, making it difficult to start the engine.

When the power mode is set to ON and the outside temperature is below 39°F (4°C), the heated windshield may automatically activate for up to 15 minutes.

### **Brightness Control**

### Adjusting the Instrument Panel Brightness



When the power mode is in ON, you can use the + or - button to adjust instrument panel brightness. **Brighten:** Press the + button. **Dim:** Press the - button.

You will hear a beep when the brightness reaches minimum or maximum. Several seconds after adjusting the brightness, you will be returned to the previous screen.

### Brightness level indicator

The brightness level is shown on the display while you are adjusting it.

#### ➢Brightness Control


The brightness of the instrument panel will be reduced when the following conditions:

- The power mode is in ON.
- The light switch is in any position other than off and it is dark outside.

The brightness can be set differently for when the exterior lights are on, and when they are off.




### Adjusting the Head-Up Display Brightness\*



When the power mode is in ON, you can use the +/- button to adjust head-up display brightness. Brighten: Press the + button. Dim: Press the - button.

The head-up display will return to its original state several seconds after adjusting the brightness.



### Brightness level indicator

The brightness level is shown on the display while you are adjusting it.


### **Driving Position Memory System**

You can store two driver's seat and door mirror positions with the driving position memory system.

When you unlock and open the driver's door with a keyless remote or keyless access system, door mirrors adjust to one of the two preset positions and the seat adjusts to retracted positions of one of the two preset positions automatically.

The seat will move to the stored position when you set the power mode to ACCESSORY.

- **DRIVER 1** transmitter is linked to memory button 1.
- **DRIVER 2** transmitter is linked to memory button 2.



The driver's seat moves rearward depending on the set seating position once you

- Stop the vehicle.
- Put the transmission in **P**.
- Turn the engine off.
- Open the driver's door.

Once the power mode is in the ACCESSORY position, the driver's seat moves forward to the **DRIVER 1** or **2** preset position.

#### Driving Position Memory System

Using the audio/information screen, you can disable the automatic seat adjustment function.

### Customized Features P. 359

The driver's seat easy exit feature can be turned ON/  $\ensuremath{\mathsf{OFF}}$  .

Customized Features P. 359

### System Operation

The system will not operate if:

- Either memory button is pressed while the seat or mirrors are in motion.
- The seat or mirrors positions are adjusted while in operation.
- Either of the memorized positions is set fully to the rear.


### Models with mode selector

• The mode selector is pressed up or down while in operation.

The system may not recognize a key if:

- The key is in close proximity to a cell phone or other wireless device.
- Both keys are in the vehicle at the same time.
- The Driving Position Memory System is disabled in customized features.
- Opening driver's door without fully grabbing door handle.

### Storing a Position in Memory



- **1.** Set the power mode to ON. Adjust the driver's seat and the door mirrors to the desired position.
- 2. Press the SET button.
- The memory button indicator light will blink.
- **3.** Press and hold memory button 1 or 2 within five seconds of pressing the **SET** button.
  - Once the seat and the door mirror positions have been memorized, the indicator light on the button you pressed stays on and you will hear the doublebeep.

#### Storing a Position in Memory


After you press the **SET** button, the storing operation will be canceled when:

- You do not press the memory button within five seconds.
- You readjust the seat or the door mirror position before the double-beep.
- You set the power mode to any position except ON.

#### Models with mode selector

• You press the mode selector up or down.

### Recalling the Stored Position



- **1.** Put the transmission into **P**.
- 2. Apply the parking brake.
- 3. Press a memory button (1 or 2).
  ▶ The indicator light will blink.

The seat and the door mirrors will automatically move to the memorized positions. When they have finished moving, the indicator light stays on.

### ➢Recalling the Stored Position

The seat and the door mirrors will stop moving if you:


- Press the **SET** button or memory button 1 or 2.
- Adjust the seat position or door mirrors.
- Put the transmission into a position other than **P**.

#### Models with mode selector

• Press the mode selector up or down.

### **Adjusting the Steering Wheel**

The steering wheel height and distance from your body can be adjusted so that you can comfortably grip the steering wheel in an appropriate driving posture.



- **1.** While the vehicle is stopped, push the steering wheel adjustment lever down.
  - The steering wheel adjustment lever is under the steering column.
- **2.** Move the steering wheel up or down, and in or out.
  - Make sure you can see the instrument panel gauges and indicators.
- **3.** Pull the steering wheel adjustment lever up to lock the steering wheel in position.
  - After adjusting the position, make sure you have securely locked the steering wheel in place by trying to move it up, down, in, and out.

➢Adjusting the Steering Wheel

### 


Adjusting the steering wheel position while driving may cause you to lose control of the vehicle and be seriously injured in a crash.

Adjust the steering wheel only when the vehicle is stopped.

### **Interior Rearview Mirror**

Adjust the angle of the rearview mirror when you are sitting in the correct driving position.

# Automatic Dimming Power Door Mirrors<sup>\*</sup> and Rearview Mirror



When you are driving after dark, the automatic dimming rearview mirror and automatic dimming power door mirrors reduce the glare from headlights behind you, based on inputs from the mirror sensor. Press the auto button to turn this function on and off. When activated, the auto indicator comes on.

#### ≫Mirrors


Keep the inside and outside mirrors clean and adjusted for best visibility.

Adjust the mirrors before you start driving. Front Seats P. 216

Mutomatic Dimming Power Door Mirrors \* and Rearview Mirror

The auto dimming function cancels when the transmission is in  $\boxed{\mathbf{R}}$ .

### **Power Door Mirrors**



You can adjust the door mirrors when the power mode is in ON.

### Mirror position adjustment

**L/R selector switch:** Select the left or right mirror. After adjusting the mirror, return the switch to the center position.

**Mirror position adjustment switch:** Press the switch left, right, up, or down to move the mirror.

### Folding door mirrors\*

Press the folding button to fold in and out the door mirrors.

### Reverse Tilt Door Mirror



If activated, either side door mirror automatically tilts downward when you put the transmission into  $[\mathbf{R}]$ ; this improves close-in visibility on the selected side of the vehicle when backing up. The mirror automatically returns to its original position when you take the transmission out of  $[\mathbf{R}]$ .

To activate this feature, set the power mode to ON and slide the selector switch to the left or right side.

#### Automatic Folding Door Mirror Function\*

#### Folding in the door mirrors

Lock the driver's door with the key, press the lock button on the keyless remote, touch the door lock sensor on any door, or press the lock button on the tailgate outer handle.

► The mirrors start folding in automatically.

#### Folding out the door mirrors

Unlock the driver's door using the key, keyless remote or keyless access system.

► The mirrors start folding out automatically.

#### Automatic Folding Door Mirror Function\*

You cannot turn the automatic folding out automatically if they have been folded in using the folding button.


You can turn the automatic folding door mirror function on and off.

#### Customized Features P. 359

Door mirrors will not fold automatically when locking from inside the vehicle using lock tab or master door lock switch.

## Seats


## **Front Seats**



Adjust the driver's seat as far back as possible while allowing you to maintain full control of the vehicle. You should be able to sit upright, well back in the seat and be able to adequately press the pedals without leaning forward, and grip the steering wheel comfortably. The passenger's seat should be adjusted in a similar manner, so that it is as far back from the front airbag in the dashboard as possible.

## Adjusting the Seat Positions

#### Adjusting the front power seats



#### ≫Seats

Always make seat adjustments before driving.

#### ➢Front Seats

## 

Sitting too close to a front airbag can result in serious injury or death if the front airbags inflate.

Always sit as far back from the front airbags as possible while maintaining control of the vehicle.

The National Highway Traffic Safety Administration and Transport Canada recommend that drivers allow at least 10 inches (25 cm) between the center of the steering wheel and the chest.



#### Models without mode selector

■ Lumbar Support Adjustment Switch Press the top: To move the lumbar support up.

Press the bottom: To move the lumbar support down.
Press the front: To increase the entire lumbar support.
Press the rear: To decrease the entire lumbar support.

## Seat Control Interface\*

Press the mode selector up or down to display seat adjustment information on the audio/information screen, and then use the adjustment switch to adjust the lumbar support, bolster support or thigh support.




#### Seat Control Interface\*

The image of each adjustment mode displayed on the audio/information screen:



 Press the mode selector up or down to select the lumbar support adjustment mode, bolster support adjustment mode or thigh support adjustment mode.
 Press the adjustment switch as follow.





To adjust the lumbar support: Press the top: To move the lumbar support up. Press the bottom: To move the lumbar

support down. **Press the front:** To increase the entire lumbar support.

**Press the rear:** To decrease the entire lumbar support.

To adjust the bolster support:

**Press the front:** To increase the bolster support. **Press the rear:** To decrease the bolster support.

#### Seat Control Interface\*

The lumbar support, bolster support and thigh support can be adjusted even when the power mode is in VEHICLE OFF. However, the adjusting mode display does not come on with the power mode in VEHICLE OFF.






## To adjust the thigh support:

**Press the front:** The tucked-down seat cushion end rolls out to support your thighs. **Press the rear:** The tucked-down seat cushion end rolls in to support your thighs.

- **3.** To close the adjusting mode display, hover over the A and/or B-zone touchpad, then press the True Touchpad Interface.
  - ▶ When you want to close the driver's side adjusting mode display, hover over and press the A-zone touchpad.
  - ▶ When you want to close the passenger's side adjusting mode display, hover over and press the B-zone touchpad.

#### Adjusting the Seat-Backs



Adjust the driver's seat-back to a comfortable, upright position, leaving ample space between your chest and the airbag cover in the center of the steering wheel.

The front seat passenger should also adjust their seat-back to a comfortable, upright position.

Reclining a seat-back so that the shoulder part of the belt no longer rests against the occupant's chest reduces the protective capability of the belt. It also increases the chance of sliding under the belt in a crash and being seriously injured. The farther a seat-back is reclined, the greater the risk of injury.

#### ➢Adjusting the Seat-Backs

## 

Reclining the seat-back too far can result in serious injury or death in a crash.

Adjust the seat-back to an upright position, and sit well back in the seat.

Do not put a cushion, or other object, between the seat-back and your back.

Doing so may interfere with proper seat belt or airbag operation.

If you cannot get far enough away from the steering wheel and still reach the controls, we recommend that you investigate whether some type of adaptive equipment may help.


## **Rear Seats**

#### Folding Down the Rear Seats

Separately fold down the left and right halves of the rear seat to make room for cargo.

#### To fold down the seat

**1.** Lower the head restraints to their lowest position. Put the armrest back into the seat-back



From the rear door side 2. Pull the release lever.

#### ➢Folding Down the Rear Seats

Make sure all items in the cargo area or items extending to the rear seats are properly secured. Loose items can fly forward if you have to brake hard.

Remove any items from the rear seat cushion and floor before you fold down the rear seat.

The rear seat-back(s) can be folded down to accommodate bulkier items in the cargo area.

When you fold down one side of the rear seats and use the non-recessed part of the cargo area, make sure to secure the cargo. Loose items can fly forward and cause injury if you have to brake hard.

Make sure that the folded seat-back does not press against the front passenger seat, as this can cause the weight sensors in the front passenger seat to work improperly.

Passenger Airbag Off Indicator P. 61

The front seat(s) must be far enough forward so they do not interfere with the rear seats as they fold down.



## To return the seat to the original position

Pull up the seat-back in the upright position.

#### To return the seat to the original position

Make sure the seat-back, head restraints and seat cushion are securely latched back into place before driving. Also, make sure all rear shoulder belts are positioned in front of the seat-back.

To lock a seat-back upright, push it backwards until it locks, so that the red tabs in the release lever go down.

When returning the seat-back to its original position, push it firmly back.

## **Rear Seat Reminder**

This feature alerts you to the possible presence of passengers or items in the rear seats before you exit the vehicle. It activates when the vehicle is set to VEHICLE OFF if the rear doors were opened shortly before or after the vehicle was set to ON.



A reminder appears on the multi-information display and an alert will sound when the power mode is set to VEHICLE OFF.

#### ≫Rear Seat Reminder

When the power mode is set to VEHICLE OFF, the reminder comes on briefly, then the function is deactivated.

The reminder will not work if the power mode has not been set to ON within 10 minutes of operating the rear doors.


The system does not detect passengers in the rear seats. Instead, it can detect when a rear door is opened and closed, indicating that there may be something in the rear seats.

You can turn off the notification setting. Customized Features P. 359

## **Head Restraints**

Your vehicle is equipped with head restraints in all seating positions.

## Adjusting the Front and Rear Outer Head Restraint Positions



Head restraints are most effective for protection against whiplash and other rearimpact crash injuries when the center of the back of the occupant's head rests against the center of the restraint. The tops of the occupant's ears should be level with the center height of the restraint.

#### ➢Head Restraints


## 

Improperly positioning head restraints reduces their effectiveness and increases the likelihood of serious injury in a crash.


Make sure head restraints are in place and positioned properly before driving.

In order for the head restraint system to work properly:

- Do not hang any items on the head restraints, or from the restraint legs.
- Do not place any objects between an occupant and the seat-back.
- Install each restraint in its proper location.



To raise the head restraint: Pull it upward. To lower the head restraint: Push it down while pressing the release button.




Front Release Button

To adjust the front head restraint forward: Push the back of it forward. To return the front head restraint to the original position:

Press the release button.

#### Changing the Rear Center Seat Head Restraint Position



A passenger sitting in a center back seating position should adjust the height of their head restraint to an appropriate position before the vehicle begins moving. **To raise the head restraint:** Pull it upward. **To lower the head restraint:** Push it down while pressing the release button.

## Removing and Reinstalling the Head Restraints

Head restraints can be removed for cleaning or repair.

#### To remove a head restraint:

Pull the restraint up as far as it will go. Then, push the release button and pull the restraint up and out.

#### To reinstall a head restraint:

Insert the legs back in place, then adjust the head restraint to an appropriate height while pressing the release button. Pull up on the restraint to make sure it is locked in position.

Removing and Reinstalling the Head Restraints

## 

Failure to reinstall or correctly reinstall, the head restraints can result in severe injury during a crash.

Always replace the head restraints before driving.

## **Maintain a Proper Sitting Position**

After all occupants have adjusted their seats and head restraints, and put on their seat belts, it is very important that they continue to sit upright, well back in their seats, with their feet on the floor, until the vehicle is safely parked and the engine is off.

Sitting improperly can increase the chance of injury during a crash. For example, if an occupant slouches, lies down, turns sideways, sits forward, leans forward or sideways, or puts one or both feet up, the chance of injury during a crash is greatly increased.

In addition, an occupant who is out of position in the front seat can be seriously or fatally injured in a crash by striking interior parts of the vehicle or being struck by an inflating front airbag.

Maintain a Proper Sitting Position

## 

Sitting improperly or out of position can result in serious injury or death in a crash.

Always sit upright, well back in the seat, with your feet on the floor.

## Armrest

## Using the Front Seat Armrest



The console lid can be used as an armrest. **To adjust:** Pull the handle and slide the armrest to desired position.


## Using the Rear Seat Armrest



Pull down the armrest in the center backrest.

## **Interior Lights**

## Interior Light Switches



#### ON

The interior lights come on regardless of whether the tailgate and doors are open or closed.

#### Door activated

The interior lights come on in the following situations:

- When the tailgate or any doors are opened.
- You unlock the driver's door.
- When the power mode is set to VEHICLE OFF.

#### 

The interior lights remain off regardless of whether the tailgate or any doors are open or closed.

#### Interior Light Switches

In the door activated position, the interior lights fade out and go off about 30 seconds after the doors are closed.

The lights go off after about 30 seconds in the following situations:

- When you unlock the driver's door but do not open it.
- When you set the power mode to VEHICLE OFF but do not open a door.

The interior lights go off immediately in the following situations:

- When you lock the driver's door.
- When you close the driver's door in ACCESSORY mode.
- When you set the power mode to ON.

To avoid draining the battery, do not leave the interior light on for an extended length of time when the engine is off.

If you leave any of the tailgate or doors open in VEHICLE OFF mode, the interior lights go off after about 15 minutes.

## Map Light Switches



#### Front

The map lights can be turned on and off by pressing the  $\overline{\&r}$  button.

# (100) (100)

#### Rear

The map lights can be turned on and off by pressing the *b* button when the interior light switch is in the door activated position.

#### Map Light Switches

When the interior light switch is in the door activated position and any door is open, the map light will not go off when you press the  $\overleftarrow{\text{sym}}$  button.

## Cargo Area Light




The cargo area light comes on when you open the tailgate.

#### ≫Cargo Area Light

The cargo area light does not have an on/off switch. In case the tailgate is left open for an extended period of time, they automatically go out in 30 minutes.

## **Storage Items**

## Glove Box



Press the button to open the glove box. You can lock the glove box with the built-in key.

#### Removable shelf

The shelf in the glove box is detachable. To remove it, disengage the tabs.

The removable shelf can be stored upside down in the glove box.


#### ➢Glove Box

## 

An open glove box can cause serious injury to your passenger in a crash, even if the passenger is wearing the seat belt.


Always keep the glove box closed while driving.

The glove box light comes on when the parking lights are on.






## Console Compartment



Slide the armrest to the rearmost position. Pull the handle to open the console compartment.

Slide the lid using the release knob to open or close the console compartment.

#### Beverage Holders



#### Front seat beverage holders

Slide the lid to use the front seat beverage holders.

#### Rear seat beverage holders


Fold the armrest down to use the rear seat beverage holders.

#### Beverage Holders

#### NOTICE

Spilled liquids can damage the upholstery, carpeting, and electrical components in the interior.

Be careful when you are using the beverage holders. Hot liquid can scald you.



#### Door side beverage holders

Are located on the both of the front and rear door side pockets.



## Coat Hooks




There are coat hooks on the rear grab handle of both sides. Pull it down to use it.

#### ≫Coat Hooks

The coat hooks are not designed for large or heavy items.

#### Tie-down Anchors




The tie-down anchors on the cargo area floor can be used to install a net for securing items.

#### ➢Tie-down Anchors

Do not let anyone access items in the cargo area while driving. Loose items can cause injury if you have to brake hard.

#### Under-floor Storage Area



Pull the handle and remove the tabs to open the cargo floor lid.

#### Sunglasses Holder



To open the sunglasses holder, press and release the indent. To close, press it again until it latches.

You can store eyeglasses and other small items in this holder.

#### Sunglasses Holder

Keep the holder closed while driving except when accessing stored items.

## **Other Interior Convenience Items**

#### Accessory Power Sockets

The accessory power sockets can be used when the power mode is in ACCESSORY or ON.



Accessory power socket (front panel)

Open the cover to use it.

■ Accessory power socket (cargo area)\* Open the cover to use it. ➢Accessory Power Sockets

#### NOTICE

Do not insert an automotive type cigarette lighter element.

This can overheat the accessory power socket.


The accessory power socket is designed to supply power for 12-volt DC accessories that are rated 180 watts (15 amps) or less.

To prevent battery drain, only use the accessory power socket with the engine running.

When the accessory power socket is not in use, close the cover to prevent any small foreign objects from getting into the accessory power socket.

#### Wireless Charger\*

To use the wireless charger, the power mode must be in ACCESSORY or ON. Charge any devices compatible with Qi wireless charging on the area indicated by the 😒 mark as follows:



- 1. To turn the system on and off, press and hold the (IJ) (power) button.
  - When the system is activated, the green indicator light comes on.
- **2.** Place the device you want to charge on the charging area.
  - The system will automatically start charging the device and the amber indicator light will come on.
  - Make sure that the device is compatible with the system and placed with the chargeable side in the center of the charging area.
- **3.** When charging is completed, the green indicator light will come on.
  - Depending on the device, the amber indicator light will stay on.

#### ≫Wireless Charger\*

#### RF Radiation Exposure Statement: U.S. models

This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

#### Canadian models

This equipment complies with ISED RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

In order to use safely:

- Remove any metal objects from the charge pad before charging a device.
- Do not open the charger case.
- Do not use the charger if it malfunctions. Contact your dealer.

If the charger interferes with radio communications, attempt to correct the interference:

• Press and hold the switch on the charger for a few seconds to turn off the charger.

spears on the audio/information screen when the device is being charged by the wireless charger.

#### When charging does not start

Perform one of the solutions in the following table.

Indicator		Cause	Solution
Green & Amber	Blinking simulta- neously	There is an obstacle(s) between the charging area and the device.	Remove the obstacle(s).
		The device is not within the charging area.	Pick up and reset the device to the center of the charging area where 👺 is located.
		The temperature of the wireless charger pad increases.	Temporarily suspend charging the device. Wait for the temperature to drop and attempt to charge the device again.
Amber	Blinking	The wireless charger is faulty.	Contact a dealer for repairs.

#### Wireless Charger \*

## 

Metal objects between the charge pad and the device to be charged will get hot and can burn you.

- Always remove foreign objects from the charge pad before charging the device.
- Be sure the surface is clear of dust and other debris before charging.
- Do not spill liquids (i. e. water, drinks, etc.) on the charger and the device.
- Do not use oil, grease, alcohol, benzine or thinner for cleaning the charge pad.
- Do not cover the system with towels, clothing, or other objects while charging etc.
- Avoid spraying aerosols which may come in contact with the charge pad surface.

This system consumes a lot of power. Do not use the system for a long time when the engine is not running. This may weaken the battery, making it difficult to start the engine.

When using the wireless charger, check the user's manual that came with the compatible device you want to charge.

The wireless charger can support up to 15W, but the charging rate varies based on the device and other conditions.

#### NOTICE

Do not place any magnetic recording media or precision machines within the charging area while charging.

The data on your cards such as credit cards can be lost because of the magnetic effect. Also, precision machines such as watches can be affected.

"Qi" and I marks are the registered trademarks owned by Wireless Power Consortium (WPC).

In the following cases, charging may stop or not start:

- The device is already fully charged.
- The temperature of the device is extremely high while charging.
- You are at a place that emits strong electromagnetic waves or noises such as TV station, electric power plant, or gas station.
- The device has a cover, case or accessories which are not compatible with wireless charging.

#### >> Wireless Charger \*

A device may not charge if the size or shape of its chargeable side is not appropriate for use with the charging area.

Not all devices are compatible with the system.

During the charging phase, it is normal for the charging area and device to heat up.


Charging may be briefly interrupted when:

- All the doors or the tailgate are closed
- to avoid interference with the proper functioning of the keyless access system.
- The position of the device is altered.

Do not charge more than one device at a time on a charging area.

If the device becomes too hot and its battery protection function activates, it may charge extremely slowly or no longer charge. The temperature at which the battery protection function activates depends on the device.

## Heated Steering Wheel\*



The power mode must be in ON to use the heated steering wheel.

Press the button on the left side of the steering wheel.

When a comfortable temperature is reached, press the button again to turn it off.


The heated steering wheel is turned off every time you start the engine, even if you turned it on the last time you drove the vehicle.

#### ➢Heated Steering Wheel \*

Do not use the heated steering wheel continuously when the engine is off. Under such conditions, the battery may be weakened, making the engine difficult to start.

#### Front Seat Heaters/Ventilators\*





The seat heaters or ventilators<sup>\*</sup> can be used when the power mode is in ON. The seat heaters: Use them to warm up the

seat. The seat ventilators\*: Use them when you want to ventilate the surface of the seats. The

lower you set the air conditioning temperature, the more you will feel the effect of the seat ventilation.

Press the seat heater or the seat ventilator\* button:

Once - The HI setting (three indicators on) Twice - The MID setting (two indicators on) Three times - The LO setting (one indicator on) Four times - The OFF setting (no indicators on)

#### Press the **AUTO** button:

The system automatically selects the setting most suitable to the ambient environment.

When the power mode is turned on after it is turned off, the previous setting is maintained.

Front Seat Heaters/Ventilators\*

## **A**WARNING

Heat induced burns are possible when using seat heaters.

Persons with a diminished ability to sense temperature (e.g., persons with diabetes, lowerlimb nerve damage, or paralysis) or with sensitive skin should not use seat heaters.

Do not use the seat heaters and the seat ventilators<sup>\*</sup> even in LO when the engine is off. Under such conditions, the battery may be weakened, making the engine difficult to start.

After a certain period of time, the strength setting for the front seat heaters will automatically be reduced by one level at a time until the front seat heaters shuts off. The elapsed time varies according to the interior environment.

\* Not available on all models

### Rear Seat Heaters\*



The seat heaters can be used when the power mode is in ON.

There is no heater in the rear center seating position.

Press the seat heater button: Once - The HI setting (three indicators on) Twice - The MID setting (two indicators on) Three times - The LO setting (one indicator on) Four times - The OFF setting (no indicators on)

#### ➢Rear Seat Heaters<sup>\*</sup>

## 


Heat induced burns are possible when using seat heaters.

Persons with a diminished ability to sense temperature (e.g., persons with diabetes, lowerlimb nerve damage, or paralysis) or with sensitive skin should not use seat heaters.

Do not use the seat heaters even in LO when the engine is off. Under such conditions, the battery may be weakened, making the engine difficult to start.

## **Using Automatic Climate Control**

The automatic climate control system maintains the interior temperature you select. The system also selects the proper mix of heated or cooled air that raises or lowers the interior temperature to your preference as quickly as possible.



Use the system when the engine is running.

- 1. Press the AUTO button.
- **2.** Adjust the interior temperature using the driver's side or passenger's side temperature control buttons.
- **3.** Press the  $\mathfrak{B}_{OFF}^{ON/}$  (ON/OFF) button to cancel.

#### ≥Using Automatic Climate Control

If any buttons are pressed while using the climate control system in auto, the function of the button that was pressed will take priority.

The **AUTO** indicator will go off, but functions unrelated to the button that was pressed will be controlled automatically.

During idle-stops, air-conditioning is suspended, and only the blower remains active.

If you do not want air-conditioning suspended, press the Auto Idle Stop **OFF** button to cancel idle-stop.

To prevent cold air from blowing in from outside, the fan may not start immediately when the **AUTO** button is pressed.

If the interior is very warm, you can cool it down more rapidly by partially opening the windows, turning the system on auto, and setting the temperature to low. Change the fresh air mode to recirculation mode until the temperature cools down.

When you set the temperature to the lower or upper limit, **Lo** or **Hi** is displayed.

Pressing the  $\boxed{\textbf{s}_{OF}^{OF}}$  button switches the climate control system between on and off. When turned on, the system returns to your last selection.

#### Switching between the recirculation and fresh air modes

Press the environmental conditions.


Recirculation mode (indicator on): Recirculates air from the vehicle's interior through the system.

Fresh air mode (indicator off): Maintains outside ventilation. Keep the system in fresh air mode in normal situations.

#### ≥Using Automatic Climate Control

When you unlock the doors with your remote, the driver's ID (**DRIVER 1** or **DRIVER 2**) is detected, and the climate control settings are turned to the respective mode automatically when you set the power mode to ON.

#### Defrosting the Windshield and Windows



Pressing the result button turns the air conditioning system on and automatically switches the system to fresh air mode.

Press the  $\boxed{mean}$  button again to turn off, the system returns to the previous settings.

#### Defrosting the Windshield and Windows


For your safety, make sure you have a clear view through all the windows before driving.

Do not set the temperature near the upper or lower limit.

When cold air hits the windshield, the outside of the windshield may fog up.

If you press the to button during Auto Idle Stop, the engine restarts automatically.

#### To rapidly defrost the windows




- **1.** Press the 🐨 button.
- 2. Press the 🖛 button.

#### To rapidly defrost the windows

After defrosting the windows, switch over to fresh air mode.

If you keep the system in recirculation mode, the windows may fog up from humidity. This impedes visibility.

## Synchronization Mode



You can set the temperature synchronously for the driver's side and the passenger's side in synchronization mode.


- 1. Press the SYNC button.
  - ► The **SYNC** indicator will come on.
  - ▶ The system switches to synchronization mode.
- 2. Adjust the temperature using the driver's side temperature control buttons.

Press the **SYNC** button or adjust the interior temperature using the passenger's side temperature control buttons to return to dual mode.

#### Synchronization Mode

When the system is in dual mode, the driver's side temperature and the passenger's side temperature can be set separately.

## Rear Temperature Control Dial\*




You can set the rear passenger compartment temperature different than the driver's, using the rear temperature control dial.

➢Rear Temperature Control Dial\*

The rear temperature can be adjusted when the climate control system is on.

## **Automatic Climate Control Sensors**



The automatic climate control system is equipped with sensors. Do not cover or spill any liquid on them.



# Features

This chapter describes how to operate technology features.

## Audio System

About Your Audio System	254
USB Ports	255
Audio System Theft Protection	257
Audio Remote Controls	258
Audio System Basic Operation	260
True Touchpad Interface	261
Audio/Information Screen	264
Smart Shortcuts	278
System Updates	281
Adjusting the Sound	287
Display Setup	288

Alexa Built-In *	289
Voice Control Operation	290
Playing AM/FM Radio	293
Playing SiriusXM <sup>®</sup> Radio	297
Playing an iPod	310
Playing a USB Flash Drive	313
Playing <i>Bluetooth</i> ® Audio	316
Wi-Fi Connection	319
AT&T Hotspot	321
Apple CarPlay	322
Android Auto™	327
Audio Error Messages	332


General Information on the Audio	
System	336
Customized Features	359
HomeLink <sup>®</sup> Universal Transceiver 3	386
Bluetooth <sup>®</sup> HandsFreeLink <sup>®</sup>	389
AcuraLink <sup>®</sup>	119

\* Not available on all models

# **About Your Audio System**

The audio system features AM/FM radio and SiriusXM<sup>®</sup> Radio service. It can also play USB flash drives, and iPod, iPhone, iPad and *Bluetooth*<sup>®</sup> devices.

You can operate the audio system from the True Touchpad Interface, buttons and knobs on the panel, or the remote controls on the steering wheel.



#### ➢About Your Audio System

State or local laws may prohibit the operation of handheld electronic devices while operating a vehicle.

SiriusXM<sup>®</sup> Radio is available on a subscription basis only. For more information on SiriusXM<sup>®</sup> Radio, contact a dealer.

Seneral Information on the Audio System P. 336

SiriusXM® Radio is available in the United States and Canada, except Hawaii, Alaska, and Puerto Rico.

SiriusXM<sup>®</sup> is a registered trademark of SiriusXM Radio, Inc.

After you turn the power mode to VEHICLE OFF (LOCK) with the driver's door closed, you can use the audio system for up to 30 minutes per driving cycle. However, whether you can continue using the audio system depends on the battery condition. Repeatedly using this feature may drain the battery. The audio system turns off when you open the driver's door.

## **USB** Ports

Install the device USB connector or the USB flash drive in the USB port.



■ In the console compartment

The USB port (2.5A) is for charging devices, playing audio files and connecting compatible phones with Apple CarPlay or Android Auto.

To prevent any potential issues, be sure to use an Apple MFi Certified Lightning Connector for Apple CarPlay, and for Android Auto, the USB cables should be certified by USB-IF to be compliant with USB 2.0 Standard.

#### ≫USB Ports

- Do not leave the iPod or USB flash drive in the vehicle. Direct sunlight and high temperatures may damage it.
- We recommend that you use a USB cable if you are attaching a USB flash drive to the USB port.
- Do not connect the iPod or USB flash drive using a hub.
- Do not use a device such as a card reader or hard disk drive, as the device or your files may be damaged.
- We recommend backing up your data before using the device in your vehicle.
- Displayed messages may vary depending on the device model and software version.

## USB charge

The USB port can supply up to 2.5A/3.0A of power. It does not output 2.5A/3.0A unless the device requests.

For amperage details, read the operating manual of the device that needs to be charged.

Under certain conditions, a device connected to the port may generate noise in the radio you are listening to.



## On the front panel

The USB port (3.0A) is only for charging devices.

#### ➢On the front panel

This port is for battery charge only. You cannot play music even if you have connected a music player to the port.

Under certain conditions, a device connected to the port may generate noise in the radio you are listening to.

#### >> On the back of the console compartment<sup>\*</sup>

These ports are for battery charge only. You cannot play music even if you have connected a music player to the ports.

Under certain conditions, a device connected to the port may generate noise in the radio you are listening to.



On the back of the console compartment\*

The USB ports (3.0A) are only for charging devices.

# **Audio System Theft Protection**


The audio system is disabled when it is disconnected from the power source, such as when the battery is disconnected or goes dead. In certain conditions, the system may display a code entry screen. If this occurs, reactivate the audio system.

## Reactivating the audio system

- **1.** Set the power mode to ON.
- 2. Turn on the audio system.
- 3. Press and hold the audio system power knob for more than two seconds.
  - ▶ The audio system is reactivated when the audio control unit establishes a connection with the vehicle control unit. If the control unit fails to recognize the audio unit, you must go to a dealer and have the audio unit checked.

# **Audio Remote Controls**

Allow you to operate the audio system while driving. The information is shown on the multi-information display or head-up display<sup>\*</sup>.



## VOL+/VOL- (Volume) Switch

**Press Up:** To increase the volume.

Press Down: To decrease the volume.

## 也 (Power) Button

Press to turn the audio system on and off.

## Left Selector Wheel

• When selecting the audio mode

Press the **APPS** button, then roll up or down to select an item on the multiinformation display or head-up display<sup>\*</sup>, and then press the left selector wheel.

#### Models with head-up display

Move the left selector wheel to the right to display the **Recents** list, then scroll to an item selected in the past and press the wheel.

#### ➢Audio Remote Controls

Some modes appear only when an appropriate device or medium is used.

Depending on the *Bluetooth*<sup>®</sup> device you connect, some functions may not be available.

Press the (back) button for the multiinformation display or head-up display\* to go back to the previous screen or cancel a command.

Press the **APPS** button to go back to the menu screen of the multi-information display or head-up display\*.


#### Models with head-up display

**Recents** list is available when the following audio mode is selected.

- FM Radio
- AM Radio
- SiriusXM
- USB Audio

### Roll up or down:

To cycle through the modes, roll up or down and then press the left selector wheel:



After an audio mode is selected, the left selector wheel can be operated for the following functions.

• When listening to the radio

**Move to the right:** To select the next favorite radio station or channel. **Move to the left:** To select the previous favorite radio station or channel.

• When listening to an iPod, USB flash drive, *Bluetooth*<sup>®</sup> Audio, or Smartphone Connection

Move to the right: To skip to the next song.

Move to the left: To go back to the beginning of the current or previous song.

#### ➢Audio Remote Controls

You can customize the items on the multiinformation display or the head-up display\*.

#### Customizing the Meter or Head-Up Display\* P. 276

You cannot operate the audio functions while the following functions are being operated on the multi-information display or head-up display\*.


- Mode selection by pressing **APPS** button
- Navigation<sup>\*1</sup>
- Phone
- Select Driving View\*1
- Customize Apps

\*1: Model with head-up display

\* Not available on all models

You can use the audio system for 30 minutes when the power mode is set to VEHICLE OFF (LOCK) with the driver's door closed. The system will then turn off automatically.

If you want to keep using it, we recommend that you turn the power mode to ACCESSORY or ON.



**小 VOL/AUDIO (Volume/Power) Knob**:

Push to turn the audio system on and off. Turn to adjust the volume when the audio system is on.

(Seek/Skip) Buttons: Press to change the station, channel, song or file.

**(Back) Button:** Press to go back to the previous display.

(Home) Button: Press to go to the home screen.

**Cards List) Button:** Press to display the cards list of the B-zone on the audio/ information screen.

▶ B-Zone P. 267

**A-Zone Touchpad:** Click or swipe the pad with your finger or move your finger along the pad to operate the A-zone on the audio/ information screen.

**B-Zone Touchpad:** Click or swipe the pad with your finger to operate the B-zone on the audio/information screen.

➢Audio System Basic Operation

True Touchpad Interface True Touchpad Interface P. 261

# **True Touchpad Interface**

You can operate the system using the True Touchpad Interface.

## A-Zone Touchpad Operation



## Click

Lightly press the A-zone touchpad to select an item.

## Press and hold

Press and hold to initiate edit mode throughout the system.

## Swipe

Swipe or drag your finger in various directions to operate each screen.

#### ■True Touchpad Interface

#### **True Touchpad Interface Operation**

- Some items may be grayed out during driving to reduce the potential for distraction.
- You can select them when the vehicle is stopped or use voice commands.
- Wearing gloves may limit or prevent the True Touchpad Interface response.
- Some electronics like inverters may cause slow response while using the True Touchpad Interface.

You can operate the True Touchpad Interface using gloves when you set the **Touchpad Sensitivity** setting to **High**. However, the True Touchpad Interface cannot be operated with insulated gloves.

Customized Features P. 359



# 


## Flick

Flick (or drag) your finger up/down or left/ right to scroll in lists or change pages throughout the system.

# 


### Handwriting a character

Move your finger quickly to trace a character on the A-zone touchpad.




Models with navigation system Swipe with two fingers Swipe (or drag) two fingers across the screen to move the map.

## B-Zone Touchpad Operation




## Click

Lightly press (click) the B-zone touchpad to select a card.



## Swipe

Swipe or drag your finger up or down to select an item.



## Flick

Flick up or down to cycle through the card displayed in the B-zone.

# **Audio/Information Screen**

Displays each mode status. From this display, you can go to various setup options.

## A-Zone

## Switching the display



Press the 👔 (home) button to go to the home screen. Select the following icons on the home screen or **All Apps** list.

## Navigation\*

Displays the navigation screen.

Refer to the Navigation System Manual

## Phone

Displays the HFL information.

**Bluetooth® HandsFreeLink®** P. 389

## FM Radio/AM Radio/SiriusXM/USB Audio/Bluetooth Audio

Displays the audio information for each.

#### Audio/Information Screen

#### All Apps list

You can select any of the apps from the All Apps list. To display the **All Apps** list, place your finger on the A-zone touchpad and swipe right.

Home Screen P. 269

You can add or remove any of the apps in the home screen through the **All Apps** list.

To add app icons to the home screen and the head-up display\* P. 270

## Settings

Enters the customizing menu screen. ■ Customized Features P. 359

■ Apple CarPlay
 Displays the Apple CarPlay screen.
 ■ Apple CarPlay P. 322

■ Android Auto
 Displays the Android Auto screen.
 ■ Android Auto<sup>™</sup> P. 327

■ System Updates Updates the software version of the audio system. System Updates P. 281

Messages
 Displays the text message screen.
 Text Message P. 407

■ AT&T HotSpot Displays the AT&T Hotspot screen. ■ AT&T Hotspot P. 321

## ■ AcuraLink Displays the AcuraLink screen.

AcuraLink® P. 419

Smart Shortcuts
 Displays the Smart Shortcuts screen.
 Smart Shortcuts P. 278

■ Alexa Displays the Alexa screen. ■ Alexa Built-In\* P. 289

## B-Zone

You can see the audio, HFL information, navigation mini map<sup>\*</sup>, and clock information on the B-zone using the B-zone touchpad.



## Switching the card

Swipe up or down on the B-zone touchpad to cycle through the following screen.



## ≫B-Zone

SiriusXM<sup>®</sup> radio service notifications are displayed in the B-zone.

#### Switching the card


The card in the B-zone will change depending on the screen displayed in the A-zone.

#### Models without navigation system

\*1: Appears only when you set a destination on the Apple CarPlay or Android Auto navigation function.

Apple CarPlay P. 322
 Android Auto<sup>™</sup> P. 327


You can also switch the screen by doing the following:



Press the (cards list) button.
 Select an item then press the B-zone touchpad.

## Home Screen

#### To change to the next screen



Swiping the A-zone touchpad left or right takes you to the next screen.

#### ➢Home Screen

The home screen has 2 pages. You can add up to 8 pages.

Press the (home) button to go directly back to the first page of the home screen from any page.

## ■ To add app icons to the home screen and the head-up display\*

You can add app icons to the home screen and the head-up display.

I App	5		
**	AcuraLink	ā	
0	Alexa	~6	
0,0	AM Radio		
	Android Auto		

- 1. Press the 🕋 (home) button.
- 2. Swipe right to display the All Apps screen.
- **3.** Go to an app on the list, then press and hold the A-zone touchpad.
- From the pop-up menu, select Add to Home Page or Add to Heads-Up Display\*.
  - ► The not consider the list when the corresponding icon has been added to the home screen or the head-up display.

#### To add app icons to the home screen and the head-up display\*

Pre-installed apps may not start up normally. If this occurs, you need to reset the system.

#### Defaulting All the Settings P. 385

If you perform **Factory Data Reset**, it may reset all the settings to their factory default.

#### Defaulting All the Settings P. 385

In case those apps still do not startup normally, even after **Factory Data Reset**, contact your dealer.

#### Models with head-up display

Each item with **HUD** is listed on the head-up display menu.

If you want to hide the item from the head-up display menu, select **Remove from Heads-Up Display**.

## ■ To add shortcut icons to the home screen and the head-up display\*

Shortcut icons for items stored in Favorite can be added to the home screen and the head-up display.



- **1.** Select a favorite item, then press and hold the A-zone touchpad.
  - A pop-up menu will appear on the screen.
- 2. Select Add to Home Page or Add to Heads-Up Display\*.
  - ► A shortcut icon will be added to the home screen or the head-up display.

To add shortcut icons to the home screen and the head-up display\*

#### Models with head-up display

You can add an icon to the head-up display directly from the home screen. Select an icon on the home screen, then press and hold the A-zone touchpad. After that, select **Add to Heads-Up Display**, and then press the (back) button or the (home) button to confirm the change.

Note that icons for Messages, Settings, System Update, AT&T Hotspot, AcuraLink, and Smart Shortcuts cannot be added to the head-up display.

## To move icons on the home screen

You can change the location of the icons on the home screen.



- **1.** Select the icon you want to move, then press and hold the A-zone touchpad.
  - The screen will change to the customization screen.
- **2.** Drag the icon to where you want it to be and then press and hold the A-zone touchpad.
  - The icon will be repositioned and the screen will remain in the customization mode.
  - After you drag the icon, keep your finger on the A-zone touchpad and then press down. If you release your finger before pressing the A-zone touchpad, the icon will remain in its original place.
  - If you want to reposition the icon on another page of the home screen, swipe the A-zone touchpad.
- **3.** Press the (back) button or the (home) button to confirm the change.

## ■ To remove icons from the home screen and the head-up display\*

You can remove icons from the home screen and the head-up display.



- **1.** From the home screen, select the icon that you want to remove, then press and hold the A-zone touchpad.
  - The screen will switch to the customization screen.
- 2. Go to Remove from Home Page or Remove from Heads-Up Display\* and press the A-zone touchpad.
  - The icon will be removed from the home screen or the head-up display and the screen will remain in the customization mode.
- **3.** Press the (back) button or the (home) button to confirm the change.

You can also remove an icon from the home screen or the head-up display directly from the **All Apps** list.

- **1.** Go to an item you want to remove, then press and hold the A-zone touchpad.
- 2. Go to Remove from Home Page or Remove from Heads-Up Display\* and press the A-zone touchpad.
  - ► The icon will be removed from the home screen or the head-up display.
- **3.** Press the (back) button or the (home) button to confirm the change.

To remove icons from the home screen and the head-up display\*

Removing an icon from the home screen does not result in the deletion of the corresponding app.

Press and hold (f) (home) button to switch to the customization screen.

### Models with head-up display

If you remove a shortcut icon from the home screen, the function of selected icon is also removed from the head-up display.

## Status Area




- **1.** Select the system status area, then press the B-zone touchpad.
  - ► The status items will appear in the Azone.
- 2. Select an item to see the details.
  - Select **Dismiss** to delete the detail.
  - ▶ Press the (back) button or select
  - status area again to close the status list.

## Searching Screen

You can use the handwriting input feature by using the A-zone touchpad when searching for various audio system items (e.g., music, navigation route, phonebook contact).

screen.

zone touchpad.



- **1.** Write letters or numbers using the A-zone touchpad.
  - Search results appear on the screen.

▶ If you re-enter letters or numbers, select the input area on the upper side of the

#### Searching Screen

#### Delete a letter or number

Swipe left on the A-zone touchpad to delete a letter or a number.

#### Input a space

Swipe right on the A-zone touchpad to input a space.

You can input letters or numbers by using the onscreen keyboard. Select **KEYBOARD** on the upper right of the screen.

When you return to the handwriting input screen, select HANDWRITING.

You can input letters or numbers by using voice control operation. Select the 🖳 icon on the upper left of the screen.

Features

## Customizing the Meter or Head-Up Display\*

You can edit, show, or hide the audio, phone and navigation<sup>\*</sup> contents on the multiinformation display or the head-up display<sup>\*</sup>.

## To add or remove an items



## On Head-Up Display\*

1	Add/Remove	Reorder 🕨
Select an App to	🗹 AAA	
toggle its	🗹 BBB	
appearance in the	🖸 CCC	
Heads -Up Display	DDD	

- **1.** Press the **APPS** button on the steering wheel.
- 2. Roll down the left selector wheel to select **Customize Apps**.
- 3. Move the left selector wheel left to select Add/Remove.
- **4.** Select an item then press the left selector wheel.
  - The checked items are displayed on the multi-information display or the head-up display\*.

276 \* Not available on all models

## Editing order



## On Head-Up Display\*

Add/Remo	ove	Reorder
	٩.	AAA
Select an App to reorder	(( <u>e</u> ))	BBB
	4	CCC
	0	DDD

- 1. Press the **APPS** button on the steering wheel.
- 2. Using the left selector wheel, scroll to **Customize Apps** and then press the selector wheel.
- **3.** Move the selector wheel to the right to go to the **Reorder** screen.
- **4.** Scroll to an item you want to move, then press the left selector wheel.
- **5.** Scroll to where you want to move the contents, then press the left selector wheel.

# **Smart Shortcuts**

By observing and learning driver behaviors, patterns, and preferences, the system anticipates driver actions and presents on-screen suggestions to help perform desired actions quicker and with fewer steps.

- The app will suggest actions based on what it learns you do often, and occasionally make recommendations based on your learned preferences.
- The system will take some time to learn. The more you interact with the system, the more suggestion you will see, and the more accurate they will become.
- Suggestions will automatically refresh periodically to provide updated content for each profile.
- You can also provide feedback on whether a suggestion is helpful by pressing and holding on it. This can help the app grow smarter over time.



- To change the notifications behavior for Smart Shortcuts:
- 1. Select **MENU** on the **Smart Shortcuts** screen.
- 2. Select Suggestion Settings.
- 3. Select an option.
- All data used for Smart Shortcuts can be erased by a Factory Data Reset.
   Defaulting All the Settings P. 385

#### Smart Shortcuts

The app also supports different profiles for each user, with customized learning for each profile. The app will also learn to associate a profile to a user over time based on key fob and connected phone data.

## How to Use



- 1. Press the 🕋 (home) button.
- 2. Select Smart Shortcuts.
- **3.** Select a shortcut to take the action suggested.

• **Call Suggestions:** When selected, a call to the contact or number suggested will be placed and shown in the B-zone. Based on your calling patterns, contacts will be suggested for you to call.

- Connect your smartphone through *Bluetooth*<sup>®</sup> to get contact suggestions.
- Call suggestions will not be displayed when you are connected to Apple CarPlay.
- **Navigation Suggestions**\*: When selected, a route will be started to the suggested destination and the embedded navigation app will open.
  - When a long route is set in your navigation system, you can receive recommendations for gas stations and places to stop at along the way.
  - The places you frequently navigate to while using the embedded navigation system will be suggested as shortcuts.
  - Save your home location in the embedded navigation app to have a shortcut suggestion for it when you're away from home.

#### ➢How to Use

You can change the profile by selecting **O** on the top of the **Smart Shortcuts** screen.

You can customize the following items by selecting **MENU** on the top of the **Smart Shortcuts** screen.

- **Profiles**: Create, change, and manage profiles.
- View App Walkthrough: View the Smart Shortcuts walkthrough.
- **Suggestion Settings**: Change where suggestions can appear.

#### To create a profile:

- 1. Select **MENU** on the **Smart Shortcuts** screen.
- 2. Select Profiles.
- 3. Select Manage Profiles.
- 4. Select + Add New Profile.
- 5. Enter name for your profile.
- 6. Click on the A-zone touchpad to confirm.
  A new profile has been created and the Smart App will automatically switch to that profile.

#### To change a profile:

- 1. Select **MENU** on the **Smart Shortcuts** screen.
- 2. Select Profiles.
- 3. Select Change Current Profile.
- 4. Select a profile from the list.
  - The change to the selected profile has been made.

- **Radio Suggestions:** When selected, the corresponding radio app (FM, AM, or SiriusXM<sup>®</sup>) will open and it will start playing the station.
  - From radio apps you can receive:
    - FM, AM, SiriusXM<sup>®</sup>: Most frequently listened stations.
    - FM, SiriusXM<sup>®</sup>: Genre-based suggestions.
  - Considerations:
    - FM suggestions will appear only when they are within range, according to your vehicle's tuner signal.
    - SiriusXM<sup>®</sup> suggestions will be available as long as there is an active account in the vehicle.

# **System Updates**

The audio system's firmware can be updated with the telematics control unit (TCU) through the subscription-based service.

## How to Update Wirelessly

## ■ Wireless connection mode setup



- 1. Press the 🕋 (home) button.
- 2. Select System Updates.
- 3. Select MENU.
- 4. Select Connection Setup.

> Change Mode		
	to connect to the Internet to to connect to the vehicle an CSWI-FI	

- 5. Select Change Mode.
- 6. Select Network.
  - ► The display will return to the network list.
- 7. Select an access point from the network list, then select **OK**.
  - If the access point requires a password, enter a password.

### How to update

When an audio system update is available, the notification is shown on the audio/ information screen. Use the following procedure to update the system.



- **1.** Press the **1** (home) button.
- 2. Select System Updates.

Notification

)System Updates	i≣ lenu
â	ŧ

- 3. Select via Wireless Connection.
  - ▶ When the download is complete, the screen for step 5 will be displayed.
- 4. Select Download Now.
  - ► A notification will appear on the screen.



- 5. Select Install Now or Install while Vehicle OFF.
  - A notification appears on the screen if the update is successful when Install Now is selected.
  - If you select Install while Vehicle OFF, proceed to steps 6 and 7.
- **6.** Set the power mode to VEHICLE OFF (LOCK).
  - A notification will appear on the screen. If you select **Postpone Update**, the update will be postponed.
- 7. Exit from your vehicle.
  - The system will start the firmware update.
  - If the update is successful, a notification informing you of this fact will appear on the screen the next time you set the power mode to ON.

#### ➢How to update

The system may cancel the firmware update if the battery is low on power, even if you have selected **Install while Vehicle OFF**. If you want to install the updated data, recharge the battery or select **Install Now**.

If you select **Install Now**, the system may reboot.

## Automatic download settings

Use the following procedure to change to the automatic download setting.



- Press the (home) button.
   Select System Updates.
- 3. Select MENU
- 4. Select Auto Download.
- 5. Select the access point, then Allow.

## View update status

Use the following procedure to confirm the update status.

- **1.** Press the 🕋 (home) button.
- 2. Select System Updates.
- 3. Select MENU.
- 4. Select Update Result.

## How to Update with a USB Device

## Download the update files from the server

O System Updates	🚍 bitan
Ŕ	ŧ
via Wireless Connection	viaUSB
(D) and	



- 1. Press the 👔 (home) button.
- 2. Select System Updates.
- 3. Select via USB.
  - ► A notification appears on the screen.
- **4.** Connect a USB device into the USB port in the console compartment.
  - The inventory data is copied into the USB device.
    - **USB Ports** P. 255
- 5. Remove the USB device from the USB port.
- **6.** Connect the USB device into your computer, and then download the update files.
  - Follow the link to download the required software update files. Refer to https://usb.acura.com for instructions.

#### ➢How to Update with a USB Device

A USB device with a minimum of 8 GB of free space or more is recommended.

Be sure to delete any previous inventory or update files from the USB device before starting the USB update process.

### Update the audio system



Step 5 of 6		
Install Now (System will Reboot)	Install while Vehicle OFF	
Software Upo	late is Available	
	may reboot during installation . on: XXX	
	ite time: 1 minutes.	

- 1. Press the 🕋 (home) button.
- 2. Select System Updates.
- 3. Select via USB.
- A notification appears on the screen.
- **4.** Connect the USB device with the update files into the USB port.
  - A notification appears on the screen.USB Ports P. 255
- 5. Select Install Now or Install while Vehicle OFF.
  - A notification appears on the screen if the update is successful when Install Now is selected.
  - When you select Install while Vehicle OFF go to step 6.
- **6.** Set the power mode to VEHICLE OFF (LOCK).
  - A notification appears on the screen. If you select **Postpone Update**, the update is postponed.
- 7. Exit from your vehicle.
  - The system will start the firmware update.
  - A notification appears on the screen if the update is successful at the next time you set the power mode to ON.

#### Update the audio system

The system may stop the firmware update when battery is low on power, even when you selected **Install while Vehicle OFF**.

If you want to install the updated data, recharge the battery or select **Install Now**.

# Adjusting the Sound

- 1. Press the 🕋 (home) button.
- 2. Select an audio source icon.

# USB Audio mode

- 3. Select SOUND.
- 4. Select the setting you want.

FM Radio, AM Radio, SiriusXM, Bluetooth Audio mode

- 3. Select MENU.
- 4. Select Sound Settings.
- 5. Select the setting you want.

Sound	
Bass / Treble	
Roof / Center Volume Amost Moof, Center spaniser volumes	
Audio Zones & Balance / Fader	
Speed Volume Compensation	

Select an item from the following choices:

- Bass / Treble: Treble, Midrange, Bass
- Roof / Center Volume\*: Roof speaker, center speaker
- Audio Zones & Balance / Fader\*: Driver Only, Front Only, Rear Only, Full Vehicle, Balance, Fader
- Balance / Fader\*: Balance, Fader
- **Speed Volume Compensation**: Sets the amount of volume increase.
- **DTS Neural Surround**\*: DTS Neural Surround<sup>™</sup>
- Compressed Audio Enhancement\*: Enhancement for compressed audio quality

#### Adjusting the Sound

The Speed Volume Compensation (SVC) adjusts the volume level based on the vehicle speed. As you go faster, audio volume increases. As you slow down, audio volume decreases.

You can also adjust the sound the following procedure.

- 1. Press the 👚 (home) button.
- 2. Select Settings.
- 3. Select Sound.

#### Audio Zones & Balance / Fader

You can change where the sound comes from by selecting one of the speaker options below:

- Full Vehicle: All the speakers emit sound.
- **Driver Only**: Allows driver to listen to the audio system while maintaining a quieter environment for the other occupants.
- Front Only: Allows front seat occupants to listen to the audio system while maintaining a quieter environment for occupants in the rear.
- **Rear Only**: Allows rear seat occupants to listen to the audio system while maintaining a quieter environment for occupants in the front.

#### **Reset to Default**

Select to reset the following settings from the pop-up menu to their factory default.

- Bass / Treble
- Roof / Center Volume\*
- Audio Zones & Balance / Fader<sup>\*</sup>
- Balance / Fader\*

# **Display Setup**

You can change the brightness of the audio/information screen.

# Changing the Screen Brightness

	Reset to Default
1	
Night Mode	Day Mode
	ay Mode I Night Mode

- 1. Press the 🕋 (home) button.
- 2. Select Settings.
- 3. Select Display.
- 4. Select Day Mode or Night Mode.
- 5. Select the setting you want.
  - When you adjust the Contrast and Black Level, select More Settings.

#### ➢Changing the Screen Brightness

You can change the **Contrast** and **Black Level** settings in the same manner.

To reset the settings, select **Reset to Default**. **Reset to Default** is only applicable to the settings in the current mode.

# Features

# Limitations for Manual Operation\*

Certain manual functions are disabled or inoperable while the vehicle is in motion. You cannot select a grayed-out option until the vehicle is stopped.

# Alexa Built-In\*

You can talk to Amazon Alexa through the audio system. With Alexa, you can:

- Stream music
- Check the weather
- Answer questions
- Control smart home devices
- And more with supported Alexa skills

# **Using Alexa**



Once you sign into Alexa in the vehicle, you can use Alexa without opening the app.

You can trigger Alexa by doing any of the following:

- Say the wake word "Alexa" from anywhere in the audio system.
- Press the 🙀 (Talk) button on the steering wheel.
- Select the **Alexa** icon from inside the app.

#### Alexa Built-In\*

#### Support Resources

For more information or client support:

• Call Acura Client Relations at 1-800-382-2238.

► Audio System Basic Operation ► Alexa Built-In\*

• Go to https://www.amazon.com/alexasupport.

#### **≥**Using Alexa

#### Troubleshooting Tips:

- Make sure you are connected to your phone via either Wi-Fi Hotspot or AT&T Vehicle Data Plan.
- If using an AT&T Vehicle Data Plan, confirm that vour subscription is active.
- Make sure you are logged into your Amazon account
- If Alexa Built-in is using your phone's Wi-Fi Network, connecting CarPlay/Android Auto by wireless will disable Alexa Built-In. To enable Alexa Built-In and Carplay or Android Auto at the same time, connect your phone with an Apple or Android OFM cable

#### **Deleting Your Alexa Settings from the Vehicle**

For your privacy and security, if you transfer the vehicle to a third party, reset all vehicle settings to default and delete all personal data. Also, remove the vehicle from the list of devices in your phone's Alexa app.

Defaulting All the Settings P. 385

# **Voice Control Operation**

Your vehicle has a voice control system that allows hands-free operation. The voice control system uses the  $\mathbb{M}_{2}^{(1)}$  (talk) and  $\mathbb{M}_{2}$  (back) buttons on the steering wheel and a microphone near the map lights on the ceiling.

# Voice Recognition

To achieve optimum voice recognition when using the voice control system:


- The system recognizes natural language and accepts free-form voice commands. An example of voice commands:
  - Voice Recognition Screen P. 291
- Close the windows and panoramic roof.
- Adjust the dashboard and side vents so air does not blow onto the microphone on the ceiling.
- Speak clearly in a clear, natural speaking voice without pausing between words.
- Reduce any background noise if possible. The system may misinterpret your command if more than one person is speaking at the same time.

#### ■Voice Control Operation

When you press the  $\mathfrak{g}$  button, the system beeps and the display changes to the voice recognition screen.

Press the (1) (home) button, (1) (back) button on the True Touchpad Interface or **APPS** button on the steering wheel to cancel a voice recognition function.

# Voice Recognition Screen



When the <u>K</u> (talk) button is pressed, the voice control screen appears. For a complete list of commands, say "Help" after the beep.

The system accepts free-form voice commands.

See the following examples for recommended voice commands.

# Phone Commands

These commands can only be used when a phone is connected.

#### Phone Commands Dial by number

- Call <Phone Number>
- Dial <Phone Number> please
- Phone <Phone Number>

# Redial

- Redial
- Redial last number
- Call last number

# Contact by voice

- Call <your contact name>
- Call <your contact name> on his/her <category name> please
- Make a call to <your contact name>
- Make a call to <your contact name> on her/his <category name>

The system only recognizes contact names stored in the phonebook of your phone.

Phone commands are not available if using Apple CarPlay.

# Audio Commands

### FM Commands

- Play FM radio
- Tune to <87.7-107.9> FM
- I want to listen to FM <87.7-107.9>
- Play FM <87.7-107.9>

#### AM Commands

- Play AM radio
- Tune to <530-1710> AM
- I want to listen to AM <530-1710>
- Play AM <530-1710>

### Sirius XM Commands

- Play XM radio
- Play XM <channel number>
- Listen to <channel name> on XM
- Play XM Channel <channel number>
- Tune to <channel name>
- Listen to <channel number> on the satellite radio

# USB Commands

- Play USB
- Play iPod
- Play genre <genre name>
- Play <artist name>
- Play <album name>
- Play <song name>
- Play <playlist name>

# ■ *Bluetooth*<sup>®</sup> Audio Commands

• Play Bluetooth

# Navigation Commands<sup>\*1</sup>

Refer to the Navigation System Manual

# Standard Commands

- Help
- Cancel
- Repeat

Help provides guidance for the current screen.

# Letter Input Commands

You can search for the desired item on each search screen with your voice.

# List Commands

- Next Page
- Previous Page
- Back
- Go to <number>
- Select <number>

\*1: Models with navigation system

# Amazon Alexa Commands

Alexa Built-In\* P. 289

# Apple CarPlay Commands

Apple CarPlay P. 322

# Android Auto Commands


Android Auto™ P. 327

292 \* Not available on all models

Feature

Features

# Playing AM/FM Radio



# Favorite Station

To add a favorite station:

- 1. Tune to the selected station.
- 2. Select Add Favorite, then select Current Station.
  - When you select From Station List, you can store a station from the station list.

#### Editing a favorite station

Select and hold to desired favorite station icon.

The following items are available:

- Remove Favorite: Delete the favorite station icon from the favorite station list.
- **Replace with** (number): Replace the stored favorite station icon.
- Add to Home Page: Add the shortcut icon of the stored favorite station to the home screen.
- Add to Heads-Up Display<sup>\*</sup>: Add the shortcut item of the stored favorite station to the head-up display menu.

#### ➢Favorite Station

The **ST** indicator appears on the display indicating stereo FM broadcasts. Stereo reproduction in AM is not available.

#### Switching the Audio Mode

Press the **APPS** button on the steering wheel, then select an item or select the audio source icon on the home screen.

#### Audio Remote Controls P. 258

You can store 12 AM/FM stations as favorite stations.

HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. For patents see *http://dts.com/patents*. HD Radio, Artist Experience, and the HD, HD Radio, and "ARC" logos are registered trademarks or trademarks of iBiquity Digital Corporation in the United States and/or other countries.



# Station List

Lists the strongest stations on the selected band. **1.** Select **Station List** to display a list.

2. Select the station.

### Manual update

Updates your available station list at any time.

- **1.** Select **Station List** to display a list.
- 2. Select Refresh.

# Radio Frequency Manual Tune Screen



- 1. Select Tune.
- **2.** Select  $\mathbf{\langle}$  or  $\mathbf{\rangle}$  to tune the radio frequency.

# Provide

Station List

Provides text data information related to your selected RDS-capable FM station.

When you select an RDS-capable FM station, the RDS automatically turns on, and the frequency display changes to the station name. However, when the signals of that station become weak, the display changes from the station name to the frequency.

#### Radio Frequency Manual Tune Screen

Select **G**, then trace the numbers of the radio frequency on the A-zone touchpad. When **KEYPAD** is selected, the on-screen keyboard appears.

# Scan

Samples each of the strongest stations on the selected band for 10 seconds. To turn off scan, select **Stop** or press the (back) button.

# HD Subchannel

Displays the subchannel list when an HD Radio<sup>™</sup> station is selected while listening to an FM station.


- 1. Select 🝺 icon.
- 2. Select the channel number.

# AM/FM Settings

Change the AM/FM settings.

- 1. Select MENU.
- 2. Select HD Radio Setting.
- 3. Select Automatic or Analog Only.

# Playing SiriusXM<sup>®</sup> Radio



### To Change the Tune Mode

- 1. Select MENU.
- 2. Select SiriusXM Settings.
- 3. Select Tune Mode.
- 4. Select All Channels or Within Category.

#### ➢Playing SiriusXM<sup>®</sup> Radio

In the channel mode, all available channels are selectable. In the category mode, you can select a channel within a category (Jazz, Rock, Classical, etc.).

There may be instances when SiriusXM® Radio does not broadcast all the data fields (artist name, title). This does not indicate a problem with your audio system.

SiriusXM® Radio stations load in ascending order, which can take about a minute. Once they have loaded you will be able to scroll up or down to make your selections.

#### Switching the Audio Mode

Press the **APPS** button on the steering wheel, then select an item or select the audio source icon on the home screen.

Audio Remote Controls P. 258

#### **Tune Start:**

When you change to a favorite channel, a song being played on that channel restarts from the beginning with this function. This can be turned on or off by the following procedure.

- 1. Select MENU.
- 2. Select SiriusXM Settings.
- 3. Select Tune Start.
- 4. Select **On** or **Off**.

To change a category, select **Category** icons, or select **Channels** and then select category item.

# Favorite Channel

To add a favorite channel:

- **1.** Tune to the selected channel.
- 2. Select Add Favorite, then select CURRENT CHANNEL.
  - When you select From Channels, you can store a channel from the channel list.

#### Editing a favorite channel

Select and hold to edit a favorite channel.

The following items are available:

- Remove Favorite: Delete the favorite channel from the favorite channel list.
- **Replace with Ch** (number): Replace the stored favorite channel.
- Create TuneMix: Create a favorite multi-channel.
- Add to Home Page: Add a shortcut to the stored favorite channel to the home screen.
- Add to Heads-Up Display<sup>\*</sup>: Add a shortcut to the stored favorite channel to the head-up display menu.

#### ■Favorite Channel

You can store 12 SiriusXM<sup>®</sup> channels in the favorite channel list.

# Create a TuneMix (for music channels only)

A TuneMix is a group of channels saved in one preset. You can store up to 20 of your preferred music channels per TuneMix channel.

Create TuneMix				
Remove Favorite	Replace with Ch 0	Create TuneMix	Add to Home Page	Add to Heads- Up Display
Ter				

To create a favorite multi-channel:

- 1. Tune a channel.
- **2.** Select and hold a number that you want to use as a favorite multi-channel.
- 3. Select Create TuneMix.
  - The number you have selected will be registered as a favorite multi-channel number, and the channel that you have tuned will be registered with this number.

To add a channel to a favorite multi-channel:

- 1. Tune a channel.
- **2.** Select and hold a favorite multi-channel number.
- 3. Select Edit TuneMix.
- 4. Select Add Channel.
  - Current channel is added to the TuneMix.
  - A message appears if the current channel cannot be added to the TuneMix.

Create a TuneMix (for music channels only)

When you want to replace the channel, select **Replace with Ch** (number).

If you want to delete a channel, select **Edit TuneMix**, and then select the channel you want to delete.

# Listening to Featured Channels

Suggested channel listings received from SiriusXM® can be displayed and selected.

- 1. Select Channels.
- 2. Select featured channel category.
- 3. Select featured channel.

➢Listening to Featured Channels

Up to eight featured channels by  $\mathsf{Sirius}\mathsf{XM}^{\circledast}$  can be displayed.

Select **SEARCH LIST**, then trace the letters and/or numbers of the channel on the A-zone touchpad. When **KEYBOARD** is selected, the on-screen keyboard appears.

# Replay Function

The system can record up to the last 60 minutes broadcast of your currently tuned channel as well as the last 30 minutes broadcast of favorite channels, starting from the moment you turn the vehicle on. If you tuned to favorite channel, the system records up to 60 minutes of a broadcast instead of up to 30 minutes. You can rewind and replay the last 30 or 60 minutes of a broadcast.

#### 1. Select More.

2. Move the position you want to replay by selecting et al.

To play or pause on playback mode, select the play/pause icon.


**Returning to real-time broadcast** Select and hold **I** or select **Live**.

#### ≫Replay Function

The system starts storing broadcast in memory when the power mode is turned ON. You can go back to the program from that point.

You can no longer replay any program once the power mode is turned off as it erases memory. You can check how long the program has been stored in memory from the audio/information screen.

After 30 or 60 minutes of recording the system will automatically start deleting the oldest data.



(A): Shows how much time the replayed segment is behind the real-time broadcast

- (B): Replayed segment
- (C): Length stored in memory
- (D): Play/Pause icon

# Live Sports Alert

While listening to other channel, you can receive sports alerts such as scores from your favorite teams.

#### To set up a favorite team

> Favorite Teams	
+ Add Favorite Team	

- 1. Select MENU.
- 2. Select SiriusXM Settings.
- 3. Select Sports Notification Setup.
- 4. Select Edit Favorite Teams.
- 5. Select Add Favorite Team.
- 6. Select a team.

#### To set up an alert message

- 1. Select MENU.
- 2. Select SiriusXM Settings.
- 3. Select Sports Notification Setup.
- 4. Select SportsFlash Game Play Notifications.
- 5. Select Notifications.
- 6. Select On.
- 7. Select Select SportsFlash Teams.
- 8. Select a registered team.
  - Press the (back) button, the screen returns to the previous screen.

#### ■Live Sports Alert

The Pop-up appears and notifies you of a sports alert function.

# Game Start Notification

You can receive a sports channel notification when registered sports teams start playing.

#### To set up a game start notification

- 1. Select MENU.
- 2. Select SiriusXM Settings.
- 3. Select Sports Notification Setup.
- 4. Select Game Notifications.
- 5. Select On.

#### Receiving a game start notification

- **1.** A pop-up appears on the B-zone and notifies you of a game starting.
- 2. Select the system status area then press the B-zone touchpad.
  - ► The status items appear on the A-zone.
- 3. Select a SiriusXM<sup>®</sup> notification item using the A-zone touchpad to see the details.

#### ➢Game Start Notification

Before receiving a game start notification, register a favorite sports team.

To set up a favorite team P. 303

# Traffic and Weather Information

You can receive traffic and weather information.

- 1. Select MENU.
- 2. Select SiriusXM Settings.
- 3. Select Traffic & Weather Setup.
- 4. Select Selected City.
- 5. Select the region.

#### Receiving a traffic and weather information

- **1.** A pop-up will appear in the B-zone to notify you that new traffic and weather information is available.
- 2. Select the system status area, then press the B-zone touchpad.
  - ▶ The status area will appear in the A-zone.
- 3. To see the details, select an item using the A-zone touchpad.
  - ▶ The traffic and weather information will appear in the B-zone.
  - Select **Keep Listening** to continue receiving traffic and weather information.
  - Select **Return to Ch** (channel number) to stop viewing traffic and weather information.

#### ➢Traffic and Weather Information

When traffic and weather information is received, a notification is displayed in the B-zone.

# Channel Schedule

You can view a channel schedule or receive an alert when your favorite program is about to start.

To view a channel schedule

- 1. Select MENU.
- 2. Select Channel Schedule.

#### To set up an alert message

- 1. Select MENU.
- 2. Select Channel Schedule.
- 3. Select a program.
- 4. Select Set Program Alert.
- 5. Select One Time or Every Time.

#### Channel Schedule

Select **SEARCH LIST**, then trace the letters and/or numbers of the channel on the A-zone touchpad. When **KEYBOARD** is selected, the on-screen keyboard appears.

#### ■To set up an alert message

The Pop-up appears and notifies you of an alert function.

Selecting **One Time** disables the alert feature next time you turn the power mode to ON.

If you want to delete the alert, select **Remove Alert**.

To enable an alert message, change settings for the alert function.

**To enable the alert function** P. 307

# Manage Program Alert

You can change settings for the alert function.

### To enable the alert function

- 1. Select MENU.
- 2. Select SiriusXM Settings.
- 3. Select Manage Program Alerts.
- 4. Select Notifications.
- 5. Select On or Off.

### To remove an alert

- 1. Select MENU.
- 2. Select SiriusXM Settings.
- 3. Select Manage Program Alerts.
- 4. Select Alerts Set.
- 5. Select an item you want to delete.
  - A confirmation message appears on the screen. Select **Delete**.

# 🔳 Scan

Sample each channel on the selected mode for 10 seconds.

- 1. Select More.
- 2. Select Scan.

You can change a scan mode by the following procedure.

- 1. Select MENU.
- 2. Select SiriusXM Settings.
- 3. Select Scan Mode.
- 4. Select Channels or Favorites.

To turn off scan, select **Stop**.

#### ≫Scan

The favorites scan function is based on TuneScan™ technology of SiriusXM<sup>®</sup>.

The "Featured Channels" function is based on Featured Favorites<sup>™</sup> technology of SiriusXM<sup>®</sup>.

TuneScan<sup>™</sup> and Featured Favorites<sup>™</sup> are registered trademarks of SiriusXM<sup>®</sup> Radio, Inc.

# SiriusXM Settings

Change the SiriusXM<sup>®</sup> settings.

- 1. Select MENU.
- 2. Select SiriusXM Settings.
- 3. Select an option.
- **Tune Mode:** Choose whether to group by category or channel number when changing channels.

To Change the Tune Mode P. 298

- Scan Mode: Select the scan mode from all channels or favorites. ➡ Scan P. 308
- **Tune Start:** Start the currently playing song at the beginning when you switch to a music channel favorite.

**Tune Start:** P. 298

• **Sports Notification Setup:** Set to receive sports alerts such as scores from your favorite teams.


Live Sports Alert P. 303

- Traffic & Weather Setup: Set to receive traffic and weather information. ➡ Traffic and Weather Information P. 305
- Manage Program Alerts: Change settings for the alert function.
   Manage Program Alert P. 307

# **Playing an iPod**

Using your USB connector, connect the iPod to the USB port, then select the USB mode.

USB Ports P. 255



# How to Select a Song from the Music Search List



- 1. Select Music Library.
- **2.** Select a search category (e.g., Artists, Albums, etc.).
- **3.** Continue making selections until you find the song of your choice.

#### ➢Playing an iPod

Available operating functions vary on models or versions. Some functions may not be available on the vehicle's audio system.

If there is a problem, you may see an error message on the audio/information screen.

#### **iPod/USB Flash Drive** P. 332

If you operate the music app on your iPhone/iPod while the phone is connected to the audio system, you may no longer be able to operate the same app on the audio/information screen. Reconnect the device if necessary.

Select **SEARCH LIST**, then trace the letters and/or numbers of the song on the A-zone touchpad. When **KEYBOARD** is selected, the on-screen keyboard appears.

# How to Select a Play Mode

You can change the playback mode for a song.



#### ■ Shuffle/Repeat

Repeatedly select the shuffle or repeat icon until you find a play mode option of your preference.

#### ➢How to Select a Play Mode

Play Mode Menu Items Shuffle



(shuffle off): Shuffle mode to off.



(shuffle all songs): Plays all available songs in a selected list in random order.

#### Repeat



(repeat off): Repeat mode to off.



(repeat song): Repeats the current song.



(repeat all): Repeats the all songs in current playlist.

\*1: A play mode icon glows when selected.


# Playing a USB Flash Drive

Your audio system reads and plays audio files on a USB flash drive in either format of MP3, WMA,  $AAC^{*1}$ , etc.

### Playable audio file P. 338

Connect your USB flash drive to the USB port, then select the USB mode.

# USB Ports P. 255



\*1:Only AAC format files recorded with iTunes are playable on this unit.

# How to Select a File from the Music Search List



- 1. Select Music Library.
- **2.** Select a search category (e.g., Artists, Albums, etc.).
- **3.** Continue making selections until you find the file of your choice.

#### ▶ Playing a USB Flash Drive

Use the recommended USB flash drives.

General Information on the Audio System P. 336

WMA files protected by digital rights management (DRM) cannot be played. The audio system skips to the next file.

If there is a problem, you may see an error message on the audio/information screen.

**iPod/USB Flash Drive** P. 332

Select **SEARCH** or **SEARCH LIST**, then trace the letters and/or numbers of the song on the A-zone touchpad. When **KEYBOARD** is selected, the onscreen keyboard appears.

# How to Select a Play Mode

You can select repeat and random modes when playing a file.



#### Random/Repeat

Repeatedly select the shuffle or repeat icon until you find a play mode option of your preference.

#### ➢How to Select a Play Mode

Play Mode Menu Items Random



(random off): Random mode to off.



(random in folder): Plays all files in current playlist.

#### Repeat



(repeat file): Repeats the current file.



\*1: A play mode icon glows when selected.

# Playing Bluetooth® Audio

Your audio system allows you to listen to music from your *Bluetooth*-compatible phone.

This function is available when the phone is paired and connected to the vehicle's *Bluetooth*<sup>®</sup> HandsFreeLink<sup>®</sup> (HFL) system.


Phone Setup P. 395

#### ➢Playing Bluetooth<sup>®</sup> Audio


Not all Bluetooth-enabled phones with streaming audio capabilities are compatible with the system. For a list of compatible phones:

- U.S.: Visit www.handsfreelink.com/Acura or call 1-888-528-7876.
- Canada: For more information on smartphone compatibility, call 1-855-490-7351.

It may be illegal to perform some data device functions while driving.



# To Play Bluetooth<sup>®</sup> Audio Files



#### connected to the system. Phone Setup P. 395 2. Select the Bluetooth® Audio mode.

If the phone is not recognized, another HFLcompatible phone, which is not compatible for Bluetooth® Audio, may already be connected.

**1.** Make sure that your phone is paired and

#### To Play Bluetooth® Audio Files

Only one phone can be used with HFL at a time. When more than one phone is paired to the vehicle, the first paired phone the system finds is automatically connected.

Different devices can be connected respectively to Bluetooth® hands-free phone and Bluetooth® Audio functions.

If more than one phone is paired to the HFL system, there may be a delay before the system begins to play.

In some cases, the name of the artist, album, or track may not appear correctly.

Some functions may not be available on some devices.

If a phone is currently connected via Apple CarPlay or Android Auto, *Bluetooth®* Audio from that phone will be unavailable. However, you can have a second previously paired phone stream *Bluetooth*<sup>®</sup> Audio by selecting () from the *Bluetooth*<sup>®</sup> device list.

Phone Setup P. 395

To play the audio files, you may need to operate your phone. If so, follow the phone maker's operating instructions.

Switching to another mode pauses the music playing from your phone.

You can change the connected phone by selecting MENU and Change Device. Phone Setup P. 395

# To play or pause a file

Select the play/pause icon.

# Searching for Music



# 1. Select Music Library.

2. Select a search category (e.g., Albums).

- 3. Select an item.
  - ► The selection begins playing.

#### Searching for Music

Depending on the *Bluetooth*<sup>®</sup> device you connect, some or all of the lists may not be displayed.

# **Wi-Fi Connection**

This vehicle is equipped with Wi-Fi connectivity. You can connect to an external Wi-Fi hotspot or communication device. In addition, the vehicle can be used by other communication devices as a Wi-Fi hotspot via the telematics unit (TCU).

- Connect the vehicle to a Wi-Fi hotspot
- Use Wi-Fi inside the vehicle

# Connect the vehicle to a Wi-Fi hotspot

Select Change Mode to en		
	Change Mode	

> XXXXXX AP		
•••••		
Show paseword		
🖸 Use this network	to automatically download A	cura updates
<ul> <li>Use this network</li> </ul>	to automatically rlownload A	cura updates

- 1. Press the 🕋 (home) button.
- 2. Select Settings.
- 3. Select Connections.
- 4. Select Wi-Fi.
- 5. Select Change Mode.
- 6. Select Network.
  - Select the access point you want to connect to the system.
  - When you change the mode from Hotspot to Network, a pop-up appears, then select Confirm.
- 7. Select Connect.
  - Enter a password for the access point.
  - When the connection is successful, Connected is displayed on the list.
- **8.** Press the (home) button to go back to the home screen.

#### ■Wi-Fi Connection

Wi-Fi and Wi-Fi Direct a registered trademark of Wi-Fi Alliance  $^{\otimes}.$ 



#### ■Connect the vehicle to a Wi-Fi hotspot

You cannot go through the setting procedure while the vehicle is moving. Park in a safe place to set the audio system in Wi-Fi mode.

Some cell phone carriers charge for tethering and smartphone data use. Check your phone's data subscription package.

Check your phone manual to find out if the phone has Wi-Fi connectivity.

You can confirm whether Wi-Fi connection is on or off with the r icon on the system status area. Transmission speed and others will not be displayed on this screen.

Status Area P. 274

In case of Wi-Fi connection with your phone, make sure your phone's Wi-Fi setting is in access point (tethering) mode.

# Use Wi-Fi inside the vehicle

You can set the network as a Wi-Fi Hotspot of this audio system. Use the following steps to set up.

Wi-Fi - Hotspot	Connected Devices List
Change Mode Hotspot or Network	
Network SSID	
Password	

- 1. Press the 🕋 (home) button.
- 2. Select Settings.
- 3. Select Connections.
- 4. Select Wi-Fi.
- 5. Select Change Mode.
- 6. Select Hotspot.
  - When you change the mode from Network to Hotspot, a pop-up appears, then select Confirm.

The following options are available for the setup.

- Network SSID: Set this network name.
- **Password**: Set a password to be required when connecting a Wi-Fi device to this network.
- **Connected Devices List**: Display the connected device list. Up to seven devices can be connected to this network.

# **AT&T Hotspot**

If you have subscribed to AT&T hotspot services, your vehicle will provide data to connect your mobile devices to the Internet. You can use the AT&T Hotspot app to turn on/off vehicle data and monitor data usage left on your subscription.

# AT&T Hotspot Menu



# Hotspot Enable

Turn on/off AT&T Hotspot.

# 2 Data Usage Bar

Check the current status of your data plan. This Usage Bar will show your current plan and how much data remains on your plan. Subscription plans for AT&T Hotspot can be added/modified at *www.att.com/acura*.

# 8 Plan Info

Shows your current AT&T subscription plan for the vehicle.

# 4 Settings

Shows the current username and password for vehicle Hotspot. **Settings** can be changed while the vehicle is not in motion.

# 6 Help

#### ≥AT&T Hotspot

To use AT&T Hotspot services, your vehicle must be subscribed to a data plan. If your vehicle is not subscribed to a data plan, you can visit *www.att.com/ acura* to add vehicle data services.

Hotspot username and password can be changed in the **Settings** of the AT&T Hotspot app. **Settings** cannot be accessed while driving. Park in a safe place to adjust Hotspot settings.

Alternatively, you can use your mobile hotspot to connect the vehicle and other mobile devices to the Internet.

Wi-Fi Connection P. 319

# **Apple CarPlay**

If you connect an Apple CarPlay-compatible iPhone to the system via the USB port in the console compartment or wirelessly, you can use the vehicle's audio/ information screen, instead of the iPhone, to make a phone call, listen to music, view maps (navigation), and access messages.

USB Ports P. 255



# Setting Up Apple CarPlay

Use of Apple CarPlay will result in the transmission of certain user and vehicle information (such as vehicle location, speed, and status) to your iPhone to enhance the Apple CarPlay experience. You will need to consent to the sharing of this information on the audio/information screen.

#### ➢Apple CarPlay

- USB connection of Apple CarPlay is supported by iOS 7.1 and higher.
- Wireless Apple CarPlay connection requires a iOS 9.0 and higher.

Park in a safe place before connecting your iPhone to Apple CarPlay and when launching any compatible apps.

While connected to Apple CarPlay, calls are only made through Apple CarPlay. If you want to make a call with *Bluetooth*<sup>®</sup> HandsFreeLink<sup>®</sup>, turn Apple CarPlay off.

Setting Up Apple CarPlay P. 322

When your iPhone is connected to Apple CarPlay, it is not possible to use the *Bluetooth*<sup>®</sup> Audio or *Bluetooth*<sup>®</sup> HandsFreeLink<sup>®</sup>. However, other previously paired phones can stream audio via *Bluetooth*<sup>®</sup> while Apple CarPlay is connected.

Phone Setup P. 395

Apple CarPlay and Android Auto cannot run at the same time.

For details on countries and regions where Apple CarPlay is available, as well as information pertaining to function, refer to the Apple homepage.

# Apple CarPlay Features



### • Phone

Access the contact list, make phone calls, or listen to voicemail.

• Music

Play music stored on your iPhone.

• Maps

Display Apple Maps and use the navigation function just as you would on your iPhone.

#### Models with navigation system

Only one navigation system (pre-installed navigation or Apple CarPlay) can give directions at a time. When you are using one system, directions to any prior destination set on the other system will be canceled, and the system you are currently using will direct you to your destination.

• Messages

Check and reply to text messages, or have messages read to you.

• Acura

Select the Acura icon to go back to the home screen.

• 📄

Go back to the Apple CarPlay Dashboard screen.

•

Go back to the Apple CarPlay menu screen.

#### ➢Apple CarPlay

# Apple CarPlay Operating Requirements & Limitations

Apple CarPlay requires a compatible iPhone with an active cellular connection and data plan. Your carrier's rate plans will apply.

Changes in operating systems, hardware, software, and other technology integral to providing Apple CarPlay functionality, as well as new or revised governmental regulations, may result in a decrease or cessation of Apple CarPlay functionality and services. Acura cannot and does not provide any warranty or guarantee of future Apple CarPlay performance or functionality.

It is possible to use 3rd party apps if they are compatible with Apple CarPlay. Refer to the Apple homepage for information on compatible apps.

# Enabling Apple CarPlay

- Connecting Apple CarPlay using the USB cable to the USB port in the console compartment
- **1.** Ensure Siri is enabled on your iPhone.
- 2. Connect the iPhone to the USB port using the USB cable.

#### USB Ports P. 255

- ▶ The confirmation screen will be displayed.
- 3. Select Enable Apple CarPlay.
  - ▶ If prompted on your device, click **Allow** to allow Apple CarPlay while your phone is locked.
    - You may change the consent settings under the **Connections** settings menu.

### Set up Apple CarPlay wirelessly by *Bluetooth*® pairing

- **1.** Ensure Siri is enabled on your iPhone.
- 2. Pair and connect the iPhone to the vehicle's *Bluetooth*<sup>®</sup> HandsFreeLink<sup>®</sup>.

#### Phone Setup P. 395

- **3.** A screen with option to select **Continue with Bluetooth** or **Change to CarPlay** is provided.
- 4. Select Change to CarPlay.
- **5.** Your iPhone will request your permission to accept wireless Apple CarPlay. Accept the request to complete setup.

#### ➢Enabling Apple CarPlay

You can use the method below to access **Apple CarPlay** settings. Here you can connect to/ disconnect from devices, delete a device or change permissions to enable or disable a device: Press the  $\frown$  (home) button  $\rightarrow$  Select Settings  $\rightarrow$ Connections  $\rightarrow$  Apple CarPlay  $\rightarrow$  Select device

#### Use of user and vehicle information


The use and handling of user and vehicle information transmitted to/from your iPhone by Apple CarPlay is governed by the Apple iOS terms and conditions and Apple's Privacy Policy.

#### Set up Apple CarPlay wirelessly on the home screen

- **1.** Ensure Siri is enabled on your iPhone.
- 2. Select Apple CarPlay on the home screen, then select Connect Phone.
- 3. Select + Connect New Device.
- 4. Start *Bluetooth*® pairing.
- 5. Select Enable Apple CarPlay on the disclaimer.
- **6.** Your iPhone will request your permission to accept wireless Apple CarPlay. Accept the request to complete setup.

# Operating Apple CarPlay with Siri

Press and hold the 🔬 (Talk) button to activate Siri.



#### 🔬 (Talk) Button:

Press and hold to activate Siri. Press again to deactivate Siri.

Press and release to activate standard voice recognition system.

#### ➢Operating Apple CarPlay with Siri

Below are examples of questions and commands for Siri:

- What movies are playing today?
- Call dad at work.
- What song is this?
- How's the weather tomorrow?
- Read my latest email.
- Find a table for four tonight in Chicago.

For more information, please visit www.apple.com/ios/siri.

# Android Auto™

When you connect an Android phone to the audio system via the USB port in the console compartment or wirelessly, Android Auto is automatically initiated. When connected via Android Auto, you can use the vehicle's audio/information screen to access the Phone, Maps, Music, and messaging features other supported apps in your Android phone.

- USB Ports P. 255
- Android Auto Setup P. 329



#### Mandroid Auto™

Android Auto connection requires the following:

- Depending on the phone manufacturer, Android 8.0, 9.0 or 10.0.
- Android Auto app version 4.7 or higher. For Wireless Android Auto
- A Google-branded or Samsung-branded phone with Android 10.0, or;
- A smartphone with Android 11.0+ and with 5 GHz WiFi. Can be any smartphone brand.

Park in a safe place before connecting your Android phone to Android Auto and when launching any compatible apps.

To use Android Auto, connect the USB cable to the USB port located in the console compartment. The USB ports located on the front panel and the back of the console compartment<sup>\*</sup> are used only for charging.

**USB Ports** P. 255

When your Android phone is connected to Android Auto, it is not possible to use the *Bluetooth®* Audio. However, other previously paired phones can stream audio via *Bluetooth®* while Android Auto is connected.

Phone Setup P. 395

Apple CarPlay and Android Auto cannot run at the same time.

Android Auto is a trademark of Google LLC.

## Android Auto Features



#### • Maps

Display Google Maps and use the navigation function just as you would with your Android phone. When the vehicle is in motion, it is not possible to make keyboard entries. Stop the vehicle in a safe location to undertake a search or provide other inputs.

#### Models with navigation system

Only one navigation system (pre-installed navigation or Android Auto) can give directions at a time. When you are using one system, directions to any prior destination set on the other system will be canceled, and the system you are currently using will direct you to your destination.

The audio/information screen shows you turn-by-turn driving directions to your destination.

#### • Phone

Make and receive phone calls as well as listen to voicemail.

#### • Exit

Select the **Exit** icon to go back to the home screen.

#### Mandroid Auto™

For details on countries and regions where Android Auto is available, as well as information pertaining to function, refer to the Android Auto homepage.

Screens may differ depending on the version of the Android Auto app you are using.

# Android Auto Operating Requirements & Limitations

Android Auto requires a compatible Android phone with an active cellular connection and data plan. Your carrier's rate plans will apply.

Changes in operating systems, hardware, software, and other technology integral to providing Android Auto functionality, as well as new or revised governmental regulations, may result in a decrease or cessation of Android Auto functionality and services. Acura cannot and does not provide any warranty or guarantee of future Android Auto performance or functionality.

It is possible to use 3rd party apps if they are compatible with Android Auto. Refer to the Android Auto homepage for information on compatible apps.

# • U Operate Android Auto with your voice.

۰

You can check Android notifications.

• (Android Auto Home) Display useful information organized by Android Auto into simple cards that appear just when they're needed.

# Android Auto Setup

When you connect an Android phone to the unit via the USB port in the console compartment or wirelessly, Android Auto is automatically initiated. Before setting up a connection, ensure that the Android Auto app is closed on the phone.

## ■ Connecting Android Auto using the USB cable to the USB port

To enable Android Auto after connecting an Android phone to the system, select **Enable Android Auto** on the screen.

You may change the consent settings under the **Connections** settings menu.

## Set up Android Auto wirelessly by Bluetooth<sup>®</sup> pairing

- 1. Pair and connect the Android phone to the vehicle's Bluetooth<sup>®</sup> HandsFreeLink<sup>®</sup>. ▶ Phone Setup P. 395
- 2. A privacy policy statement will appear. Select Change to Android Auto.
- **3.** Your phone will display various screens that request your permissions needed for Android Auto. Accept the requests to complete setup.

#### ≥Android Auto Setup

Only initialize Android Auto when you safely parked. When Android Auto first detects your phone, you will need to set up your phone so that auto pairing is possible. Refer to the instruction manual that came with your phone.

You can use the method below to change Android Auto settings after you have completed the initial setup:

Press the (home) button  $\rightarrow$  Select Settings  $\rightarrow$  Connections  $\rightarrow$  Android Auto  $\rightarrow$  Select device

## Use of user and vehicle information


The use and handling of user and vehicle information transmitted to/from your phone by Android Auto is governed by the Google's Privacy Policy.

#### Set up Android Auto wirelessly on the home screen

- 1. Select Android Auto on the home screen, then select Connect Phone.
- 2. Select + Connect New Device.
- 3. Start Bluetooth® pairing.
- 4. A privacy policy statement will appear. Select Enable Android Auto.
- **5.** Your phone will display various screens that request your permissions needed for Android Auto. Accept the requests to complete setup.

# Operating Android Auto with Voice Recognition

Press and hold the 🔬 (Talk) button to operate Android Auto with your voice.



## 🔬 (Talk) Button:

Press and hold to operate Android Auto with your voice. Press and release to activate standard voice recognition system.

#### Derating Android Auto with Voice Recognition

Below are examples of commands you can give with voice recognition:

- Reply to text.
- Call my wife.
- Navigate to Acura.
- Play my music.
- Send a text message to my wife.
- Call flower shop.

For more information, please refer to the Android Auto homepage.

You can also activate the voice recognition function by selecting the  $\boxed{\bigcirc}$  icon in the lower-left corner of the screen.

# iPod/USB Flash Drive

If an error occurs while playing an iPod or USB flash drive, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message	Solution
USB Error	Appears when an incompatible device is connected. Disconnect the device. Then, turn the audio system off and turn it on again. Do not reconnect the device that caused the error. <b>iPod</b> Appears when an unsupported iPod is connected. If it appears when a supported iPod is connected, update the iPod software to the newer version. <b>USB flash drive</b> Appears when an unsupported device is connected. If it appears when a supported device is connected, update the device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a supported device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support device is connected. If it appears when a support dev
The selected file cannot be played on this system	Appears when the files in the USB flash drive are copyright protected or an unsupported format.
No Data	<ul> <li>iPod</li> <li>Appears when the iPod is empty.</li> <li>USB flash drive</li> <li>Appears when the USB flash drive is empty.</li> <li>iPod and USB flash drive</li> <li>Check that compatible files are stored on the device.</li> </ul>
USB Hub Error	Appears when the USB hub with plural USB devices is connected. Disconnect the USB hubs and directly connect the device to the USB port using the extension cable.

# Android/Apps

If an error occurs while using the audio system or apps, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message	Solution
Unfortunately, **** has stopped.*1	Error has occurred within app, select <b>OK</b> on the screen to close the app.
**** isn't responding. Do you want to close it?*1	App is not responding. Select Wait if you can wait for a response from app a little longer. If it does not respond even if you keep waiting, select OK to close the app and start it up. If the error message continues, perform Factory Data Reset.

\*1:\*\*\*\*part is variable characters, and will change depending upon where an error occurs.

# Apple CarPlay/Android Auto

If an error occurs while using the Apple CarPlay or Android Auto, you may see the following error messages. If you cannot clear the error message, contact a dealer.

Error Message	Solution	
Error	Appears when Apple CarPlay or Android Auto fails to recognize your device. Check if your device is compatible with Apple CarPlay or Android Auto, or the latest version of the app is installed on your device.	
Maximum Number of Apple CarPlay Devices Exceeded	Appears when the number of stored Apple CarPlay devices or Android Auto devices exceeds the limitation. Select <b>Replace and Continue</b> and delete a registered device to connect a new device for the Apple CarPlay connection or Android Auto connection.	
Maximum Number of Android Auto Devices Exceeded		
Phone Call Active	Appears when the Android Auto device becomes connected to USB during an active <i>Bluetooth</i> <sup>®</sup> hands-free phone call.	
(connected device name) <b>Disconnected</b>	Appears when the paired device is disconnected from the HFL function. Reconnect device and try again.	
Maximum Number of Bluetooth Devices Exceeded	Appears when the number of stored <i>Bluetooth</i> <sup>®</sup> devices exceeds the limitation. Select <b>Replace and Continue</b> and delete a registered device to connect a new device for the <i>Bluetooth</i> <sup>®</sup> connection.	
Bluetooth Connection Error	Appears when <i>Bluetooth</i> <sup>®</sup> connection is failed. Check the <i>Bluetooth</i> <sup>®</sup> connection of this audio system and your connected device.	

Error Message	Solution
Android Auto – SSL Authentication Failure Set the vehicle date and time to match the device.	Set the vehicle date to match the device.
Wireless connection problem in Android Auto – Android Auto Connection Unstable	Temporarily connect the device to the USB data port or try and bring the device to front of the vehicle.
Wireless connection problem in Android Auto – Temporarily connect the device to the USB data port.	Failing to connect or disconnects randomly. Temporarily connect the device to the USB data port.
Android Auto – Bluetooth Connection Error	Reconnect Android Auto device and try again.
Unable to start Android Auto from the connected device.	There could be many possible reasons for this error but updating Android Auto app on the phone and google play services could solve the problem. Other solution include deleting saved phone information from the vehicle and deleting vehicle information from the phone's <i>Bluetooth</i> <sup>®</sup> list and setting up a new connection.

# SiriusXM<sup>®</sup> Radio Service

# Subscribing to SiriusXM<sup>®</sup> Radio

- **1.** You need your radio ID ready before registering for subscription. To see the ID in the screen, select channel up/down icons to Ch.0.
- **2.** Have your radio ID ready, and either call or visit the SiriusXM<sup>®</sup> website to subscribe.

# Receiving SiriusXM<sup>®</sup> Radio

Switch to the SiriusXM<sup>®</sup> mode by using the audio remote controls on the steering wheel, or through the audio/information screen, and stay in this mode for about 30 minutes until the service is activated. Make sure your vehicle is in an open area with good reception.

# SiriusXM<sup>®</sup> Radio Display Messages

## Channel \*\*\*\* not subscribed. Call SiriusXM to subscribe.\*1

You are not subscribed to the channel selected.

#### Subscription updated:

SiriusXM® radio is receiving information update from the network.

## **Channel Not Available:**

No such channel exits, or the artist or title information is unavailable.

## No Signal:

The signal is too weak in the current location.

## **Check Tuner:**

There is a problem with the SiriusXM<sup>®</sup> tuner. Contact a dealer.

## Check Antenna:

There is a problem with the SiriusXM® antenna. Contact a dealer.

\*1: \*\*\*\*part is variable characters, and will change depending upon where an subscribe.

#### Subscribing to SiriusXM<sup>®</sup> Radio

Contact Information for SiriusXM® Radio:

- US: SiriusXM® Radio at www.siriusxm.com/subscribenow, or 1-866-635-2349
- Canada: SiriusXM<sup>®</sup> Canada at www.siriusxm.ca/subscribe-now, or 1-877-209-0079

#### ➢Receiving SiriusXM<sup>®</sup> Radio

The SiriusXM® satellites are in orbit over the equator; therefore, objects south of the vehicle may cause satellite reception interruptions. Satellite signals are more likely to be blocked by tall buildings and mountains the farther north you travel from the equator.

You may experience reception problems under the following circumstances:

- In a location with an obstruction to the south of your vehicle.
- In tunnels
- On the lower level of a multi-tiered road
- Large items carried on the roof rack

# Compatible iPod, iPad, iPhone, and USB Flash Drives

# I iPod, iPad, and iPhone Model Compatibility

Model

Made for iPod touch (7th generation)/iPod touch (6th generation)

Made for iPhone SE (2nd generation)/iPhone 11 Pro Max/iPhone 11 Pro/iPhone 11/ iPhone XS Max/iPhone XS/iPhone XR/iPhone X/iPhone 8 Plus/iPhone 8/iPhone 7 Plus/iPhone 7/iPhone SE (1st generation)/iPhone 6s Plus/iPhone 6s/iPhone 6 Plus/ iPhone 6/iPhone 5s

Made for iPad (7th generation)/iPad (6th generation)/iPad (5th generation)

Made for iPad Pro (10.5-inch)/iPad Pro 12.9-inch (2nd generation)/iPad Pro (12.9-inch)/iPad Pro (9.7-inch)

Made for iPad Air (3rd generation)/iPad Air 2/iPad Air

Made for iPad mini (5th generation)/iPad mini 4/iPad mini 3/iPad mini 2

#### ➢iPod, iPad, and iPhone Model Compatibility

This system may not work with all software versions of these devices.

The Lightning connector works with iPhone SE (2nd generation), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 6, iPhone 6 S, iPhone 6 Plus, iPhone 6, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone 5s, iPad Pro (10.5-inch), iPad Pro 12.9-inch (2nd generation), iPad Pro (12.9-inch), iPad Pro (9.7-inch), iPad Air (3rd generation), iPad Air 2, iPad Air, iPad (7th generation), iPad mini (5th generation), iPad mini 4, iPad mini 3, iPad mini 2, iPod touch (7th generation), iPod touch (6th generation).

USB works with iPhone SE (2nd generation), iPhone 11 Pro Max, iPhone 11 Pro, iPhone 11, iPhone XS Max, iPhone XS, iPhone XR, iPhone X, iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE (1st generation), iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone 5s, iPad Pro (10.5-inch), iPad Pro 12.9-inch (2nd generation), iPad Pro (12.9-inch), iPad Pro (9.7-inch), iPad Air (3rd generation), iPad Air 2, iPad Air, iPad (7th generation), iPad (6th generation), iPad (5th generation), iPad mini 2, iPod touch (7th generation), iPod touch (6th generation).

## USB Flash Drives

- A USB flash drive of 256 MB or higher is recommended.
- Some digital audio players may not be compatible.
- Some USB flash drives (e.g., a device with security lockout) may not work.
- Some software files may not allow for audio play or text data display.
- Some versions of playable file formats may be unsupported.

#### ■ Playable audio file

Format/Codec	File Type(s)	
AAC LC	3GPP (.3gp), MPEG-4 (.mp4, .m4a),	
HE-AACv1 (AAC+)	ADTS raw AAC (.aac, decode in Android	
HE-AACv2 (enhanced AAC+)	3.1+, encode in Android 4.0+, ADIF not	
AAC ELD (enhanced low delay AAC)	supported), MPEG-TS (.ts, not seekable, Android 3.0+)	
AMR-NB	– 3GPP (.3gp)	
AMR-WB		
FLAC	FLAC (.flac) only	
MIDI	Type 0 and 1 (.mid, .xmf, .mxmf), RTTTL/ RTX (.rtttl, .rtx), OTA (.ota), iMelody (.imy)	
MP3	MP3 (.mp3)	
Opus	Matroska (.mkv)	
PCM/WAVE	WAVE (.wav)	
Vorbis	Ogg (.ogg), Matroska (.mkv, Android 4.0+)	

#### ≫USB Flash Drives

Files on the USB flash drive are played in their stored order. This order may be different from the order displayed on your PC or device.

# Honda App License Agreement

## END USER LICENSE AGREEMENT

PLEASE CAREFULLY READ THIS END USER LICENSE AGREEMENT (THIS "AGREEMENT") WHICH GOVERNS YOUR USE OF THE SOFTWARE INSTALLED ON YOUR HONDA OR ACURA VEHICLE (YOUR "VEHICLE") AS WELL AS THE APPLICATIONS, SERVICES, FUNCTIONS, AND CONTENT PROVIDED THROUGH THE SOFTWARE (COLLECTIVELY, THE "SERVICES"). YOUR USE OF THE SOFTWARE OR SERVICES WILL SERVE AS YOUR CONSENT TO THE TERMS OF THIS AGREEMENT. THE SOFTWARE IS OWNED (OR LICENSED), PROVIDED, AND/OR OPERATED BY AMERICAN HONDA MOTOR CO. INC., ("HONDA," "US," "WE," OR "OUR"), WITH ITS BUSINESS ADDRESS AT 1919 TORRANCE BLVD., TORRANCE, CA 90501. REFERENCE TO "HONDA" IN THIS AGREEMENT INCLUDES HONDA'S PARENT COMPANY AND ITS AFFILIATES AND DESIGNATED AGENTS. THE SERVICES ARE OWNED (OR LICENSED), PROVIDED, AND/OR OPERATED BY HONDA OR A THIRD-PARTY SERVICE PROVIDER (A "PROVIDER"). REFERENCE TO A "PROVIDER" IN THIS AGREEMENT INCLUDES SUCH PROVIDER'S PARENT COMPANY, AFFILIATES, AND DESIGNATED AGENTS.

**A. Description of the Software.** The SOFTWARE includes the software, firmware and the like, installed and executing on your VEHICLE during manufacture, and thereafter updated from time to time by HONDA, you or an authorized HONDA dealer (a "DEALER"). The SOFTWARE allows you to access and use a variety of SERVICES, including but not limited to: (a) HONDA applications, services, and content provided through the SOFTWARE (together, "HONDA SERVICES"); and (b) PROVIDER applications, services, and content provided through the SOFTWARE (together, "PROVIDER SERVICES"), each of which may provide access to various information, media, content, and services.

#### **B. SOFTWARE Licensing and Intellectual Property.**

**1. SOFTWARE.** This AGREEMENT grants you a non-exclusive, limited, and revocable license to use the SOFTWARE and SERVICES solely (a) as installed on your VEHICLE by HONDA, (b) as updated on your Vehicle by HONDA, you (but only as and when directed by HONDA), or a DEALER and (c) as permitted under the terms of this AGREEMENT.

**2. HONDA Services.** The SOFTWARE may provide you with access to various HONDA SERVICES. Installation, activation, or use of HONDA SERVICES may require your consent to additional terms, conditions, and privacy policies applicable to those HONDA SERVICES (the "HONDA TERMS"). You acknowledge and agree that any collection, use, sharing of data generated by your VEHICLE or your use of your VEHICLE, and your use of the HONDA SERVICES shall be subject to this AGREEMENT and any additional HONDA TERMS that may be specifically applicable to such HONDA SERVICES or data generation. The HONDA SERVICES may collect, use, and share such data while you are using the SOFTWARE.

**3. Open-Source Software.** The SOFTWARE and SERVICES may incorporate software licensed to HONDA under free or open-source licenses which govern HONDA's distribution and your use of such software. HONDA and the third-party authors, licensors, and distributors of such software disclaim all warranties and all liability arising from any and all use or distribution of the software. To the extent such software is provided under terms that differ from the applicable free or open-source licenses, those terms are offered by HONDA alone. Additional information regarding free and open-source software incorporated in the SOFTWARE and SERVICES is available in this manual or within the SOFTWARE.

**4. Provider Services.** The SOFTWARE may provide you with access to various PROVIDER SERVICES. Installation or use of such PROVIDER SERVICES may require your consent to additional terms, conditions, and privacy policies of the applicable PROVIDER (the "PROVIDER TERMS"). This AGREEMENT restricts the manner in which you can install and use PROVIDER SERVICES but does not grant you a license or permission to use such PROVIDER SERVICES. Your permission to use PROVIDER SERVICES is limited and subject to any license grants, conditions, and limitations included in the PROVIDER TERMS. You acknowledge that any collection, use, sharing of your information, targeted advertising practices by PROVIDERS, and your use of the PROVIDER SERVICES shall be subject to both this AGREEMENT and any applicable PROVIDER TERMS. The PROVIDER SERVICES may collect, use, and share such information while you are using the SOFTWARE.

#### 5. License Limitations and Restrictions on Use.

(a) <u>Limited License</u>. You understand and agree that the SOFTWARE and SERVICES are licensed, not sold, to you solely for use in accordance with this AGREEMENT and any applicable PROVIDER TERMS, and any documentation for the VEHICLE made available to you by HONDA (any "DOCUMENTATION"). HONDA and its licensors reserve all rights in the SOFTWARE and HONDA SERVICES not expressly granted to you under this AGREEMENT. PROVIDERS and their licensors reserve all rights in the PROVIDER SERVICES not expressly granted to you under the applicable PROVIDER TERMS.

(b) <u>Restrictions on Use</u>. The licenses granted under this AGREEMENT do not permit you to use the SOFTWARE or SERVICES on a device other than your VEHICLE. As a condition of using the SOFTWARE and SERVICES, you agree that you may not and will not:

(1) copy, download, distribute, modify, publish, sell, rent, lease, lend, license, sublicense, reuse, or create derivative works of the SOFTWARE or SERVICES or any of the content or other material within the SOFTWARE or SERVICES, including without limitation, HONDA or PROVIDER names, logos, or any other trademarks of HONDA or PROVIDERS or used in association with the SOFTWARE or any SERVICES, except as required to use the SOFTWARE or SERVICES in accordance with this AGREEMENT, any applicable PROVIDER TERMS, and the DOCUMENTATION;

(2) access or use the SOFTWARE or SERVICES in any manner intended to damage or impair the operation of the SOFTWARE or SERVICES or interfere with anyone else's use and enjoyment of the SOFTWARE or SERVICES;

(3) access or attempt to access any system or server on which the SOFTWARE or SERVICES is hosted or modify or alter the SOFTWARE or SERVICES in any way;

(4) use the SOFTWARE or SERVICES for any unlawful purpose, or in violation of any third party rights;

(5) use the SOFTWARE or SERVICES in violation of any applicable traffic regulations, rules or laws, including but not limited to any driver distraction laws, rules or regulations;

(6) violate the terms of this AGREEMENT, any HONDA TERMS, any PROVIDER TERMS or other applicable third-party terms, conditions, and privacy policies; or

(7) reverse engineer, decompile, disassemble, attempt to derive the source code of, nor permit others to reverse engineer, decompile, or disassemble, or attempt to derive the source code of the SOFTWARE or SERVICES, except and only to the extent that such activity is expressly permitted (a) by applicable law notwithstanding this limitation or (b) the terms of applicable free or opensource software licenses.

**6. Intellectual Property Rights.** All title and intellectual property rights in and to the SOFTWARE and SERVICES, the accompanying DOCUMENTATION, and all copies of the SOFTWARE or SERVICES are owned by HONDA, PROVIDERS, or their suppliers or licensors. This AGREEMENT does not grant you any rights in connection with any trademarks or service marks of HONDA, PROVIDERS, or their licensors, affiliates, or suppliers.

**7. Export Restrictions:** You acknowledge that the SOFTWARE and SERVICES are subject to U.S., European Union, and other export jurisdictions. You agree to comply with all applicable international and national laws that apply to the SOFTWARE and SERVICES, including the U.S. Export Administration Regulations, as well as end-user, end-use, and destination restrictions issued by the U.S. and other governments.

### **C. SOFTWARE Operation**

**1.** HONDA reserves the right to suspend or terminate your access to and use of the SOFTWARE or SERVICES if you are found to be in violation of this AGREEMENT or as reasonably deemed necessary by HONDA.

**2.** <u>Eligibility/Registration/Activation</u>. The SOFTWARE is intended for and available to individuals who (a) are of legal age of majority in their jurisdiction of residence (and at least 18 years of age), or are younger than 18 years of age and possess a valid driver's license issued by their jurisdiction of residence, and (b) own or have permissive access to a compatible VEHICLE. We do not knowingly collect any information, including personal information, from children under 13. If we learn or are notified that we have collected personal information of a child under 13, we will immediately take steps to delete such information.

**3.** <u>Use of PROVIDER SERVICES through the SOFTWARE.</u> Certain PROVIDER SERVICES made available through the SOFTWARE may require that you register or otherwise have an account with the PROVIDER and agree to PROVIDER TERMS. Any use of any of such PROVIDER SERVICES within the SOFTWARE is subject to this AGREEMENT and the applicable PROVIDER TERMS. HONDA does not exercise control over such PROVIDER SERVICES and is not responsible or liable for the availability, security, or content of such PROVIDER SERVICES, and the inclusion of any PROVIDER SERVICES does not imply a referral from, the approval of, or the endorsement by HONDA of such PROVIDER SERVICES. HONDA is not responsible or liable, directly or indirectly, for any damage relating to or resulting from your use of the PROVIDER SERVICES.</u>

**4.** <u>Links to Third Party Sites</u>: The SOFTWARE may provide you with the ability to access third-party sites and content through the use of the SOFTWARE or SERVICES. The third-party sites and content are not under the control of HONDA. HONDA is not responsible or liable, directly or indirectly, for such third-party websites and their content or for any damage relating to or resulting from your access or use of such websites and content.

**5.** <u>Unauthorized Use and Abuse.</u> You are responsible for ensuring your (and any authorized third parties') use of the SOFTWARE and SERVICES remains in compliance with this AGREEMENT and all other applicable HONDA TERMS and PROVIDER TERMS. You acknowledge and agree that any use of the SOFTWARE or SERVICES occurring through your VEHICLE will be deemed your actions and that HONDA and PROVIDERS may rely upon such actions. You agree to immediately notify us if you suspect fraudulent or abusive activity involving the SOFTWARE or SERVICES. If you so notify us or if we otherwise suspect fraudulent or abusive activity, you agree to cooperate with us in any fraud investigation and to use any fraud prevention measures we prescribe. Your failure to immediately notify us or cooperate to use such measures will result in your liability for all fraudulent usage or abusive activity associated with your VEHICLE.

**6.** <u>SOFTWARE Updates</u>. The SOFTWARE and SERVICES may be updated when your VEHICLE is serviced by a DEALER or remotely, over-theair, by HONDA from time to time; such updates may occur with or without further notice or your future consent. The SOFTWARE may be updated at HONDA's discretion and for any purpose including, without limitation, to patch or otherwise improve the SOFTWARE or SERVICES functionality, security, or stability. All updates to the SOFTWARE and SERVICES are subject to this AGREEMENT and any other applicable HONDA TERMS and PROVIDER TERMS.

7. <u>Uninstalling</u>, <u>Removing</u>, and <u>Replacing the SOFTWARE</u>. Replacing SOFTWARE or HONDA SERVICES with software or firmware not provided and installed by HONDA or a DEALER will render all representations and warranties for the SOFTWARE, HONDA SERVICES, and VEHICLE functionality reliant upon the SOFTWARE or HONDA SERVICES null and void.

#### **D. SOFTWARE Operational Notices and Warnings**

1. <u>Vehicle Geolocation Information</u>. You acknowledge that your VEHICLE may be equipped with certain traffic and map features. The traffic feature will automatically collect and transmit, through GPS technology, your Vehicle's current location (longitude and latitude), travel direction and speed ("VEHICLE GEOLOCATION INFORMATION") to HONDA and PROVIDERS. The VEHICLE GEOLOCATION INFORMATION") to HONDA and PROVIDERS. The VEHICLE GEOLOCATION INFORMATION") to HONDA and PROVIDERS. The VEHICLE GEOLOCATION INFORMATION is used by HONDA and PROVIDERS to provide traffic and navigation-related information to you, but may also be used to provide other SERVICES or offers to you. HONDA will not use such VEHICLE GEOLOCATION INFORMATION for its own marketing efforts, or provide such information to unaffiliated third parties for their own purposes, without your express consent.

**2.** <u>Potential Map Inaccuracy and Route Safety.</u> Maps used by this system may be inaccurate because of changes in roads, traffic controls, routing, or driving conditions. Always use good judgment and common sense when following suggested routes. Do not follow the route suggestions if doing so would result in an unsafe or illegal driving maneuver, if you would be placed in an unsafe situation, or if you would be directed into an area that you consider unsafe. Do not rely on any navigation features included in the system to route you to emergency services. Not all emergency services such as police, fire stations, hospitals, or clinics are likely to be contained in the map database for such navigation features. Ask local authorities or an emergency services operator for such locations and routes. The driver is ultimately responsible for the safe operation of the vehicle and therefore, must evaluate whether it is safe to follow the suggested directions. Any navigation features are provided only as an aid. Make your driving decisions based on your observations of local conditions and existing traffic regulations. Navigation features are not a substitute for your personal judgment. Any route suggestions made by the SOFTWARE or SERVICES should never replace any local traffic regulations or your personal judgment or knowledge of safe driving practices.

**3.** <u>Speech Recognition</u>: You acknowledge and understand that HONDA and PROVIDERS may record, retain, and use voices commands when you use the speech recognition components of the SOFTWARE or SERVICES. You and all VEHICLE operators and passengers (a) consent to the recording and retention of voice commands in support of providing speech recognition components and (b) release HONDA and PROVIDERS from all claims, liabilities, and losses that may result from any use of such recorded voice commands. Recognition errors are inherent in speech recognition. It is your responsibility to monitor any speech recognition functions included in the system and address any errors. Neither HONDA nor PROVIDERS will be liable for any damages arising out of errors in the speech recognition process.

**4.** <u>Distraction Hazards.</u> Navigation features may require manual (non-verbal) input or setup. Attempting to perform such set-up or insert data while driving can seriously distract your attention and could cause a crash or other serious consequences; the ability to undertake such interactions may also be limited by state or local law, which laws you are responsible to know and follow. Even occasional short scans of the screen may be hazardous if your attention has been diverted away from your driving at a critical time. Pull over and stop the vehicle in a safe and legal manner before attempting to access a function of the system requiring prolonged attention. Do not raise the volume excessively. Keep the volume at a level where you can still hear outside traffic and emergency signals while driving. Driving while unable to hear these sounds could result in a crash.

#### E. Information Collection and Storage

1. Information Collection, Use, Transmission and Storage of Data. Consent to Use of Data: You agree that HONDA and PROVIDERS may collect and use your information gathered in any manner as part of product support services related to the SOFTWARE or related services. HONDA may share such information with third parties, including, without limitation, PROVIDERS, third party software and services suppliers, their affiliates and/or their designated agents, solely to improve their products or to provide services or technologies to you. HONDA, third party software and systems suppliers, their affiliates and/or their affiliates and/or their designated agent may disclose this information to others, but not in a form that personally identifies you.

**2.** <u>Information Storage.</u> Depending on the type of multimedia system you have in your VEHICLE, certain information may be stored for ease of use of the SOFTWARE including, without limitation, search history, location history in certain applications, previous and saved destinations, map locations within certain applications, and device numbers and contact information.

(a) <u>Vehicle Health Information</u>. Your VEHICLE may remotely transmit information regarding the status and health of your VEHICLE ("VEHICLE INFORMATION") to HONDA without notification to you. VEHICLE INFORMATION may contain VEHICLE maintenance and malfunction status that is derived from VEHICLE diagnostic data and includes, but is not limited to, status of powered doors and windows, battery life data, battery charging data, VEHICLE speed, coolant temperature, air compressor revolution, output power, warning codes, diagnostic trouble codes, fuel injection volume, and engine rotations per minute. VEHICLE HEALTH INFORMATION may be used by HONDA for research and development, to deliver HONDA SERVICES and information to you, and to contact you, and is retained only for a period of time necessary to fulfill these goals.

(b) <u>VEHICLE Geolocation Data (non-navigation/map based)</u>. If you opt-in to geolocation-based SERVICES, your vehicle's geolocation data (latitude and longitude) will be automatically sent from your VEHICLE to HONDA and PROVIDERS.

(c) You understand that the inputting or uploading of information to your VEHICLE's multimedia system or the SOFTWARE or SERVICES is at your own risk and that HONDA is not responsible for unauthorized access to or use of any personal or other information. All information uploaded to the SOFTWARE and SERVICES may be stored on your VEHICLES's multimedia system and you understand that the security and safety of your VEHICLE's multimedia system is your sole responsibility. F. NO WARRANTY. You understand and agree that your use of the SOFTWARE and SERVICES are solely at your own risk and that you will be solely responsible for any damage to your VEHICLE's multimedia system or any other equipment or any loss of data that may result from your use of the SOFTWARE or SERVICES. THE SOFTWARE AND SERVICES ARE PROVIDED ON AN "AS IS" AND "AS AVAILABLE" BASIS WITHOUT ANY WARRANTY OF ANY KIND. EXPRESSED. IMPLIED OR STATUTORY. WE SPECIFICALLY DISCLAIM ANY IMPLIED WARRANTIES. OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT. HONDA makes no warranties that the SOFTWARE or SERVICES will meet your requirements, or that the SOFTWARE or SERVICES will be uninterrupted, timely, secure, noninfringing or error free. You understand and agree that you are responsible for any and all charges, costs or expenses associated with your use of the SOFTWARE or SERVICES. Advice or information, whether oral or written, obtained by you from us or through the SOFTWARE or SERVICES are provided for informational purposes only and will not create any warranty not expressly made herein. You should not rely on any such information or advice. We assume no liability or responsibility for any errors or omissions in the SOFTWARE or SERVICES. We do not make any warranty or representation that your use of the material displayed on, or obtained through, the SOFTWARE or SERVICES is non-infringing of any rights of any third party. Any decision or action taken by you on the basis of information or content provided via the application is at your sole discretion and risk. HONDA and PROVIDERS are not responsible or liable for any such decision, or for the accuracy, completeness, usefulness, or availability of any content or information displayed, transmitted, or otherwise made available via the SOFTWARE or SERVICES. To the extent jurisdictions do not allow the exclusion of certain warranties, some of the above exclusions may not apply to you.

#### G. LIMITATIONS ON LIABILITY. You and HONDA are each waiving important rights.

1. <u>Limitations on YOUR liability</u>. HONDA cannot recover from you any consequential, indirect, incidental, or special damages, or attorney's fees in connection with your use of the SOFTWARE or HONDA SERVICES. HONDA WAIVES TO THE FULLEST EXTENT ALLOWED BY LAW ANY CLAIM FOR DAMAGES OTHER THAN DIRECT, COMPENSATORY DAMAGES AS LIMITED IN THIS AGREEMENT.

2. Limitation on HONDA and PROVIDER liability. Neither HONDA nor PROVIDERS will be liable to you or any other party for consequential, indirect, incidental, special, or punitive damages (including without limitation lost profits) in connection with your use of the SOFTWARE or SERVICES, even if HONDA or PROVIDERS are aware of the possibility of such damages. These limitations apply to all claims, including, without limitation, claims in contract and tort (such as negligence, product liability and strict liability). To the extent that a jurisdiction does not permit the exclusion or limitation of liability as set forth herein our liability is limited to the maximum extent permitted by law in such states. If HONDA or PROVIDERS are found liable to you for any reason, you agree that the aggregate liability of all these parties to you for any claim is limited to ten U.S. dollars (US \$10.00). Neither HONDA nor any PROVIDER would have agreed to provide the SOFTWARE or SERVICES to you if you did not agree to this limitation. This amount is the sole and exclusive liability of HONDA and PROVIDERS to you, and is payable as liquidated damages and not as a penalty. Except where prohibited by law, you may not bring any claim against HONDA or any third-party beneficiary more than two (2) years after the claim arises. We do not have any liability for SOFTWARE or SERVICES interruptions of any length.

(a) <u>Release of HONDA and PROVIDERS</u> For yourself and anyone else claiming under you, you agree to release and discharge HONDA, PROVIDERS, their respective officers, directors, and employees, and each third-party beneficiary from all claims, liabilities and losses in connection with the SOFTWARE or SERVICES, including, but not limited to claims for personal injury or property damage arising from the total or partial failure of performance of the SOFTWARE or SERVICES, even if caused by or based upon the negligence, gross negligence, strict products liability, Deceptive Trade Practices Act violations, bad faith, or breach of warranty of us or the malfunction of the SOFTWARE or SOFTWARE SERVICES. YOU AGREE TO WAIVE TO THE FULLEST EXTENT ALLOWED BY LAW, ANY CLAIM FOR DAMAGES OTHER THAN DIRECT, COMPENSATORY DAMAGES AS LIMITED IN THIS AGREEMENT. YOU HEREBY RELEASE AND DISCHARGE HONDA AND ITS LICENSORS AND CONTRACTORS (INCLUDING ANY THIRD PARTIES PROVIDING ALL OR PART OF THE SOFTWARE OR SERVICES) FROM AND AGAINST ANY CLAIMS, DAMAGES, EXPENSES AND LIABILITY ARISING FROM OR RELATED TO ANY INJURIES, DAMAGES, OR LOSSES TO ANY PERSON (INCLUDING DEATH) OR PROPERTY OF ANY KIND RESULTING IN WHOLE OR PART, DIRECTLY OR INDIRECTLY, FROM YOUR USE OF THE SOFTWARE OR SERVICES.

**H. Survival.** You agree that the limitations of liability and indemnities in this AGREEMENT will survive even after the AGREEMENT has ended. These limitations of liability apply not only to you, but to anyone using the SOFTWARE or SERVICES via your VEHICLE, to anyone making a claim on your behalf, and to any claims made by your family, employees, customers, or others arising out of or relating to your VEHICLE, the SOFTWARE, or SERVICES.

I. Availability/Interruption. The SOFTWARE and certain SERVICES are made available through your VEHICLE's compatible multimedia system when the VEHICLE is turned on. Certain SERVICES may be available only through your compatible mobile device when it is within the operating range of the VEHICLE and a wireless carrier. The availability of the SOFTWARE and SERVICES may be subject to transmission limitation or interruption, including but not limited to technical obsolesce or sunsetting of the hardware, software or firmware, inside of or external to the Vehicle, required for data transmission or receipt. HONDA does not guarantee that the SOFTWARE, SERVICES, or any portion thereof will be available at all times or in all areas. You acknowledge and agree that HONDA is not responsible for performance degradation, interruption or delays. You acknowledge that HONDA shall not be liable to you if the SOFTWARE or SERVICES in a given location are not available. If the SOFTWARE or SERVICES are not available within your intended location, you agree that your sole remedy shall be to cease using the SOFTWARE and SERVICES.

**J. PRODUCT SUPPORT:** Product support for the SOFTWARE is provided by HONDA. For product support, please refer to HONDA instructions provided in the DOCUMENTATION. Should you have any questions concerning this AGREEMENT, or if you desire to contact HONDA for any other reason, please refer to the HONDA contact information provided in the DOCUMENTATION.

#### K. Termination and Transfer.

**1. Termination.** This AGREEMENT is effective until terminated by you or US. WE may terminate this AGREEMENT for any or no reason, and with or without notice to you. Your rights under this AGREEMENT will terminate automatically without notice from US if you fail to comply with any term of this AGREEMENT. Upon termination of this AGREEMENT, you shall cease all use of the SOFTWARE and SERVICES.

**2. Transfer:** You may permanently transfer your rights under this AGREEMENT only as part of a sale or transfer of the VEHICLE, provided you retain no copies, you transfer all of the SOFTWARE and HONDA SERVICES (including all component parts, the media and printed materials, and any upgrades), and the recipient agrees to the terms of this AGREEMENT. You agree to notify HONDA upon the sale or transfer of the VEHICLE. To contact HONDA, please refer to the HONDA contact information provided in the DOCUMENTATION.

L. Changes to the SOFTWARE or SERVICES. WE may change, modify, or update the SOFTWARE or SERVICES from time to time. Unless explicitly stated otherwise, any new features or services that augment or enhance the SOFTWARE or SERVICES in the future shall respectively be considered part of the SOFTWARE or SERVICES and subject to this AGREEMENT. WE reserve the right at any time and from time to time to interrupt, restrict, modify, suspend, discontinue, temporarily or permanently, the SOFTWARE or SERVICES (or any portion thereof), with or without notice to you, and you agree that HONDA shall not be liable to you or to any third party for any modification, suspension or discontinuance of the SOFTWARE or SERVICES.

#### **M.** ARBITRATION:

PLEASE READ THIS ARBITRATION PROVISION CAREFULLY TO UNDERSTAND YOUR RIGHTS. YOU AGREE THAT ANY CLAIM THAT YOU MAY HAVE IN THE FUTURE MUST BE RESOLVED THROUGH BINDING ARBITRATION. YOU WAIVE THE RIGHT TO HAVE YOUR DISPUTE HEARD IN COURT AND WAIVE THE RIGHT TO BRING CLASS CLAIMS. YOU UNDERSTAND THAT DISCOVERY AND APPEAL RIGHTS ARE MORE LIMITED IN ARBITRATION.

Arbitration is a method of resolving a claim, dispute or controversy without filing a lawsuit. By agreeing to arbitrate, the right to go to court is waived and instead claims, disputes or controversies are submitted to binding arbitration. This provision sets forth the terms and conditions of our agreement. YOU and HONDA agree and acknowledge that this Agreement affects interstate commerce and the Federal Arbitration Act ("FAA") applies. By using the Software, Vehicle, or Services, YOU elect to have disputes resolved by arbitration. YOU, HONDA or any involved third party may pursue a Claim. "Claim" means any dispute between YOU, HONDA, or any involved third party relating to your use of the Software, the Vehicle, or the Services, this Agreement, or our relationship, including any representations, omissions or warranties. "Claim" does not include personal injury or wrongful death claims. YOU or HONDA may seek remedies in small claims court or provisional judicial remedies without arbitrating. In addition, notwithstanding anything herein to the contrary, YOU or HONDA may seek equitable relief in a court of competent jurisdiction.

YOU or HONDA may select arbitration with American Arbitration Association, JAMS or National Arbitration and Mediation. Contact these sponsors for their rules. The hearing will be in the federal district where YOU reside. If agreed, it may be by telephone or written submissions. Filing and arbitrator fees to be paid per the sponsor rules. You may contact the sponsor for a fee waiver. If no fee waivers, HONDA will pay filing and arbitrator fees up to \$5,000, unless law requires more. Each party is responsible for other fees. Arbitrator may award costs or fees to prevailing party, if permitted by law. HONDA will not seek fees, unless the claims are frivolous.

Arbitrator shall be an attorney or current or retired judge familiar with automotive or consumer software. The arbitrator shall follow substantive law, statute of limitations and decide all issues relating to the interpretation, construction, enforceability and applicability of this provision. The arbitrator may order relief permitted by law. This provision is governed and enforceable by the FAA. An award shall include a written opinion and be final, subject to appeal by the FAA.

This provision survives termination of this Agreement or relationship, bankruptcy, assignment or transfer. If part of this provision is unenforceable, the remainder remains in effect. If unenforceability allows arbitration as a class action, then this provision is entirely unenforceable. YOU may opt out within 30 days of your initial use of the Software by sending a signed, written notice to HONDA at Honda Financial Services, P.O. Box 165007, Irving, TX 75016. HONDA reserves the right to make changes to this provision after providing written notice and an opportunity to opt out.

**N. Miscellaneous:** You may not assign this AGREEMENT without HONDA's prior written consent. This AGREEMENT and any additional HONDA TERMS and PROVIDER TERMS represents the entire agreement between you and US. HONDA may amend the terms of this AGREEMENT by providing you with notices of such updated terms. If you do not consent to be bound by the updated terms, your sole remedy will be to cease using the SOFTWARE and SERVICES. If any part of this AGREEMENT is found invalid, void, or unenforceable, the balance of the AGREEMENT will remain valid and enforceable according to its terms. To the fullest extent permitted by law, and except as explicitly provided otherwise, this AGREEMENT and any disputes arising out of or relating to it will be governed by the laws of the State of California, except that California laws concerning choice of law or conflicts shall not apply if they would cause the substantive law of another jurisdiction to apply. Notwithstanding the foregoing, Section M shall be governed by the Federal Arbitration Act and the laws of the State of California, as applicable, as set forth therein. The failure to enforce any term of this AGREEMENT on one occasion shall not prevent enforcement on any other occasion or the enforcement of any other term. Headings and captions shall not be considered included for purposes of interpretation or application hereof, but are for convenience only.

# Legal Information on Apple CarPlay/Android Auto

## OWNER'S MANUAL LICENSE/LIABILITY STATEMENTS

USE OF APPLE CARPLAY IS SUBJECT TO YOUR AGREEMENT TO THE CARPLAY TERMS OF USE, WHICH ARE INCLUDED AS PART OF THE APPLE IOS TERMS OF USE. IN SUMMARY, THE CARPLAY TERMS OF USE DISCLAIM APPLE AND ITS SERVICE PROVIDERS' LIABILITY IF THE SERVICES FAIL TO PERFORM CORRECTLY OR ARE DISCONTINUED, STRICTLY LIMIT APPLE AND ITS SERVICE PROVIDERS' OTHER LIABILITIES, DESCRIBE THE KINDS OF USER INFORMATION (INCLUDING, FOR EXAMPLE, VEHICLE LOCATION, VEHICLE SPEED, AND VEHICLE STATUS) BEING GATHERED AND STORED BY APPLE AND ITS SERVICE PROVIDERS, AND DISCLOSE CERTAIN POSSIBLE RISKS ASSOCIATED WITH THE USE OF CARPLAY, INCLUDING THE POTENTIAL FOR DRIVER DISTRACTION. SEE APPLE'S PRIVACY POLICY FOR DETAILS REGARDING APPLE'S USE AND HANDLING OF DATA UPLOADED BY CARPLAY.

USE OF ANDROID AUTO IS SUBJECT TO YOUR AGREEMENT TO THE ANDROID AUTO TERMS OF USE WHICH MUST BE AGREED TO WHEN THE ANDROID AUTO APPLICATION IS DOWNLOADED TO YOUR ANDROID PHONE. IN SUMMARY, THE ANDROID AUTO TERMS OF USE DISCLAIM GOOGLE AND ITS SERVICE PROVIDERS' LIABILITY IF THE SERVICES FAIL TO PERFORM CORRECTLY OR ARE DISCONTINUED, STRICTLY LIMIT GOOGLE AND ITS SERVICE PROVIDERS' OTHER LIABILITIES, DESCRIBE THE KINDS OF USER INFORMATION (INCLUDING, FOR EXAMPLE, VEHICLE LOCATION, VEHICLE SPEED, AND VEHICLE STATUS) BEING GATHERED AND STORED BY GOOGLE AND ITS SERVICE PROVIDERS, AND DISCLOSE CERTAIN POSSIBLE RISKS ASSOCIATED WITH THE USE OF ANDROID AUTO, INCLUDING THE POTENTIAL FOR DRIVER DISTRACTION. SEE GOOGLE'S PRIVACY POLICY FOR DETAILS REGARDING GOOGLE'S USE AND HANDLING OF DATA UPLOADED BY ANDROID AUTO.

## DISCLAIMER OF WARRANTIES; LIMITATION ON LIABILITY

YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF APPLE CARPLAY OR ANDROID AUTO ("THE APPLICATIONS") IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, ACCURACY AND EFFORT IS WITH YOU TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. AND THAT THE APPLICATIONS AND INFORMATION ON THE APPLICATIONS IS PROVIDED "AS IS" AND "AS AVAILABLE," WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND, AND HONDA HEREBY DISCLAIMS ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE APPLICATIONS AND INFORMATION ON THE APPLICATIONS, EITHER EXPRESS. IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES AND/OR CONDITIONS OF MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, ACCURACY, QUIET ENJOYMENT, AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY HONDA OR AN AUTHORIZED. REPRESENTATIVE SHALL CREATE A WARRANTY. AS EXAMPLES, AND WITHOUT LIMITATION. HONDA DISCLAIMS ANY WARRANTY REGARDING THE ACCURACY OF DATA PROVIDED BY THE APPLICATIONS, SUCH AS THE ACCURACY OF DIRECTIONS, ESTIMATED TRAVEL TIME, SPEED LIMITS, ROAD CONDITIONS, NEWS, WEATHER, TRAFFIC, OR OTHER CONTENT PROVIDED BY APPLE, GOOGLE, THEIR AFFILIATES, OR THIRD PARTY PROVIDERS: HONDA DOES NOT GUARANTEE AGAINST LOSS OF APPLICATION DATA, WHICH MAY BE LOST AT ANY TIME; HONDA DOES NOT GUARANTEE THAT THE APPLICATIONS OR ANY SERVICES PROVIDED THROUGH THEM WILL BE PROVIDED AT ALL TIMES OR THAT ANY OR ALL SERVICES WILL BE AVAILABLE AT ANY PARTICULAR TIME OR LOCATION. FOR EXAMPLE. SERVICES MAY BE SUSPENDED OR INTERRUPTED WITHOUT NOTICE FOR REPAIR. MAINTENANCE, SECURITY FIXES, UPDATES, ETC., SERVICES MAY BE UNAVAILABLE IN YOUR AREA OR LOCATION, ETC. IN ADDITION, YOU UNDERSTAND THAT CHANGES IN THIRD PARTY TECHNOLOGY OR GOVERNMENT REGULATION MAY RENDER THE SERVICES AND/OR APPLICATIONS OBSOLETE AND/OR UNUSABLE.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT SHALL HONDA OR ITS AFFILIATES BE LIABLE FOR PERSONAL INJURY, OR ANY INCIDENTAL, SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, CORRUPTION OR LOSS OF DATA, FAILURE TO TRANSMIT OR RECEIVE ANY DATA, BUSINESS INTERRUPTION OR ANY OTHER COMMERCIAL DAMAGES OR LOSSES, ARISING OUT OF OR RELATED TO THE APPLICATIONS OR YOUR USE OF OR INABILITY TO USE THE APPLICATIONS OR INFORMATION ON THE APPLICATIONS, HOWEVER CAUSED, REGARDLESS OF THE THEORY OF LIABILITY (CONTRACT, TORT OR OTHERWISE) AND EVEN IF HONDA WERE ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES AND JURISDICTIONS DISALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR DAMAGES, SO THESE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. IN NO EVENT SHALL HONDA'S TOTAL LIABILITY TO YOU FOR ALL DAMAGES (OTHER THAN AS MAY BE REQUIRED BY APPLICABLE LAW IN CASES INVOLVING PERSONAL INJURY) EXCEED THE AMOUNT OF FIVE DOLLARS (\$5.00). THE FOREGOING LIMITATIONS WILL APPLY EVEN IF THE ABOVE STATED REMEDY FAILS OF ITS ESSENTIAL PURPOSE.

# **About Open Source Licenses**

To see the open source license information, follow these steps.

- 1. Press the 🕋 (home) button.
- 2. Select Settings.
- 3. Select System.
- 4. Select About.
- 5. Select Legal Information.

➢About Open Source Licenses

For Amplifier Equipment For open source information, please visit: http://www.hondaopensource2.com/18.5MY\_AMP

For Telematics Control Unit Free/Open Source Software Information.

This product contains Free/Open Source Software(FOSS).

The license information and/or the source code of such FOSS can be found at the following URL.

https://www.denso.com/global/en/opensource/tcu/ honda/

# **License Information**

## DTS Neural Surround

For DTS patents, see *http://patents.dts.com*. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS Neural Surround is a trademark of DTS, Inc. © DTS, Inc. All Rights Reserved.



## DTS Enhance

\*\*For DTS patents, see *http://patents.dts.com*. Manufactured under license from DTS, Inc. DTS, the Symbol, DTS and the Symbol together and DTS Enhance are registered trademarks or trademarks of DTS, Inc. in the United States and/or other countries © DTS, Inc. All Rights Reserved.



## Apple

"Made for iPod," "Made for iPhone," and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance. Apple, the Apple Logo, iPad, iPhone, iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. iPad Air, iPad mini, iPad Pro, Apple CarPlay, iPod, iPhone, iTunes, Siri and Lightning are trademarks of Apple Inc. App Store is a service mark of Apple Inc.



## Bluetooth

"The *Bluetooth*<sup>®</sup> word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by DENSO CORPORATION is under license. Other trademarks and trade names are those of their respective owners."



# Windows Media

This product is protected by certain intellectual property rights of Microsoft. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft.

## MPEG

Mpeg4 Visual

THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (i) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUALA STANDARD ("MPEG-4 VIDEO") AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NONCOMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL, INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA, LLC. SEE *HTTP://WWW.MPEGLA.COM*.

### VC-1

THIS PRODUCT IS LICENSED UNDER THE VC-1 PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE VC-1 STANDARD ("VC-1 VIDEO") AND/OR (ii) DECODE VC-1 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE VC-1 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE *HTTP://WWW.MPEGLA.COM*.

#### AVC/H.264

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NONCOMMERCIAL USE OF A CONSUMER TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE *HTTP://WWW.MPEGLA.COM*. Use the audio/information screen to customize certain features.

#### How to customize

With the power mode in ON, select **Settings**, then select a setting item.




#### ➢Customized Features


When you customize settings:


- Make sure that the vehicle is at a complete stop.
- Put the transmission into **P**.


The contents and order of the customized features may vary depending on the vehicle's features.


■ Customization flow

















### List of customizable options

Setup Group	Cu	stomizable Featu	ures	Description	Selectable Settings
		System Sound	s	Changes the system sounds volume.	—
	C. chom	Phone Calls		Changes the phone call volume.	—
	System Volumes	Voice Recogni	tion	Changes the voice recognition volume.	—
		Navigation Guidance		Changes the navigation guidance volume.	—
	Touchpad Sen	sitivity		Sets the sensitivity of the True Touchpad Interface.	High/Low <sup>*1</sup>
System	Date & Time	Time Format		Selects the digital clock display from 12H to 24H.	12 Hour <sup>*1</sup> /24 Hour
		lime Set Date &	Automatic Date & Time	Selects <b>On</b> to have the GPS automatically adjust the clock. Select <b>Off</b> to cancel this function.	On*1/Off
			Set Date	Adjusts date. Adjusting the Clock P. 154	_
		Set Time		Adjusts clock. Adjusting the Clock P. 154	_

Setup Group	Customizable Features			Description	Selectable Settings
	Date & Time	Set Time	Automatic Time Zone	Sets the audio system to automatically adjust the clock when driving through different time zones.	On*1/Off
		zone	Zone (Select time zone)	Changes the time zone manually.	_
	System Units			Changes the speed/distance unit on the multi-information display, head-up display* and audio/information screen.	Miles <sup>*1</sup> /KM (U.S.) Miles/KM <sup>*1</sup> (Canada)
System	Language			Changes the display language.	English <sup>*1</sup> /Français/ Español
	Factory Data R	Reset		Resets all the settings to their factory default. Defaulting All the Settings P. 385	Continue/Cancel
	About			Displays the Android setting items.	—
	Advanced Options	Location Acces	55	Selects <b>Off</b> not to allow apps including the navigation system <sup>*</sup> to access the vehicle's location.	On*1/Off

Setup Group	Customizable Features			Description	Selectable Settings
System		Interruptions .	Interruption Mode	Sets the interruption mode for allowing to notify when calls and notifications arrive.	Always interrupt*1/ Don't interrupt/ Allow only priority interruptions
	Advanced		Events and reminders	Sets priority interruptions of events and reminders.	On*1/Off
5,550	Options	interruptions	Calls         Sets priority interruptions of calls.	Sets priority interruptions of calls.	On <sup>*1</sup> /Off
			Messages	Sets priority interruptions of messages.	<b>On/Off</b> *1
			Calls/ messages from	Sets priority interruptions of from who.	Anyone/Contacts only <sup>*1</sup> /Starred contacts only

Setup Group	С	ustomizable Features	Description	Selectable Settings
		Options	Turns the <i>Bluetooth</i> <sup>®</sup> on and off.	On <sup>*1</sup> /Off
		+ Connect New Device	Pairs a new phone to HFL. Phone Setup P. 395	_
Connections Blu	Bluetooth	(Saved Devices)	Connects, disconnects, or deletes a paired phone. Changes permissions for <b>AcuraLink</b> <b>Assist</b> and <b>Phone Data Collection</b> .	_
			Phone Setup P. 395	

Setup Group	Customizable Fea	tures	Description	Selectable Settings
	Change Mod	<b>e</b> *2	Changes the Wi-Fi mode.	Off <sup>*1/</sup> Hotspot/ Network
	Change Mod	<b>e</b> * <sup>3</sup>	Changes the Wi-Fi mode.	Off/Hotspot/ Network
	Network SSI	<b>D</b> *3	Sets this network name.	_
	Password* <sup>3</sup>		Sets password for require entering password when connecting Wi-Fi device to this network.	_
c (* 147	Connected D	evices List <sup>*3</sup>	Displays the connected device list.	_
Connections Wi	Change Mod	<b>e</b> <sup>*4</sup>	Changes the Wi-Fi mode.	Off/Hotspot/ Network
	(Available Net	works)*4	Displays the available network(s).	
		Add Network	Searches a new available network(s).	_
	Advanced*4	Remembered Networks	Displays the previously entered network(s).	_
		Connected Devices List	Displays the connected device list.	_

\*1:Default Setting
\*2:Appears when Wi-Fi mode is Off.
\*3:Appears when Wi-Fi mode is Hotspot.
\*4:Appears when Wi-Fi mode is Network.

Setup Group		Customiz	able Features	i	Description	Selectable Settings
				Network SSID	Sets this network name.	_
Connections	Android Auto	Advanced Options		Password	Sets password for require entering password when connecting Wi-Fi device to this network.	_
		+ Connect	New Device	Pairs a new phone to Android Auto. <b>D</b> Android Auto Setup P. 329		_
				Allow Android Auto	Sets up the Android Auto connection.	Disable/Enable
		(Saved	Options		Turn AcuraLink Assist on and off.	Disable/Enable*1
		Devices)	-	Phone Data Collection	Allow Acura to collect phone data.	Disable/Enable*1
				Delete	Delete an Android Auto device.	Cancel/Delete

Setup Group		Customiz	able Features	i	Description	Selectable Settings
CONNECTIONS		Advanced Options Sets password for re Password password when con			Sets this network name.	_
			Sets password for require entering password when connecting Wi-Fi device to this network.	_		
	Apple	+ Connect New Device		hone to Apple CarPlay. <b>g Apple CarPlay</b> P. 324	_	
	CarPlay	Allow Apple CarPlay (Saved		Disable/Enable		
	Devices) Options AcuraLink Turn AcuraLink Assist on a	Turn AcuraLink Assist on and off.	Disable/Enable*1			
			Delete	Delete an Apple CarPlay device.	Cancel/Delete	

Setup Group	Customizable Features		Description	Selectable Settings
	Brightness		Changes the brightness of the audio/ information screen.	—
	Display Off		Turns the audio/information screen brightness off.	—
<b>D</b> ' 1	Night Mode		Changes between the daytime mode	
Display	Day Mode		and nighttime mode. Display Setup P. 288	
	More	Contrast	Changes the contrast of the audio/ information screen.	—
	Settings	Black Level	Changes the black level of the audio/ information screen.	—

Setup Group	Cu	stomizable Features	Description	Selectable Setting
		Forward Collision Warning Distance	Changes Collision Mitigation Braking System (CMBS™) alert distance.	Long/Normal <sup>*1/</sup> Short
		ACC Forward Vehicle Detect Beep	Causes the system to beep when the system detects a vehicle, or when the vehicle goes out of the ACC with Low Speed Follow range.	On/Off <sup>*1</sup>
	Driver Assist System Setup	Road Departure Mitigation Setting	Changes the setting for the road departure mitigation system.	Normal <sup>*1</sup> /Wide/ Warning Only/ Narrow
		Lane Keeping Assist Suspend Beep	Causes the system to beep when Lane Keeping Assist System (LKAS) is suspended.	On/Off*1
		Blind Spot Information	Changes the setting for the blind spot information.	Audible and Visual Alert <sup>*1</sup> /Visual Alert

Setup Group	Cu	stomizable Features	Description	Selectable Settings
		Adjust Outside Temp Display	Adjusts the temperature reading by a few degrees.	-5°F ~ ±0°F <sup>*1</sup> ~ 5°F (U.S.) -3°C ~ ±0°C <sup>*1</sup> ~ 3°C (Canada)
		"Trip A" Reset Timing	Changes the setting of how to reset trip meter A and average fuel economy A.	With Refuel/IGN Off/Manually Reset*1
		"Trip B" Reset Timing	Changes the setting of how to reset trip meter B and average fuel economy B.	With Refuel/IGN Off/Manually Reset*1
Vehicle	Meter Setup	Reverse Shift Position Beep	Causes the beeper to sound once when the transmission is put into $[\mathbf{R}]$ .	On*1/Off
		Adjust Alarm Volume	Changes the alarm volume, such as buzzers, warnings, turn signal sound, and so on.	High/Mid*1/Low
		Turn by Turn Display	Selects whether the turn-by-turn display comes on during the route guidance.	On*1/Off
		Rear Seat Reminder	Turns the Rear Seat Reminder feature on and off.	On*1/Off

Setup Group	Customizable Features		Description	Selectable Settings
Vehicle	Meter Setup	Models with navigation system Speed Limit Information	Select whether the speed limit information source is camera located behind the rearview mirror or the navigation system. You can also turn off speed limit information.	Traffic Sign Recognition <sup>*1/</sup> Navigation/Off
		Models without navigation system Speed Limit Information	Selects whether the speed limit information should be displayed on head-up display*/meter.	On*1/Off

Setup Group	Cus	stomizable Features	Description	Selectable Settings
Driving Position Setup	Driving	Memory Position Link	Turns the driving position memory system on and off.	On <sup>*1</sup> /Off
		Seat Position Movement at Entry/Exit	Causes the driver's seat to move back to make it easier to enter or exit the vehicle.	On*1/Off
		Door Unlock Mode	Changes which doors unlock when you grab the driver's door handle.	Driver Door or Tailgate Only <sup>*1/</sup> All Doors
Vehicle		Keyless Access Light Flash	Causes some exterior lights to flash when you unlock/lock the doors.	On <sup>*1</sup> /Off
	Keyless Access Setup	Keyless Access Beep	Causes the beeper to sound when you unlock/lock the doors.	On <sup>*1</sup> /Off
		Remote Start System On/ Off <sup>*</sup>	Turns the remote engine start feature on and off.	On <sup>*1</sup> /Off
		Walk Away Auto Lock	Changes the settings for the auto lock function when you walk away from the vehicle.	Enable/Disable*1

Setup Group		Customizable Features	Description	Selectable Settings
		Accent Light Brightness*	Changes the brightness level of the interior accent lighting.	Link to Illumination*1/Max/ High/Mid/Low/Off
		Accent Light Theme*	Changes the theme of the interior accent lighting. ▲ Lighting area of the accent light P. 463	Dynamic Mode <sup>*1</sup> See other selectable settings on the screen.
		Interior Light Dimming Time	Changes the length of time the interior lights stay on after you close the doors.	15 sec/30 sec*1/60 sec
Lighting Setup       Headlight Auto Off Timer       exteritive distribution         Vehicle       Chan         Auto Interior Illumination Sensitivity       bright when	Changes the length of time the exterior lights stay on after you close the driver's door.	0 sec/15 sec <sup>*1/</sup> 30 sec/ 60 sec		
		Changes the sensitivity of the brightness of the instrument panel when the headlight switch is in <b>AUTO</b> position.	Min/Low/Mid*1/ High/Max	
	Auto Headlight On with Wiper Onwhen the headli AUTO position a used several tim	Causes the headlights to come on when the headlight switch is in the <b>AUTO</b> position and the wipers are used several times within a certain number of intervals.	On*1/Off	
		Auto Light Sensitivity <sup>*</sup>	Changes the timing for the headlights to come on.	Min/Low/Mid <sup>*1/</sup> High/Max

\* Not available on all models

Setup Group	Cu	stomizable Features	Description	Selectable Settings
		Auto Door Lock	Changes the setting for the automatic locking feature.	Off/With Vehicle Speed <sup>*1</sup> /Shift from P
		Auto Door Unlock	Changes the setting for when the doors unlock automatically.	All Doors with Driver's Door Opens <sup>*1</sup> /All Doors with Shift to P/All Doors with IGN Off/ Off
Vehicle	Door Setup	Keyless Lock Answer Back	LOCK/UNLOCK- The exterior lights flash. LOCK (2nd push)- The beeper sounds.	On*1/Off
		Security Relock Timer	Changes the time it takes for the doors to relock and the security system to set after you unlock the vehicle without opening any door.	30 sec*1/60 sec/90 sec
		Auto Folding Door Mirror*	Changes the setting so that the mirrors fold at the time the doors are locked with the remote transmitter or keyless access system.	Auto Fold with Keyless*1/Manual Only

Setup Group	C	ustomizable Features	Description	Selectable Settings
		Power Tailgate Keyless Open Mode	Changes the setting to enable the power tailgate to be opened with the keyless remote at anytime or only when the doors are unlocked.	Anytime <sup>*1</sup> /When Unlocked
Power       Tailgate         Tailgate       Power Tailgate Open by       disable the power tailgate         Setup       Outer Handle       operation when the user         Vehicle       Hands Free Access Power       Changes the setting to end         Hands Free Access Power       disable the power tailgate         operation when a kicking       operation when a kicking	Changes the setting to enable or disable the power tailgate open operation when the user presses the outer handle of the power tailgate.	Off (Manual only)/ On (Power/ Manual) <sup>*1</sup>		
	Changes the setting to enable or disable the power tailgate open operation when a kicking motion under the rear bumper is detected.	On*1/Off		
	Maintenance	(Select Reset Items)	Resets the Maintenance Minder™	
	Information	Reset All Due	<ul> <li>display when you have performed the maintenance service.</li> </ul>	—

Setup Group	Cus	tomizable Features	Description	Selectable Settings
Rear Camera*       Guidelines       on the rear camera model         Cross Traffic Monitor       Turns the cross traffic on and off.         Camera       Guidelines       Selects whether the gu on the rear camera model         Surround View Camera*       Guidelines       Selects whether the gu on the rear camera model         Surround View Camera*       Cross Traffic Monitor       Selects whether the gu on the rear camera model         Surround View Camera*       Cross Traffic Monitor       Turns the cross traffic on and off.         Show after Shifting from Beverse       Sets the rear view to be switched to the front to the switched to the	Rear Camera*	Guidelines	Selects whether the guidelines come on the rear camera monitor. Multi-View Rear Camera* P. 565	Dynamic/Fixed/ Both <sup>*1</sup> /Off
		Cross Traffic Monitor	Turns the cross traffic monitor feature on and off.	On*1/Off
	Selects whether the guidelines come on the rear camera monitor. Surround View Camera System* P. 567	Dynamic/Fixed/ Both <sup>*1</sup> /Off		
	Turns the cross traffic monitor feature on and off.	On*1/Off		
	-	-	Sets the rear view to be automatically switched to the front view when the transmission is out of <b>R</b> .	On/Off*1

Setup Group	Cu	stomizable Features	Description	Selectable Settings
		Treble		
	Dees / Trable	Midrange		
	Bass / Treble	Bass	_	
		Reset to Default		
		Roof Speaker Volume		
	Roof / Center Volume*	Center Speaker Volume		
Sound         Reset to Default         Adjusts the settings of the a speakers' sound.	Adjusts the settings of the audio	_		
		Full Vehicle	Adjusting the Sound P. 287	
	Reset to Default			
	Balance / Fader*	Reset to Default		

Setup Group	Customizable Features	Description	Selectable Settings
	Speed Volume Compensation	Adjusts the settings of the audio	Off/Low/Mid <sup>*1</sup> /High
Sound	DTS Neural Surround*	speakers' sound.	On/Off <sup>*1</sup>
	Compressed Audio Enhancement*	Adjusting the Sound P. 287	On/Off <sup>*1</sup>
Notifications		Changes the notification settings for apps.	—

# **Defaulting All the Settings**

Reset all the menu and customized settings as the factory defaults.

### Defaulting System Settings



- 1. Press the 🕋 (home) button.
- 2. Select Settings.
- 3. Select System.
- 4. Select Factory Data Reset.
  - A confirmation message appears on the screen.
- 5. Select Continue to reset the settings.
- 6. Select Reset to reset the settings.
  - ► The system will reboot.

### **Defaulting Vehicle Settings**

Velvicie	Reset to Default
Driving Position Setup	
Meter Setup	
Power Tailgate Setup	
Keyless Access Setup	

- 1. Press the 👔 (home) button.
- 2. Select Settings.
- 3. Select Vehicle.
- 4. Select Reset to Default.
- 5. Select Reset.

#### Defaulting All the Settings

When you transfer the vehicle to a third party, reset all settings to default and delete all personal data.

If you perform **Factory Data Reset**, it will reset the preinstalled apps to their factory default.

The HomeLink<sup>®</sup> Universal Transceiver can be programmed to operate up to three remote controlled devices around your home, such as garage doors, lighting, or home security systems.

### Important Safety Precautions

Refer to the safety information that came with your garage door opener to test that the safety features are functioning properly. If you do not have the safety information, contact the manufacturer.

Before programming HomeLink, make sure that people and objects are out of the way of the garage or gate to prevent potential injury or damage.

When programming a garage door opener, park just outside the garage door's path.


#### ➢HomeLink<sup>®</sup> Universal Transceiver

Before programming HomeLink to operate a garage door opener, confirm that the opener has an external entrapment protection system, such as an "electronic eye," or other safety and reverse stop features. If it does not, HomeLink may not be able to operate it.

#### NOTE:

Some LED lightbulbs installed in the garage door opener can interfere with the training and consistent operation of your HomeLink device. Please consider use of Low RF interference bulbs in your garage door opener.

# **Training HomeLink**



If it is necessary to erase a previously entered learned code:

- Press and hold the I and III HomeLink buttons for about 10 seconds, until the green indicator blinks. Release the buttons, and proceed to step 1.
- If you are training the second or third button, go directly to step 1.

The instructions on the next page should work for most gate or garage openers, but may not work for all. For detailed instructions about your specific remote opener, visit *http://www.homelink.com* or call (800) 355-3515.

### Programming a Button

- **1.** Position the remote transmitter you wish to link 1 to 3 inches (3 8 cm) from the HomeLink<sup>®</sup> button you want to program.
- 2. Press and hold the desired HomeLink button. Is the HomeLink indicator (LED) *slowly flashing orange*?



YËS

- **3a.** Hold the button on the remote transmitter. Does HomeLink indicator (LED) change from *slowly flashing orange to rapidly flashing green or continuously on green*? The process should take less than 60 seconds.
- Press and hold the programmed HomeLink button for about a second. Does the device (garage door opener) work?

NO

NO

**3b.** Canadian Garage Door Opener A. Press and release the HomeLink button. Press, hold and release the button on the remote every 2 secs. Does the HomeLink indicator (LED) change from *slowly flashing orange to rapidly flashing or continuously on green*? The process should take less than 60 seconds.



HomeLink LED is continuously on green.

 Press and hold the HomeLink button again. The remote-controlled device should operate.

Training Complete

HomeLink indicator *rapidly flashes* green.

**5a.** The remote has a rolling code. Press the "learn" button on the remote-controlled device (e.g. garage door opener).

**5b.** Within 30 secs, press and hold the programmed HomeLink button for 2 secs.

#### ■Training HomeLink

#### Reprogramming a Button

If you want to retrain a programmed button for a new device, you do not have to erase all button memory. You can replace the existing memory code using this procedure:

- 1. Press and hold the desired HomeLink button until the HomeLink indicator begins to *slowly flash orange*. This should take about 20 seconds.
- Release the HomeLink button and position the remote transmitter you wish to link 1 - 3 inches (3 - 8 cm) from the HomeLink button you want to program, then follow steps 3 - 6 under "programming a button."

#### Erasing Button Memory

To erase programming from the buttons, press and hold the two outside HomeLink buttons until the HomeLink indicator changes from *orange to rapidly flashing green*. This should take about 10 seconds. You should erase all programming before selling the vehicle.

#### Operating

To operate, simply press and release the programmed HomeLink button. Activation will now occur for the trained device.

#### Questions


For questions or comments, visit www.HomeLink.com, www.youtube.com/ HomeLinkGentex, or by calling the HomeLink Hotline (North America only) at (800) 355-3515.

HomeLink<sup>®</sup> is a registered trademark of Gentex Corporation.

*Bluetooth*<sup>®</sup> HandsFreeLink<sup>®</sup> (HFL) allows you to place and receive phone calls using your vehicle's audio system, without handling your cell phone.

# **Using HFL**

### HFL Buttons



#### Bluetooth® HandsFreeLink®

Place your phone where you can get good reception.

To use HFL, you need a *Bluetooth*-compatible cell phone. For a list of compatible phones, pairing procedures, and special feature capabilities:

- U.S.: Visit www.handsfreelink.com/Acura, or call 1-888-528-7876.
- Canada: For more information on smartphone compatibility, call 1-855-490-7351.

To use the system, the  $\textit{Bluetooth}^{\circledast}$  setting must be On.

Phone Setup P. 395

Voice control tips

- Aim the vents away from the ceiling and close the windows, as noise coming from them may interfere with the microphones.
- Press the K
   button when you want to call a number using a phonebook name or a number.
   Speak clearly and naturally after a beep.
- If the microphone picks up voices other than yours, the command may be misinterpreted.
- To change the volume level, the volume level is able to change by the audio system's volume.

#### Left Selector Wheel:

- **Incoming call:** Move the selector wheel to the right to answer the call. Move it to the left to decline the call.
- **During a call:** Move the selector wheel to the right to display the call options menu. Move it to the left to end the call.
- **(back) button:** Press the button to go back to the previous screen or to cancel a command.
- 🔬 (talk) button: Press the button to start voice recognition.

To go to the phone screen of the multi-information display or the head-up display<sup>\*</sup>: **1.** Press the **APPS** button on the steering wheel.

- 2. Using the selector wheel, scroll to **Phone** on the multi-information display or the head-up display<sup>\*</sup>, and then press the left selector wheel.
  - You can select Favorites or Recents by moving the selector wheel to the left or the right.

#### **≥**Bluetooth<sup>®</sup> HandsFreeLink<sup>®</sup>

#### Bluetooth® Wireless Technology


The *Bluetooth*<sup>®</sup> word mark and logos are registered trademarks owned by *Bluetooth* SIG, Inc., and any use of such marks by Honda Motor Co., Ltd., is under license. Other trademarks and trade names are those of their respective owners.

#### **HFL** Limitations


An incoming call on HFL will interrupt the audio system when it is playing. It will resume when the call is ended.

### HFL Status Display

The audio/information screen notifies you when there is an incoming call.



Bluetooth<sup>®</sup> connection status is displayed in the B-zone.



#### ➢HFL Status Display

The information that appears on the audio/ information screen varies between phone models.

### Limitations for Manual Operation\*

Certain manual functions are disabled or inoperable while the vehicle is in motion. You cannot select a grayed-out option until the vehicle is stopped.

# **HFL Menus**

The power mode must be in ACCESSORY or ON to use the system.

### Phone screen





- Press the (home) button.
   Select Phone
- 2. Select Phone.

#### ≫HFL Menus

To use HFL, you must first pair your *Bluetooth*compatible cell phone to the system while the vehicle is parked.

Some functions are limited while driving.





## Phone Setup




## ■ Bluetooth® setup

You can turn *Bluetooth*<sup>®</sup> function on and off.

- **1.** Press the 🕋 (home) button.
- 2. Select Settings.
- 3. Select Connections.
- 4. Select Bluetooth.
- 5. Select Options.
- 6. Select On.

#### *■Bluetooth*<sup>®</sup> setup

If there is an active connection to Apple CarPlay or Android Auto, this setting is unavailable.



## To pair a cell phone (when there is no phone paired to the system)

- 1. Press the 🕋 (home) button.
- 2. Select Phone.
- 3. Select Connect Phone.
- Make sure your phone is in search or discoverable mode, then select + Connect New Device.
  - ► HFL automatically becomes discoverable.
- **5.** Select the **HandsFreeLink** when it appears on your phone.
  - If HFL does not appear, select Search for Devices.
- **6.** The system gives you a pairing code on the audio/information screen.
  - Confirm if the pairing code on the screen and your phone match. This may vary by phone.
  - After confirming pairing, may be required to confirm *Bluetooth*<sup>®</sup> operation depending on phone. Select Continue with Bluetooth.
- 7. The device options screen appears, then select **Continue**.
  - You can enable/disable the AcuraLink Assist and Phone Data Collection on the screen. Both default settings are Enable.

#### ➢Phone Setup

Your *Bluetooth*-compatible phone must be paired to the system before you can make and receive hands-free calls.

#### Phone Pairing Tips:

- You cannot pair your phone while the vehicle is moving.
- Up to six phones can be paired.
- Your phone's battery may drain faster when it is paired to the system.

Once you have paired a phone, you can see it displayed on the screen with one or more icons on the right side.

These icons indicate the following:

- (): The phone is compatible with *Bluetooth*<sup>®</sup> Audio.
- : The phone can be used with HFL.
- 💽: The phone is compatible with Apple CarPlay.
- : The phone is compatible with Android Auto.

If there is an active connection to Apple CarPlay or Android Auto, pairing of additional *Bluetooth*<sup>®</sup> compatible devices is unavailable.

#### Enable Smart Sharing pop-up

Smart Sharing to share phone data with Acura. You can change the **AcuraLink Assist** and **Phone Data Collection** settings later by selecting the device in the **Phone Menu** screen and then **Options**. For detailed information of all data shared visit *https://acuralink.acura.com/#/acuralinkLegalTerms* 

		Options
+	Connect New Device	
	Phone A	48 🔲
	Phone B	48 🔲
	Phone C	48 🔲

## To change the currently paired phone

- 1. Go to the Phone Menu screen. ⇒ Phone Menu screen P. 394
- 2. Select Change Connected Phone.

When connecting to another phone:

**3.** Select a phone to connect.



5. Select Connect.

When changing the currently paired phone setting:

- **3.** Select a currently paired phone.
- 4. Select () or .
- 5. Select Apply Changes.

■To change the currently paired phone

If there is an active connection to Android Auto, this setting is unavailable.

If no other phones are found or paired when trying to switch to another phone, HFL will continue to connect an original phone.

To pair other phones, select **+ Connect New Device** from the **Bluetooth** screen.



#### To delete a paired phone

- 2. Select Change Connected Phone.
- **3.** Select a phone you want to delete.

## 4. Select Options.

#### 5. Select Delete Device.

**6.** A confirmation message appears on the screen. Select **Delete**.

#### ≥To delete a paired phone

You can also delete a paired phone by the following procedure.

- 1. Press the 👚 (home) button.
- 2. Select Settings.
- 3. Select Connections.
- 4. Select Bluetooth.
- 5. Select a phone you want to delete.
- 6. Select Options.
- 7. Select Delete Device.
- 8. A confirmation message appears on the screen. Select **Delete**.

If there is an active connection to Android Auto, you cannot delete a paired phone.

## Ringtone

You can change the ringtone setting.



- **1.** Go to the **Phone Menu** screen. **▶ Phone Menu screen** P. 394
- 2. Select Ringtone.
- 3. Select Vehicle or Phone.

#### ≫Ringtone

**Vehicle**: The fixed ringtone sounds from the speakers.

**Phone**: Depending on the make and model of the cell phone, the ringtone stored in the phone will sound if the phone is connected.

## Automatic Transferring

If you get into the vehicle while you are on the phone, the call can be automatically transferred to HFL.

Auto Phone Call Transfer	
hen vehicle starts, automatically transf pakers.	
Off	On

- **1.** Go to the **Phone Menu** screen. **Phone Menu screen** P. 394
- 2. Select Auto Phone Call Transfer.
- 3. Select On or Off.

## Automatic Import of Phone Contacts and Call History



#### When Auto Sync Phone is set to On:

When your phone is paired, the contents of its phonebook and call history are automatically imported to the system.

#### Changing the Auto Sync Phone setting

- **1.** Go to the **Phone Menu** screen.
- 2. Select Auto Sync Phone.
- 2. Select Auto Sync Phone.
- 3. Select On or Off.

#### Mutomatic Import of Phone Contacts and Call History

On some phones, it is necessary to enable import during setup so the phone's contacts can be accessed.

When you select a name from the phone contacts list, you can see a category icon. The icons indicate what types of numbers are stored for that name.



On some phones, it may not be possible to import the category icons to the system.

The phonebook is updated after every connection. Call history is updated after every connection or call.

## Favorite Contacts



- To store a favorite contact number:
- 1. Go to the phone screen.
  - Phone screen P. 393
- 2. Select Add Favorite.

**3.** Select a place from where to choose a number.

#### From Recents:

Select a number from the call history.

#### From Contacts:

Select a number from the phonebook of a cellular phone connected to the system.

#### Using Enter Number:

- Trace the number on the A-zone touchpad, then press it.
  - If the **KEYPAD** icon located to the upper
- right of the screen is selected, the
- keyboard will appear.
- 4. Select a number.



#### To edit a Favorite Contact

- **1.** Go to the phone screen. **▶** Phone screen P. 393
- 2. Select and hold a desired favorite contact.
- 3. Select the following options:
  - **Remove Favorite**: Delete the favorite contact.
  - Add to Home Page: Add a favorite contact shortcut icon to the home screen.
  - Add to Heads-Up Display\*: Add a favorite contact shortcut icon to the head-up display menu.
- **4.** Press the **(back)** button on the True Touchpad Interface.
  - The screen will return to the previous screen.

## Making a Call



You can make calls by inputting any phone number, or by using the imported phonebook, call history, or Favorite Contact entries.

#### Making a Call

Once a call is connected, you can hear the voice of the person you are calling through the audio speakers.

While there is an active connection with Apple CarPlay, phone calls cannot be made with HandsFreeLink<sup>®</sup> and are only made from Apple CarPlay.

	QUERRED Y ROLE
A AAA	Q
* BBB	R
c CCC	<b>5</b>
DDD	\$ v

# ■ To make a call using the imported phonebook

- **1.** Go to the phone screen.
- 2. Select Contacts.
- 3. Select a name.
  - You can sort by First Name or Last Name. Select the icon on the upper right of the screen.
- 4. Select a number.
  - Dialing starts automatically.

## To make a call using a phone number

- **1.** Go to the phone screen.
- 2. Select Enter Number.
- **3.** Trace the number on the A-zone touchpad, then press it.
  - You can enter the number using the onscreen keyboard. Select KEYPAD located to the upper right of the screen.
- 4. Press the A-zone touchpad.
  - ▶ Dialing starts automatically.
  - ► If the on screen keyboard is displayed, select **Call**.

#### To make a call using the imported phonebook

This feature also allows you to send a message or set a navigation route<sup>\*</sup> to a contact's address.

- Text Message P. 407
- Refer to Navigation System Manual



2

Add Favorite

#### ■ To make a call using the call history Call history is stored by All, Dialed, Missed, and Received.

- **1.** Go to the phone screen.
  - Phone screen P. 393
- 2. Select Recents.
  - You can sort by All, Dialed, Missed, or Received. Select the icon on the upper right of the screen.
- 3. Select a number.
  - ▶ Dialing starts automatically.

## To make a call using a Favorite Contact entry

- **1.** Go to the phone screen.
  - Phone screen P. 393
- 2. Select desired favorite contact.
  - Dialing starts automatically.

S Phone A . all

0

BBB

AAA



## Receiving a Call



When there is an incoming call, an audible notification sounds (if activated) and the **Incoming Call...** screen appears.

Move the left selector wheel to the right to answer the call. Move it to the left to decline or end the call.

You can also select **Answer** or **Ignore** on the audio/information screen to use hands-free calling.

#### ➢Receiving a Call

#### Call Waiting

To put a call on hold so that you can answer an incoming call, move the left selector wheel to the right.

Move the left selector wheel to the right to resume the call.

Select **Ignore** to ignore the incoming call if you do not want to answer it.

Move the left selector wheel to the left to end a call.

Instead of using the selector wheel, you can use the icons on the audio/information screen to perform the above mentioned functions.

When a screen other than the phone screen is displayed in the A-zone, the incoming call screen is displayed in the B-zone.

## Options During a Call

The following options are available during a call. **MUTE**: Mute your voice. **TRANSFER TO MOBILE**: Transfer a call from the system to your phone. **ENTER NUMBER**: Send numbers during a call. This is useful when you call a menudriven phone system.



The available options are shown on the lower half of the screen.

Select the option.

- ► UNMUTE is displayed when the mute function is on. Select UNMUTE to turn it off.
- TRANSFER TO VEHICLE is displayed when the hands-free mode is off. Select TRANSFER TO VEHICLE to turn the hands-free mode is on.

#### ➢Options During a Call

You can select the icons on the audio/information screen.

## **Text Message**

You can operate the various options of the text message function from the message box.



- 1. Press the 🕋 (home) button.
- 2. Select Messages.

The following options are available: **Inbox**: Shows received messages. **Send Message to Contact**: Sends a message to your contact on the list.

Send Message to Contact P. 418 Add Favorite: Adds the favorite contact to the message box.

You can add a shortcut to the home screen that will take you directly to your favorite contact. Select and hold the contact, then select Add to Home Page.

**MENU**: Sets the message option for changing the connected device, turning on or off message notifications, or editing replies.

#### ➢Text Message

The text message features may not be available depending on the cellular phone.



#### To edit a Favorite Contact

- 1. Press the 🕋 (home) button.
- 2. Select Messages.
- 3. Select and hold a desired favorite contact.
- **4.** Select following options.
  - **Remove Favorite**: Delete a favorite contact.
  - Add to Home Page: Add the shortcut icon of a favorite contact to the home screen.
- 5. Press the (back) button on the True Touchpad Interface.
  - The screen will return to the previous screen.

## To Set Up Text Message Options



- To turn on or off the text message notice
- 1. Press the 🕋 (home) button.
- 2. Select Messages.
- 3. Select MENU.
- 4. Select Notifications.
- 5. Select On or Off.

#### ■To Set Up Text Message Options

To use the text message function, it may be necessary to set up on your phone.

#### To turn on or off the text message notice

**On:** A pop-up notification comes on every time you receive a new message.

**Off:** The message you receive is stored in the system without notification.

When a screen other than the **Messages** function screen is displayed in the A-zone, a text message notification is displayed in the B-zone.

## Receiving a Text Message

HFL can display newly received text messages as well as the last 20 messages received on a linked cell phone. Each received message can be read aloud and replied to using a fixed common phrase.

1. No. 17 19-4			-
	BBB HE, XXXXX		
Dismiss		Open	
	$\downarrow$		
<ul> <li>Message 1 of 20</li> <li>BBB Jul 31</li> </ul>			View Message
Prev O			Next
Reply		ر Call	

- **1.** A pop-up appears and notifies you of a new text message.
- 2. Select Open.
- 3. Select ▶ to listen to the message. To stop listening to the message, select ■.
  - Select O to hear the message from the beginning.

#### Receiving a Text Message

Some cell phones might not be able to read the transmission log of data sent and data received.

The system does not display any received messages while you are driving. You can only hear them read aloud.

The system can only receive messages that are sent as text (SMS) messages. Messages sent using the data services will not be displayed in the list.

With some phones, you may be able to display up to 20 of the last text messages received.

State or local laws may limit your use of the HFL text message feature. Only use the text message feature when conditions allow you to do so safely.

Depending on the status of the A-zone, the received message screen may be displayed on the B-zone.

## Selecting a Phone

You can select one from the *Bluetooth*<sup>®</sup> device list to be active and receive notifications.

Change Connected Phone	
Notifications	
Saved Replies Customer list of saved replies	

- **1.** Press the **1** (home) button.
- 2. Select Messages.
- 3. Select MENU.
- 4. Select Change Connected Phone.
- **5.** Change a desired phone.

To change the currently paired phone P. 397

#### Selecting a Phone

You can only receive notifications from one phone at a time.

You can only connect one device to use both text message function and *Bluetooth*<sup>®</sup> hands-free phone function.

If there is a connection to Apple CarPlay or Android Auto, a message will appear if this setting is selected allowing the user to end the Apple CarPlay or Android Auto session and continue with the setting.

## Displaying Messages



.....

Next

i.

Call

- **1.** Press the **1** (home) button.
- 2. Select Messages.
- 3. Select Inbox.
- **4.** Select a message.
  - ► The message information is displayed.
- 5. Select View Message.
  - ► The text message is displayed.

#### Displaying Messages

The 📴 icon appears next to an unread message.

If you delete a message on the phone, the message will also be deleted from the system. If you send a message from the system, the message goes to your phone's outbox.

To see the previous or next message, select **Prev** or **Next** on the message screen.

Information

Prev

BBB

•

Rephy

412



## Read or Stop reading a message

- **1.** Display the message information.
- 2. Select ►.
  - ► The system starts reading the message aloud.
- **3.** Select **I** to stop reading.

Select **s** again to start reading the message.

- ► While listening to the message, select
  - to start reading the message from the beginning.



#### Reply to a message

- **1.** Display the message information.
- 2. Select Reply.
- **3.** Select the reply message.
  - ► The pop-up menu appears on the screen.
- 4. Select **Send** to send the message.
  - Message sent appears on the screen when the reply message was successfully sent.

#### Reply to a message

The available reply messages are as follows:

- I'm on my way.
- I'm running late.
- No
- ОК
- Talk to you later, I'm driving.
- Yes

The display language of the default reply message depends on the connected phone.

#### To edit a reply message P. 415

You can add or delete a reply message by selecting **Saved Replies**.

- To edit a reply message P. 415
- Discrete the second sec

Only certain phones receive and send messages when paired and connected. For a list of compatible phones:

- U.S.: Visit www.handsfreelink.com/Acura, or call 1-888-528-7876.
- Canada: For more information on smartphone compatibility, call 1-855-490-7351.



# Saved Replies Reset to Default Create New Message I'm on my way: I'm running late. No

## ■ To edit a reply message

- 1. Press the 🕋 (home) button.
- 2. Select Messages.
- 3. Select MENU.
- 4. Select Saved Replies.
- 5. Select Create New Message.
- **6.** Use the A-zone touchpad to write a reply. When you finish writing you message, press the A-zone touchpad.
  - You can enter the number using the onscreen keyboard. Select KEYBOARD located to the upper right of the screen.

#### To delete a reply message

- 1. Press the 🕋 (home) button.
- 2. Select Messages.
- 3. Select MENU.
- 4. Select Saved Replies.
- 5. Select a reply message you want to delete.
  - A confirmation screen appears on the screen. Select **Delete**.
  - ► To cancel the delete, press the (back) button.

#### ≥To delete a reply message

#### **Reset to Default**

Select to reset all reply messages to their factory default.



## Making a call to a sender

Display the message information.
 Select Call.

#### Models with head-up display

#### Displaying message on the head-up display

You can read a text message on the head-up display only when a text message is received.

- **1.** Move right the left selector wheel to select **Open**.
- 2. Roll up or down the left selector wheel to select **Reply**, and then press the left selector wheel.
  - Select **Call** to dial a call.
  - Select **Repeat** to start reading the message from the beginning.
- **3.** Roll up or down the left selector wheel to select a message, and then press the left selector wheel.
- **4.** Roll up or down the left selector wheel to select **Send**, and then press the left selector wheel.
  - Message sent appears on the head-up display when the reply message was successfully sent.

## Send Message to Contact



- 1. Press the 🕋 (home) button.
- 2. Select Messages.
- 3. Select Send Message to Contact.
- 4. Select a contact name.
  - You can sort by First Name or Last Name. Select the icon on the upper right of the screen.
- 5. Select a number.
- 6. Select the reply message.
  - ▶ The pop-up menu appears on the screen.
- 7. Select Send to send the message.
  - Message sent appears on the screen when the reply message was successfully sent.

#### Send Message to Contact

This feature also allows you to send a message or set a navigation route<sup>\*</sup> to a contact's address.

Making a Call P. 402

Refer to Navigation System Manual

## AcuraLink<sup>®</sup>

Is a subscription-based service that provides convenient features such as voice communication in case of emergency, online security, one-on-one operator assistance, and the transmission of important messages regarding your vehicle's status.

## To Connect to AcuraLink

Use the following procedure to connect to AcuraLink.

## To enable the AcuraLink

You need to allow the consent of the location service to enable the AcuraLink.



- 1. Press the 🕋 (home) button.
- 2. Select AcuraLink.
  - The confirmation message appears on the screen for the first time, then select Allow.

#### ➢AcuraLink<sup>®</sup>

AcuraLink also provides services you can operate from the Internet or your smartphone.

To subscribe to AcuraLink, or to get more information about all of its features, contact an Acura dealer, or visit *owners.acura.com* (U.S.) or *www.acura.ca/owners/acuralink* (Canada).

#### ≥To enable the AcuraLink

You can also set up a **Vehicle Data Collection** by the following procedure.

- 1. Press the 🕋 (home) button.
- 2. Select AcuraLink.
- 3. Select MENU.
- 4. Select Vehicle Data Collection.
- 5. Select Allow or Block.
- Allow: Sends the vehicle location data, diagnostic information, driving behavior data and phone data when you have previously allowed it when you connect a phone with *Bluetooth*<sup>®</sup>.
- **Block**: Does not send the vehicle location data, diagnostic information, driving behavior data.

For detail information of all data shared visit *https://acuralink.acura.com/#/acuralinkLegalTerms* 

## To link with AcuraLink



You may see the connection guide screen after launching AcuraLink when there is no phone connection available.

**Continue Without Connecting:** Displays the AcuraLink menu screen without phone connection.

**Connect Phone:** Displays the *Bluetooth*<sup>®</sup> setup screen.

To change the currently paired phone P. 397

#### 

We recommend that you install the AcuraLink app in your smartphone to make AcuraLink more functional. Contact an Acura dealer, or visit *owners.acura.com* (U.S.) or *www.acura.ca/owners/ acuralink* (Canada).

If you do not connect a phone to AcuraLink, Last Mile function of AcuraLink app is disabled.

#### ≫AcuraLink

You can also select **AcuraLink** from the **All Apps** screen.

Audio/Information Screen P. 264

## AcuraLink

Press the (home) button.
 Select AcuraLink.



#### Vehicle Notifications

Displays the diagnostic information, recall or important safety information<sup>\*1</sup>, or general information by connecting to the Acura server using HFL.

#### Contact Acura

Connect to the AcuraLink operator when trying to find a destination or for roadside assistance.

#### My Acura Dealer

Calls your Acura dealer using HFL or sets a destination of the navigation  $^{\ast}$  to the dealer.

#### MENU

Displays the AcuraLink menu screen.

- Vehicle Data Collection: Displays the AcuraLink connection setting screen. ➡ To enable the AcuraLink P. 419
- AcuraLink Subscriptions: Displays your current AcuraLink subscription status.
- **Connect Bluetooth Device**: Displays the *Bluetooth*<sup>®</sup> setup screen.
  - To change the currently paired phone P. 397

\*1: When you select **Roadside Assistance**, the system connect to the AcuraLink operator through the telematics control unit (TCU).


\* Not available on all models

## ■Vehicle Notifications

Some messages can be deleted manually; some others will automatically disappear when the malfunction is fixed, contact a dealer if necessary.

## AcuraLink Message

You can check the messages that are received quickly in the shortcut operation.



- **1.** A notification appears and notifies you of a new message on the B-zone.
- **2.** Select the system status icon then press the B-zone touchpad.
  - ► The status area list appears on the Azone.
  - A notification is continuously displayed in the header area until the new message is read.
- 3. Select a new message to open.
  - If you have selected the update option for AcuraLink, follow the directions on the screen to complete the process.

#### ➢AcuraLink Message

When you update AcuraLink, you must keep the engine running and maintain a constant connection with AcuraLink.

If the update is interrupted, the system will automatically resume the process. If, however, a week has elapsed since the process was first interrupted, you must repeat the process from the beginning.

## In Case of Emergency

#### Automatic collision notification



If your vehicle's airbags deploy or if the unit detects that the vehicle is severely impacted, your vehicle automatically will attempt to connect to an E911 operator through your connected cellular phone. If connected, information about your vehicle and its location can be sent to the operator<sup>\*1</sup>; you also can speak to the operator when connected.

**IMPORTANT:** For the vehicle equipped with AcuraLink Assist, owner activation constitutes authorization for Acura to collect information from your vehicle needed to provide the service. In a crash, AcuraLink Assist will attempt to notify emergency services but ACURA CANNOT GUARANTEE THAT SUCH NOTIFICATION WILL OCCUR.

Acura reserves the right to terminate AcuraLink services at any time or for any reason, and in the future may not be able to provide services due to changes in, or obsolescence of, technology integral to the service or changes in governmental regulation.

\*1: Depending on your phone and its cellular coverage, your vehicle's location may not be sent to the operator.

#### ➢In Case of Emergency

Your vehicle may not be able to connect to the operator if its, or your cellular phone's, battery level is low, the line is disconnected, or you do not have adequate cellular coverage.

You cannot use this emergency services when:

- You travel outside your cellular provider's coverage areas.
- There is a problem with the connecting devices, such as the microphones or speakers, or your connected phone itself.

You cannot operate other phone-related functions using the screen while talking to the operator. Only the operator can terminate the connection to your vehicle.

#### ➢Automatic collision notification

If the unit fails to connect to the operator, it repeatedly tries until it succeeds.

#### Manual operator connection



If you need to talk to the AcuraLink operator in a situation where no airbag has deployed, you can manually connect to them by pressing the **ASSIST** button with the power mode in ACCESSORY or ON.

- **1.** Open the cover attached to the ceiling console.
- 2. Press the ASSIST button.
  - You are connected to the AcuraLink operator.

#### Manual operator connection

Do not press the button while driving. When you need to contact the operator, park the vehicle in a safe place.

If the unit fails to connect to the operator, it automatically cancels the action after three minutes.

If necessary, the cover can be broken to access the **ASSIST** button.

## Operator Assistance

Connect to the AcuraLink operator when trying to find a destination or for roadside assistance.



Audio/Information screen when connected to the AcuraLink operator

**1.** Press the **LINK** button.

Connection to the operator begins.

- 2. Talk to the operator.
  - To disconnect, select End Call on the audio/information screen or move to left the left selector wheel.


#### ➢Operator Assistance

Remain attentive to road conditions and driving during operator assistance.

If you want to add or renew a subscription, call the Operator Assistance.

- 1. Press the 🕋 (home) button.
- 2. Select AcuraLink.
- 3. Select MENU.
- 4. Select AcuraLink Subscriptions.
- 5. Select Call AcuraLink Support.

Press the (back) button to return to the previous screen, and then in call screen displayed on the B-zone.



## Connection Features

Your subscribed telematics service provider can check your vehicle's condition. For maximum functionality, download AcuraLink app in your smartphone and connect it with the vehicle.

#### Automatic Collision Notifications

A live agent will reach out and check on you and request that help be sent in the event of a crash.

#### Send Destination

Search for destinations on your phone and instantly beam turn-by-turn directions to your navigation system<sup>\*</sup>. Requires In-vehicle Navigation System<sup>\*</sup>.

#### Stolen Vehicle Locator

In the event of a stolen vehicle, your vehicle will help local authorities recover it.

#### Remote Start & Stop

Arrive at your vehicle with the engine warmed up and the interior set to a comfortable temperature.

#### Remote Lock & Unlock

Lock and unlock your vehicle with your smartphone.

#### Find My Car

Find your parked vehicle and flash/sound your horns remotely using your smartphone.

#### Connection Features

The contact information of your provider, your user ID and PIN will be given when you subscribe to AcuraLink. If you forget any of the above, contact a Acura dealer, or go to *owners.acura.com* (U.S.) or *www.acura.ca/owners/acuralink* (Canada).

You can also activate the remote door lock/unlock and vehicle finder features from the Internet or using your smartphone app. Ask a dealer, or visit *owners.acura.com* (U.S.) or *www.acura.ca/owners/ acuralink* (Canada) for details.

#### ≫Find My Car

The lights will stop flashing and horn will stop sounding under the following:

- When conditions 30 seconds have elapsed.
- You unlock the doors using the remote transmitter.
- You unlock the doors using the keyless access system.
- You unlock the doors using the built-in key.
- The power mode is set to ACCESSORY or ON.

#### Vehicle Status

Get door and lock status as well as mileage, fuel, oil life, and tire pressure readings on your phone.

#### Emergency Call

A live agent will stay on the call with you and request that help be sent in the event of an emergency.

#### Security Alarm Alert

Receive alerts if vehicle security alarm is triggered.

#### Destination by Voice

Talk to a live assistant who will search and send turn by turn directions to your vehicle's navigation system<sup>\*</sup>. Requires In-vehicle Navigation System<sup>\*</sup>.

#### Last Mile

Receive walking directions to your final destination right when you get out of your Acura. Requires In-vehicle Navigation System<sup>\*</sup>.

#### Geofence Alert

Receive a notification anytime your vehicle enters or leaves a region set by you.

#### Speed Alert

Receive a notification when your vehicle has exceeded a speed limit set by you.

This page intentionally left blank.

# Driving

This chapter discusses driving and refueling.

Before Driving Towing a Trailer	
Off-Highway Driving Guidelines	441
When Driving	
Starting the Engine	443
Precautions While Driving	449
Automatic Transmission	450
Shifting	451
Acura Integrated Dynamics System	459
Auto Idle Stop	464
Vehicle Stability Assist™ (VSA®), aka Electr	onic
Stability Control (ESC), System	.471
Agile Handling Assist	473

Super Handling-All Wheel Drive <sup>™</sup> (S	H-
AWD®)*	. 474
Tire Pressure Monitoring System (TP	MS)
with Tire Fill Assist	. 475
Tire Pressure Monitoring System (TP	MS) -
Required Federal Explanation	. 477
Blind Spot Information System	. 479
AcuraWatch <sup>™</sup>	. 483
Collision Mitigation Braking System	M
(CMBS <sup>™</sup> )	486
(CIVIDS /	
Low Speed Braking Control*	
	. 497
Low Speed Braking Control*	. 497 Low

Lane Keeping Assist System (LKAS)	522
Road Departure Mitigation System	530
Traffic Sign Recognition System	535
Front Sensor Camera	541
Radar Sensor	543
Sonar Sensors *	544
Braking	545
Parking Your Vehicle	555
Multi-View Rear Camera*	565
Surround View Camera System*	567
Refueling	575
Fuel Economy and CO <sub>2</sub> Emissions	578
Turbo Engine Vehicle	579

## **Driving Preparation**

Check the following items before you start driving.

## Exterior Checks

- Make sure there are no obstructions on the windows, door mirrors, exterior lights, or other parts of the vehicle.
  - Remove any frost, snow, or ice.
  - Remove any snow on the roof, as this can slip down and obstruct your field of vision while driving. If frozen solid, remove ice once it has softened.
  - ▶ When removing ice from around the wheels, be sure not to damage the wheel or wheel components.
- Make sure the hood is securely closed.
   If the hood opens while driving, your front view will be blocked.
- Make sure the tires are in good condition.
  - Check air pressures, and check for damage and excessive wear.
     Checking and Maintaining Tires P. 614
- Make sure there are no people or objects behind or around the vehicle.
  - ► There are blind spots from the inside.

#### Exterior Checks

#### NOTICE

When doors are frozen shut, use warm water around the door edges to melt any ice. Do not try to force them open, as this can damage the rubber trim around the doors. When done, wipe dry to avoid further freezing.

Do not pour warm water into the key cylinder. You will be unable to insert the key if the water freezes in the hole.

Heat from the engine and exhaust can ignite flammable materials left under the hood, causing a fire. If you've parked your vehicle for an extended period, inspect and remove any debris that may have collected, such as dried grass and leaves that have fallen or have been carried in for use as a nest by a small animal. Also, check under the hood for leftover flammable materials after you or someone else has performed maintenance on your vehicle.

# Interior Checks

- Store or secure all items on board properly.
  - Carrying too much cargo, or improperly storing it, can affect your vehicle's handling, stability, stopping distance, and tires, and make it unsafe.
    - Maximum Load Limit P. 433
- Do not pile items higher than the seat height.
  - They can block your view and may be thrown forward in the event of sudden braking.
- Do not place anything in the front seat footwells. Make sure to secure the floor mat.
  - An object or unsecured floor mat can interfere with your brake and accelerator pedal operation while driving.
- If you have any animals on board, do not let them move around in the vehicle.
   They may interfere with driving and a crash could occur.
- Securely close and lock all doors and the tailgate.

Locking/Unlocking the Doors from the Inside P. 169

- Adjust your seating position properly.
  - Adjust the head restraint, too.

Seats P. 216

### Adjusting the Front and Rear Outer Head Restraint Positions P. 225

- Adjust the mirrors and steering wheel properly.
  - Adjust them while sitting in the proper driving position.

Adjusting the Steering Wheel P. 212

➢ Mirrors P. 213

### Minterior Checks

The headlight aim is set by the factory, and does not need to be adjusted. However, if you regularly carry heavy items in the cargo area or tow a trailer, have the aiming readjusted at a dealer or by a qualified technician.

- Be sure items placed on the floor behind the front seats cannot roll under the seats.
  - ► They can interfere with the driver's ability to operate the pedals, the operation of the seats, or the operation of the sensors under the seats.
- Everyone in the vehicle must fasten their seat belt.

Fastening a Seat Belt P. 42

- Make sure that the indicators in the instrument panel come on when you start the vehicle, and go off soon after.
  - Always have a dealer check the vehicle if a problem is indicated.
    - Indicators P. 80

# **Maximum Load Limit**

The maximum load for your vehicle is 838 lbs (380 kg). See the Tire and Loading Information label attached to the driver's doorjamb.

Label Example	TIRE AND LOADING INFORMATION SEATING CAPACITY TOTAL 5 FRONT 2 REAR 3 The combined weight of occupants and cargo should never exceed XXXkg or XXXIbs.			
	TIRE	SIZE	COLD TIRE PRESSURE	SEE OWNER'S
	FRONT	XXXX/XXXXX XXX	XXXKPA, XXPS1	MANUAL FOR ADDITIONAL
	REAR		XXXKPA, XXPS1	
	SPARE	XXXX/XXXXX XXXX	XXXKPA, XXPS I	INFORMATION

This figure includes the total weight of all occupants, cargo, and accessories, and the tongue load if you are towing a trailer.

Steps for Determining Correct Load Limit -

- (1) Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3) Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- (4) The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1,400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. (1,400 750 (5 x 150) = 650 lbs.)

≫Maximum Load Limit

# 

Overloading or improper loading can affect handling and stability and cause a crash in which you can be hurt or killed.

Follow all load limits and other loading guidelines in this manual.

Gross Vehicle Weight Rating (GVWR):

The maximum allowable weight of the vehicle, all occupants, all accessories, all cargo, and the tongue load.


Specifications P. 690

Gross Axle Weight Rating (GAWR):

The maximum allowable weight of the vehicle axle. **Specifications** P. 690

(5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.(6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

In addition, the total weight of the vehicle, all occupants, accessories, cargo, and trailer tongue load must not exceed the Gross Vehicle Weight Rating (GVWR) or the Gross Axle Weight Rating (GAWR). Both are on a label on the driver's doorjamb.



≫Maximum Load Limit

Towing a Trailer:


See Towing a Trailer to determine whether your vehicle is designed to tow a trailer.

Towing a Trailer P. 435

# **Towing Preparation**

# Towing Load Limits

Your vehicle can tow a trailer if you carefully observe the load limits, use the proper equipment, and follow the towing guidelines. Check the load limits before driving.



Total trailer weight

Do not exceed the maximum allowable weight of the trailer, cargo, and everything in or on it shown in the table. Towing loads in excess of this can seriously affect vehicle handling and performance and can damage the engine and drivetrain.

Number of occupants	2WD models	AWD models
2	1,500 lbs (680 kg)	1,500 lbs (680 kg)
3	1,500 lbs (680 kg)	1,300 lbs (590 kg)
4	1,400 lbs (635 kg)	1,150 lbs (522 kg)
5	600 lbs (272 kg)	600 lbs (272 kg)

Each weight limit is calculated based on the following conditions:

- Occupants fill seats from the front of the vehicle to the back
- Each occupant weighs 150 lbs (68 kg)
- Each occupant has 17.6 lbs (8 kg) cargo in the cargo area.

Any additional weight, cargo or accessories reduce the maximum trailer weight and maximum tongue load.

### ➢Towing Load Limits

# 

Exceeding any load limit or improperly loading your vehicle and trailer can cause a crash in which you can be seriously hurt or killed.

Check the loading of your vehicle and trailer carefully before starting to drive.

Check if all loads are within limits at a public scale. If a public scale is not available, add the estimated weight of your cargo load to the weight of your trailer (as quoted by the manufacturer), and the tongue load.


When using a detachable towing device, always remove the towing device when not in use and only install it when towing so that it does not cover or hide anything on the rear of your vehicle, such as the exterior lights or licence plate.

### Break-in Period.

Avoid towing a trailer during your vehicle's first 600 miles (1,000 km).

Never exceed the gross weight ratings. Gross weight information

Vehicle Specifications P. 690



### Tongue load

The weight of the tongue with a fully loaded trailer on the hitch should be approximately 10% of the total trailer weight.

- Excessive tongue load reduces front tire traction and steering control. Too little tongue load can make the trailer unstable and cause it to sway.
- To achieve a proper tongue load, start by loading 60% of the load toward the front of the trailer and 40% toward the rear. Readjust the load as needed.

# Towing Equipment and Accessories

Towing equipment varies by the size of your trailer, how much load you are towing, and where you are towing.

### Hitches

The hitch must be of an approved type and properly bolted to the underbody.

### Safety chains

Always use safety chains when you tow a trailer. Leave enough slack to allow the trailer to turn corners easily, but do not allow the chains to drag on the ground.

### Trailer brakes

Recommended for any trailer with a total weight of 1,000 lbs (450 kg) or more: There are two common types of trailer brakes: surge and electric. Surge brakes are common for boat trailers, since the brakes will get wet. If you choose electric brakes, be sure they are electronically actuated. Do not attempt to attach trailer brakes to your vehicle's hydraulic system, as it will lower braking effectiveness and create a potential hazard.

### Additional towing equipment

Many states and provinces/territories require special outside mirrors when towing a trailer. Even if mirrors are not required in your locale, you should install special mirrors if visibility is restricted in any way.

#### ➢Towing Equipment and Accessories

Make sure that all equipment is properly installed and maintained, and that it meets federal, state, province/ territory, and local regulations.

Consult your trailer maker for proper installation and setup of the equipment.


Improper installation and setup can affect the handling, stability, and braking performance of your vehicle.

Consult your trailer sales or rental agency if any other items are recommended or required for your towing situation.

The lighting and wiring of trailers can vary by type and brand. If a connector is required, it should only be installed by a qualified technician.

# Trailer light

Trailer lights and equipment must comply with federal, state, province/territory, and local regulations. Check with your local trailer sales or rental agency for the requirements in the area where you plan to tow.



We recommend that you have a dealer install an Acura wiring harness and converter.

They are designed for your vehicle.

### ■Trailer light

The trailer lighting connector is located behind the left side panel in the cargo area.

Even if you are planning to use the non-Acura trailer lighting harness and converter, ask a dealer for the correct connector and pins.

# **Driving Safely with a Trailer**

# Things You Need To Know Before Towing a Trailer

- Have the trailer properly serviced and keep it in good condition.
- Make sure that all the weights and load in the vehicle and trailer are within limits.
   Towing Load Limits P. 435
- Securely attach the hitch, safety chains, and other necessary parts to the trailer.
- Securely store all the items in and on the trailer so that they do not shift while driving.
- Check if the lights and brakes on the trailer are working properly.
- Check the pressures of the trailer tires.
- Turn off the Auto Idle Stop system using the Auto Idle Stop **OFF** button. The trailer weight can affect your vehicle's brake effectiveness if Auto Idle Stop is activated on a hill while towing a trailer.

### Models with Parking Sensor System

Turn off the rear parking sensor system.
 Turning off All Rear Sensors P. 560

### Models with Low Speed Braking Control

• Turn off the Low Speed Braking Control system. It may activate if it detects the towed object as an obstacle.

System On and Off P. 499

#### Driving Safely with a Trailer

Operating speed when towing a trailer must not exceed 62 mph (100 km/h).

### Parking

In addition to the normal precautions, place wheel chocks at each of the trailer's tires.

Remember to unhitch the trailer before changing a flat tire. Ask the trailer sales or rental agency where and how to store the trailer's spare tire.

### Towing Speeds and Gears

- Drive slower than normal.
- Obey posted speed limits for vehicles with trailers.
- Use the **D** position when towing a trailer on level roads.

# Turning and Braking

- Turn more slowly and with a wider turning arc than normal.
- Allow more time and distance for braking.
- Do not brake or turn suddenly.

# Driving in Hilly Terrain

- Monitor your temperature gauge. If it nears the red (H) mark, turn off the climate control system and reduce speed. Pull to the side of the road safely to cool down the engine if necessary.
- Put the transmission into **S** if the transmission shifts frequently.

# **Towing Behind a Motorhome**

Your vehicle is not designed to be towed behind a motor home. If your vehicle needs to be towed in an emergency, refer to the emergency towing information.

Emergency Towing P. 685

#### ➢Towing Speeds and Gears

When towing a fixed-sided trailer (e.g., camper), do not exceed 55 mph (88 km/h). At higher speeds, the trailer may sway or affect vehicle handling.

# **General Information**

Your vehicle has been designed primarily for use on pavement, however, its higher ground clearance allows you to occasionally travel on unpaved roads. It is not designed for trail-blazing, or other challenging off-highway activities.

If you decide to drive on unpaved roads, you will find that it requires somewhat different driving skills and that your vehicle will handle somewhat differently than it does on pavement. Pay attention to the precautions and tips in this section, and get acquainted with your vehicle before leaving the pavement.

# **Important Safety Precautions**

To avoid loss of control or rollover, be sure to follow all precautions and recommendations:

- Be sure to store cargo properly and do not exceed your cargo load limits.
   Maximum Load Limit P. 433
- Whenever you drive, make sure you and your passengers always wear seat belts.
- Keep your speed low, and never go faster than the conditions allow.
- It's up to you to continually assess the situation and drive within the limits.

➢Off-Highway Driving Guidelines

# 

Improperly operating this vehicle on or offpavement can cause a crash or rollover in which you and your passengers could be seriously injured or killed.

- Follow all instructions and guidelines in this owner's manual.
- Keep your speed low, and don't drive faster than conditions permit.

Failure to operate your vehicle correctly might result in a crash or a rollover.

- Important Handling Information P. 34
- Precautions While Driving P. 449

### Models with SH-AWD®

Spinning the tires can also damage the SH-AWD<sup>®</sup> system.

# **Avoiding Trouble**

- **Check Out Your Vehicle** before you leave the pavement and make sure that all scheduled maintenance has been completed. Pay special attention to the condition of the tires, and check the tire pressures.
- **Remember** the route you choose presents limits (too steep or bumpy), you have limits (driving skill and comfort), and your vehicle has limits (traction, stability, and power). Failing to recognize these limits will likely put you and your passengers in a hazardous situation.
- Accelerating and Braking should be done slowly and gradually. Trying to start or stop too fast can cause a loss of traction and you could lose control.
- Avoiding Obstacles and Debris in the road reduces the likelihood of a rollover or damage to your suspension or other components.
- **Driving on Slopes** increases your risk of a rollover, particularly if you attempt to drive across a slope that is too steep. Going straight up or down a slope is usually the safest. If you can't clearly see all conditions or obstacles on a slope, walk it before you drive it. If there is any doubt whether you can safely pass, don't try it. Find another route. If you get stuck when climbing, do not try to turn around. Back down slowly following the same route you took up the hill.
- **Crossing a Stream** Avoid driving through deep water. If you encounter water in your route (a small stream or large puddle, for example), evaluate it carefully before going ahead. Make sure it is shallow, flowing slowly, and has firm ground underneath. If you are not sure of the depth or the ground, turn around and find another route. Driving through deep water can also damage your vehicle. The water can get into the transmission and differential, diluting the lubricant and causing an eventual failure. It can also wash the grease out of the wheel bearings.
- If You Get Stuck, carefully go in the direction that you think will get you unstuck. Do not spin the tires as this will only make things worse and could damage the transmission. If you are unable to free yourself, your vehicle will need to be towed. Front tow hooks are provided for this purpose.

# **Starting the Engine**

# Electric Parking Brake Switch

 Make sure the parking brake is applied.
 The Parking Brake and Brake System indicator (red) comes on for 30 seconds when you press the electric parking brake switch.

**2.** Depress the brake pedal.

### Starting the Engine

Keep your foot firmly on the brake pedal when starting the engine.

The engine is harder to start in cold weather and in thinner air found at altitudes above 8,000 feet (2,400 meters).

When starting the engine in cold weather, turn off all electrical accessories such as the lights, climate control system, and rear defogger in order to reduce battery drain.


If you live in a region where winter is extremely cold, an engine block heater will improve starting and warming of the engine. Consult a dealer for details.

If the exhaust system sounds abnormal or you can smell exhaust gas inside the vehicle, have your vehicle checked by a dealer. There may be a problem with the engine or exhaust system.

Bring the keyless remote close to the **ENGINE START/STOP** button if the battery in the keyless remote is weak.

► If the Keyless Remote Battery is Weak P. 665

The engine may not start if the keyless remote is subjected to strong radio waves.





 Press the ENGINE START/STOP button without depressing the accelerator pedal.

### Starting the Engine

Do not hold the **ENGINE START/STOP** button to start the engine.

If the engine does not start, wait at least 30 seconds before starting the engine again.


The immobilizer system protects your vehicle from theft. If an improperly coded device is used, the engine's fuel system is disabled.

Immobilizer System P. 183

# Remote Engine Start\*

You can remotely start the engine using the two-way keyless remote from extended distances.

### To start the engine



The engine runs for up to 10 minutes without you starting the vehicle. To extend the run time for another 10 minutes during the first run, press the button, then press and hold the

► The amber LED blinks, then the green LED comes back on if a 10-minute extension request was transmitted successfully.

After pressing the <u>a</u> button, wait for the green LED to blink. This indicates that the all the doors and the tailgate are locked.

\* Not available on all models

# 

Carbon monoxide gas is toxic and can rapidly accumulate in closed or even partly enclosed areas.


Breathing it can cause unconsciousness and even kill you.

Never use the remote engine starter with the vehicle parked in a garage or other areas with limited ventilation.

The remote engine start may violate local laws. Before using the remote engine start, check your local laws.

If there are buildings and obstacles between your vehicle and the remote, the range will be reduced. This distance may vary by external electrical interference.

# ■ To stop the engine



#### Remote Engine Start\*

The engine may not start by the remote engine start if:

• You have disabled a remote engine start setting using the audio/information screen.

### **Customized Features** P. 359

- The power mode is not in VEHICLE OFF.
- The transmission is in a position other than **P**.
- The hood is open, or any door or the tailgate is unlocked.
- The 12-volt battery temp is too low or the 12-volt battery charge is too low.
- You have already used the remote twice to start the engine.
- Another registered keyless remote is in the vehicle.
- There is any antenna failure.
- The door is unlocked with the built-in key.
- The engine oil pressure is low.
- The engine coolant temperature is extremely high.
- The telematics unit malfunctions.
- The security system alarm is not set.

Before starting the engine, make sure to check the door lock status using the remote. When you press the <u>a</u> button, wait for the green LED to blink. If the red LED turns on, the doors and tailgate did not lock, and the engine does not start.

#### Remote Engine Start\*

While the engine is running, the vehicle will automatically precondition inside the vehicle. When it is warm outside:

- The climate control system is activated in recirculation mode.
- The seat ventilator\* is activated. When it is cold outside:
- The defroster is activated at a moderately warm temperature.
- The rear defogger and door mirror heaters are activated.
- The front seat heaters and heated steering wheel are activated.

Heated Steering Wheel\* P. 244
 Front Seat Heaters/Ventilators\* P. 245

# Starting to Drive

### When the engine was started using the keyless remote\*

1. Depress and hold the brake pedal, then press the ENGINE START/STOP button.

#### When the engine was started in any case

- 2. Keeping your right foot on the brake pedal, put the transmission into D. SelectR when reversing.
- **3.** With the parking brake applied, release the brake pedal and gently depress the accelerator pedal.
  - Make sure the Parking Brake and Brake System indicator (red) goes off.
     Parking Brake P. 545

### Hill start assist system

Hill start assist keeps the brake engaged briefly to help prevent the vehicle from rolling on inclines as you move your foot from the brake pedal to the accelerator.

Put the transmission into D or S when facing uphill, or R when facing downhill, then release the brake pedal.

# Stopping the Engine

You can turn the engine off when the vehicle is completely stopped.

- **1.** Depress the brake pedal and change the shift position to **P**.
  - ► Do not release the brake pedal until you have confirmed that **P** is shown on the gear position indicator.
- 2. Press the ENGINE START/STOP button.

#### Starting to Drive

You can also release the parking brake by pulling the electric parking brake switch while depressing the brake pedal. When facing downhill, you can start your vehicle more smoothly by manually releasing it with the electric parking brake switch than by releasing it with the accelerator pedal.

### When the engine was started using the keyless remote\*

The engine stops when the transmission is taken out of P before the **ENGINE START/STOP** button is pressed. Follow step 1 when starting to drive.

#### ➢Hill start assist system

Hill start assist may not prevent the vehicle from rolling downhill on a very steep or slippery slope, and will not operate on small inclines.

Hill start assist will operate even when  $\mathsf{VSA}^{\circledast}$  is switched off.

Hill start assist is not a replacement for the parking brake.

# **Precautions While Driving**

# Driving Guidelines for Your Utility Vehicle

Utility vehicles have a significantly higher rollover rate than other types of vehicles. To prevent rollovers or loss of control:

- Take corners at slower speeds than you would with a passenger vehicle.
- Avoid sharp turns and abrupt maneuvers whenever possible.
- Do not modify your vehicle in any way that you would raise the center of gravity.
- Do not carry heavy cargo on the roof.

Never carry more than 165 lbs (75 kg) of cargo on the roof rack (Acura accessory).

#### ➢Precautions While Driving

### NOTICE

Do not select a shift button while pressing the accelerator pedal. You could damage the transmission.

### NOTICE

If you repeatedly turn the steering wheel at an extremely low speed, or hold the steering wheel in the full left or right position for a while, the electric power steering (EPS) system heats up. The system goes into a protective mode, and limits its performance. The steering wheel becomes harder and harder to operate. Once the system cools down, the EPS system is restored.

Repeated operation under these conditions can eventually damage the system.

If the power mode is set to ACCESSORY while driving, the engine will shut down and all steering and brake power assist functions will stop, making it difficult to control the vehicle.

Do not select [N] while driving as you will lose engine braking (and acceleration) performance.

During the first 600 miles (1,000 km) of operation, avoid sudden acceleration or full throttle operation so as not to damage the engine or powertrain.

# 🔳 In Rain

Avoid driving in deep water and on flooded roads. This can damage the engine or driveline, or cause electrical component failure.

# Other Precautions

If there is a strong impact with something under the vehicle, stop in a safe location. Check the underside of the vehicle for damage or any fluid leaks.

# **Automatic Transmission**

# Creeping

When the engine runs at higher idle speeds, the creeping force increases. Keep the brake pedal firmly depressed when stopped.

# Kickdown

Quickly depressing the accelerator pedal while driving uphill may cause the transmission to drop to a lower gear, unexpectedly increasing vehicle speed. Depress the accelerator pedal carefully, especially on slippery roads and curves.

### Precautions While Driving

Avoid hard braking for the first 200 miles (300 km) after purchasing your new vehicle or replacing the brake pads or rotors, to allow for proper break-in.

### Driving Guidelines for Your Utility Vehicle

Failure to operate your vehicle correctly might result in a crash or a rollover.

Important Handling Information P. 34

# Shifting

Change the gear position in accordance with your driving needs.

# Shift button positions

P. F. C

Ρ

Park

Used when parking, before turning off or starting the engine.



Reverse Used when reversing.



Neutral Transmission is not locked.



# **Drive/S Position**

Each time you press the D/S button, the mode switches between Drive and S Position mode.

Used for:

### Drive

- Normal driving (gears change between 1st and 10th automatically)
- Temporarily driving in the sequential mode

#### S Position

- Automatically changing gears between 1st and 8th (8th gear is used only at high speed)
- Driving in the sequential mode

### ≫ Shiftina

# 

The vehicle can roll away if left unattended without confirming that Park is engaged.

A vehicle that rolls away could cause a crash resulting in serious injury or death.

Always keep your foot on the brake pedal until you have confirmed that P is shown on the gear position indicator.

To prevent malfunction and unintended engagement:


- Do not spill any liquids on or around shift buttons.
- Do not place or drop any objects on or around shift buttons
- Do not let passengers or children operate the shift buttons

The beeper sounds and the message appears on the multi-information display when you depress the accelerator pedal with the gear position in [N].

### Multi-Information Display Warning and Information Messages P. 107

Change the gear position to D or R with the brake pedal depressed.


# ■ P (parking) button



Park your vehicle in a safe place with the power mode in ON, then apply the brakes and press the  $\boxed{P}$  button to put the transmission in Park. The indicators on the sides of the  $\boxed{P}$  button

come on.

# Shift Operation



#### Shift Operation

### NOTICE

When you change  $\boxed{D}$  to  $\boxed{R}$  and vice versa, depress the brake pedal to come to a complete stop, then select the intended gear position while maintaining brake pressure.

When changing the gear position to  $\boxed{\mathbf{P}}$ , always keep your foot on the brake pedal until you have confirmed that  $\boxed{\mathbf{P}}$  is shown on the gear position indicator.

Use the gear position indicator and the shift button indicator to check the gear position before selecting a shift button.

If the indicator of the currently selected gear position, or all the gear position indicators are blinking simultaneously, there is a problem with the transmission.

Avoid sudden acceleration and have the transmission checked by a dealer as soon as possible.

The fuel supply may be cut off if you drive at engine speeds in or over the tachometer red zone (engine speed limit). If this happens, you may experience a slight jolt.

When the engine speed is increased while the transmission is in [N], [P] or [R], the fuel supply may be cut off even without the engine speed entering the tachometer red zone.

### ■ When opening the driver's door

If you open the driver's door under the following conditions, the gear position automatically changes to  $[\mathbf{P}]$ .

- The vehicle is stationary with the engine running, or moving at 1 mph (2 km/h) or slower.
- The transmission is in other than **P**.
- You have unfastened the driver side seat belt.
  - ▶ If you manually change the gear position from P with the brake pedal depressed, the gear position will automatically return to P once you release the brake pedal.

### When turning off the power mode

If you turn the engine off while the vehicle is stationary, and the transmission is in other than  $[\mathbf{P}]$ , the gear position automatically changes to  $[\mathbf{P}]$ .

#### Shift Operation

When shifting gears in extremely low temperatures  $(-22^{\circ}F/-30^{\circ}C)$ , there may be a short delay before the shift is indicated in the display. Always confirm you are in the correct gear before driving.

The beeper sounds once when you change to **ℝ**. **≥** Customized Features P. 359

#### ≥When opening the driver's door

While the system is designed to automatically change the gear position to P under the described conditions, in the interest of safety you should always select P before opening the driver's door. Make sure to park the vehicle in a safe place.

When Stopped P. 555

If you want to drive the vehicle after the gear position has automatically changed to [P] under the described conditions, close the door, fasten the seat belt, depress the brake pedal, then change the gear position.

If you leave the vehicle, turn off the engine and lock the doors.

### ■ If you want to keep the transmission in N position [car wash mode]

With the engine running:

- **1.** Press and hold the brake pedal.
- **2.** Select **N**, then release the button to display **N** (Neutral) hold mode on the multi-information display.
- **3.** Press and hold **N** again for two seconds.
  - This puts the vehicle in car wash mode which must be used when your vehicle is pulled through a conveyor type automatic car wash where you or an attendant do not remain in the vehicle.



If the **ENGINE START/STOP** button is pressed after car wash mode has been activated, the power mode will change to ACCESSORY and a message will be displayed on the multiinformation display.

- ► For 15 minutes the gear position remains in **N** with the power mode in ACCESSORY. After that, the position automatically changes to **P** and the power mode changes to OFF.
- Manually press the ENGINE START/ STOP button cancels ACCESSORY mode. The P indicator comes on and the power mode changes to OFF. You must always press the ENGINE START/ STOP button when car wash mode is no longer needed.

If you want to keep the transmission in N position [car wash mode]

To keep the vehicle in  $\boxed{\mathbf{N}}$  position, you can also follow this procedure:

While the engine is on, select [N], and then within five seconds, press the **ENGINE START/STOP** button.

The transmission may not stay in  $\boxed{\mathbf{N}}$  position while the following indicators are on or when the message below appears:

- Malfunction indicator lamp
- Transmission system indicator
- Charging system indicator
- The **12 Volt Battery Charging System Problem. Do Not Drive.** message on the multi-information display.

# Restrictions on selecting a gear position

You cannot select a gear position under certain circumstances that may lead to a crash.

When the transmission is in:	1. Under these circumstances:	2. If you try to change to the following:	3. The gear position remains in/changes to:	How to change the gear position
P	The brake pedal is not depressed.		Ρ	Release the accelerator
	The accelerator pedal is depressed.			
	The vehicle is moving at low speed without the brake pedal depressed.	Other gear position		pedal and depress the brake pedal.
	The vehicle is moving at low speed with the accelerator pedal depressed.		N	
N, D or S	The vehicle is moving forward.	R		Stop your vehicle in a
R or N	The vehicle is moving backward.	D, S		safe place, depress the brake pedal, and select
R, N, D or S	The vehicle is moving.	Ρ		the appropriate gear position.

# Sequential Mode

Use the paddle shifters to change between 1st and 10th gears without releasing your hands from the steering wheel. The transmission will switch to the sequential mode.

### ■ When the transmission is in D:

The vehicle will go into the sequential mode momentarily, and the sequential mode gear selection indicator will come on.

When the vehicle goes into the sequential mode by — paddle shifter and the lower gear is available, the transmission properly selects single or double gear change.

Once you start traveling at a constant speed, the sequential mode will automatically switch off, and the sequential mode gear selection indicator will go off.

Hold the + paddle shifter for two-seconds or push the D/S button to return to normal drive.

### ■ When the transmission is in S:


The vehicle will go into the sequential mode, and the  $\mathbf{M}$  (sequential mode) indicator and sequential mode gear selection indicator will come on.

If the vehicle speed increases and the engine speed reaches near the tachometer red zone, the transmission automatically shifts up to the next gear.

You can cancel this mode by holding the + paddle shifter for two seconds or push the D/S button. When the sequential mode is canceled, the sequential mode indicator and sequential mode gear selection indicator go off.

### Sequential Mode

The sequential mode may be canceled if the Dynamic Mode is changed to another dynamic mode.



#### Sequential Mode Operation

Each paddle shift operation makes a single or double gear change.

To change gears continuously, release the paddle shifter before pulling it again for the next gear.

If the sequential mode gear selection indicator blinks when you try to shift up or down, this means your vehicle speed is not in its allowable gear range or the protection of transmission system is necessary. Slightly accelerate to shift up and decelerate to shift down while the indicator is blinking.



The transmission is in [S] and **Sport** mode, to prioritize the engine performance enhancement, the transmission may not allow for shifting up while the engine speed is low.

# **Acura Integrated Dynamics System**

Modifies the dynamic character of the vehicle. There are four modes to select from: **COMFORT**, **NORMAL**, **SPORT**, and **SNOW**.


Turn the **Dynamic Mode** switch to select a mode. The mode you have selected appears on the audio/information screen.

➢Acura Integrated Dynamics System

The mode may not be able to be changed when:

- The vehicle is turning
- The VSA® system is activating
- There is a problem with the engine, transmission, the brake system, the VSA®, the EPS, the Active Damper System<sup>\*</sup>, or the SH-AWD<sup>®\*</sup>

# Selecting the Dynamic Mode



### Mode descriptions

Each mode has been crafted for different driving styles according to the following chart.

Mode	Function	Accent Light Color <sup>*1</sup>
SNOW	Maximizes controllability through reduced throttle response When in <b>SNOW</b> , the Auto Idle Stop System will stay disabled regardless of the Auto Idle Stop <b>OFF</b> button <b>2</b> Auto Idle Stop P. 464	White
COMFORT	Maximizes driver comfort through decreased steering effort and reduced ride firmness (if Active Damper System is equipped)	Blue
NORMAL	Balanced response for everyday use	White
SPORT	Enhances vehicle response through increased steering effort, heightened throttle response, modified active sound control, and more responsive ride and/or handling (if Active Damper System and/or SH-AWD® is equipped) When in <b>SPORT</b> , the Auto Idle Stop System will stay disabled regardless of the Auto Idle Stop <b>OFF</b> button Auto Idle Stop P. 464	Red

\*1:Interior accent light only available if equipped. Interior accent light changes with **Dynamic Mode** only when **Accent Light Theme** is \_\_\_\_\_\_set to **Dynamic Mode**.

Customized Features P. 359

Lighting area of the accent light P. 463

### Next start-up mode

The mode for the next start-up is saved according to the following chart. Each keyless remote has its own mode saved.

Last Dynamic Mode	Next Dynamic Mode	Welcome Accent Light Color*1
SNOW	NORMAL	White
COMFORT	COMFORT	Blue
NORMAL or SPORT	NORMAL	White


\*1:Interior accent light only available if equipped. Interior accent light changes with Dynamic Mode only when Accent Light Theme is set to Dynamic Mode. Customized Features P. 359

Lighting area of the accent light P. 463

# Lighting area of the accent light

Interior accent light only available if equipped. Interior accent light changes with **Dynamic Mode** only when **Accent Light Theme** is set to **Dynamic Mode**.

Customized Features P. 359



Lighting Area of the Accent Light

# Auto Idle Stop

To help maximize fuel economy, the engine automatically stops when the vehicle comes to a stop, depending on environmental and vehicle operating conditions. The indicator (green) comes on at this time.



Auto Idle Stop Indicator (Green) The environmental and vehicle conditions that impact Auto Idle Stop system operation are varied.

Auto Idle Stop Activates When: P. 467, 468

The engine then restarts once the vehicle is about to move again, and the indicator (green) goes off.

The Engine Automatically Restarts When: P. 469

If the driver's door is opened while the indicator (green) comes on, a buzzer sounds to notify you that the Auto Idle Stop function is in operation.

A message associated with Auto Idle Stop appears on the multi-information display.

### ≫Auto Idle Stop

The 12-volt battery installed in this vehicle is specifically designed for a model with Auto Idle Stop. Using a 12-volt battery other than this specified type may shorten the 12-volt battery life, and prevent Auto Idle Stop from activating. If you need to replace the 12-volt battery, make sure to select the specified type. Ask a dealer for more details.



The Auto Idle Stop suspend indicator comes on and a message appears on the multiinformation display. when the Auto Idle Stop system cannot be activated.

Indicators P. 80

Auto Idle Stop System ON/OFF P. 466

# Auto Idle Stop System ON/OFF



To turn the Auto Idle Stop system off, press this button. The Auto Idle Stop system stops.

Auto Idle Stop system will stop, the indicator will come on and a message appears on the multi-information display.

The Auto Idle Stop system is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle.

#### ➢Auto Idle Stop System ON/OFF

If you turn off the Auto Idle Stop system while it is activated, the engine will restart.

### Auto Idle Stop Activates When: P. 467

If you hold the Auto Idle Stop **OFF** button, you can disable idle stop messages.

Indicators P. 80

# Auto Idle Stop Activates When:

The vehicle stops with the gear position in D and the brake pedal depressed. When you put the transmission into P, the Auto Idle Stop continues to operate, even if the brake pedal is released.

▶ If you depress the brake pedal, the engine may automatically restart.

## Auto Idle Stop does not activate when:

- The Auto Idle Stop **OFF** button is pressed.
- The driver's seat belt is not fastened.
- The engine is not adequately warmed up or coolant temperature is high.
- The transmission fluid temperature is low or high.
- The vehicle comes to a stop again before the vehicle speed reaches 3 mph (5 km/h) after the engine starts.
- The vehicle is stopped on a steep incline.
- The transmission is in a position other than **D**.
- The engine is started with the hood open.
  - ► Turn off the engine. Close the hood before you restart the engine to activate Auto Idle Stop.
- The battery charge is low.
- The internal temperature of the battery is 14°F (-10°C). or less.
- The climate control system is in use, and the outside temperature is below -4°F (-20°C) or over 104°F (40°C).
- The climate control system is in use, and the temperature is set to Hi or Lo.
- 🗑 is ON (indicator on).
- The Integrated Dynamics System mode is changed to **SNOW** or **SPORT** mode.

Auto Idle Stop Activates When:

Do not open the hood while the Auto Idle Stop function is activated. If the hood is opened, the engine will not restart automatically.

In this case, restart the engine with the **ENGINE START/STOP** button.

Starting the Engine P. 443

When ACC with Low Speed Follow is in operation, the vehicle stops without depressing the brake pedal and Auto Idle Stop may activate.

Pressing the **ENGINE START/STOP** button causes the engine to no longer restart automatically. Follow the standard procedure to start the engine.

Starting the Engine P. 443

#### Auto Idle Stop may not activate when:

- The vehicle is stopped by braking suddenly.
- The steering wheel is operated.
- Altitude is high.
- The climate control system is in use, and there is a significant difference between the set temperature and the actual interior temperature.
- The climate control system is in use, and humidity in the interior is high.

# The Engine Automatically Restarts When:

- The brake pedal is released (without the automatic brake hold system activated).
- The accelerator pedal is depressed (with the automatic brake hold system activated).

Automatic Brake Hold P. 550

#### ■ The engine restarts even if the brake pedal is depressed<sup>\*1</sup> when:

- The Auto Idle Stop **OFF** button is pressed.
- The steering wheel is operated.
- The transmission is put into  $\mathbb{R}$  or  $\mathbb{S}$ , or when it is set from  $\mathbb{N}$  to  $\mathbb{D}$ .
  - ► If you put the transmission into P after the Auto Idle Stop activates, the Auto Idle Stop continues to operate. In this case, the engine restarts when you depress the brake pedal.
- The pressure on the brake pedal is reduced and the vehicle starts moving while stopped on an incline.
- The brake pedal is released slightly during a stop.
- The battery charge becomes low.
- The accelerator pedal is depressed.
- The driver's seat belt is unlatched.
- 🗑 is ON (indicator on).
- The climate control system is in use, and the difference between the set temperature and actual interior temperature becomes significant.
- The climate control system is being used to dehumidify the interior.
- The Integrated Dynamics System mode is changed to **SNOW** or **SPORT** mode.
- The vehicle ahead of you starts again when your vehicle stops automatically with ACC with Low Speed Follow.

The Engine Automatically Restarts When:

If you are using an electronic device during Auto Idle Stop, the device may temporarily be turned off when the engine restarts.

The engine restarts even if the brake pedal is depressed<sup>\*1</sup> when:

\*1: With the automatic brake hold system activated, you can release the brake pedal while Auto Idle Stop is in operation.

If the automatic brake hold system has been turned off, or if there is a problem with the system, the engine will restart automatically when you release the brake pedal.

Automatic Brake Hold P. 550

# Starting Assist Brake Function

Briefly keeps the brake applied after releasing the brake pedal to restart the engine. This can keep your vehicle from unexpectedly moving while on an incline.

# Vehicle Stability Assist™ (VSA®), aka Electronic Stability Control (ESC), System

VSA® helps to stabilize the vehicle during cornering if the vehicle turns more or less than what was intended. It also assists in maintaining traction on slippery surfaces. It does so by regulating engine output and selectively applying the brakes.

# VSA<sup>®</sup> Operation



When VSA<sup>®</sup> activates, you may notice that the engine does not respond to the accelerator. You may also notice some noise from the hydraulic brake system. You will also see the indicator blink. Wehicle Stability Assist<sup>™</sup> (VSA<sup>®</sup>), aka Electronic Stability Control (ESC), System


The VSA<sup>®</sup> may not function properly if tire type and size are mixed. Make sure to use the same size and type of tire, and the air pressures as specified.

When the VSA® system indicator comes on and stays on while driving, there may be a problem with the system. While this may not interfere with normal driving, have your vehicle checked by a dealer immediately.

VSA® cannot enhance stability in all driving situations and does not control the entire braking system. You still need to drive and corner at speeds appropriate for the conditions and always leave a sufficient margin of safety.

The main function of the VSA® system is generally known as Electronic Stability Control (ESC). The system also includes a traction control function.

# VSA<sup>®</sup> On and Off



This button is on the driver side control panel. To partially disable VSA<sup>®</sup> functionality/ features, press and hold it until you hear a beep.

Your vehicle will have normal braking and cornering ability, but traction control function will be less effective.

To restore VSA<sup> $\otimes$ </sup> functionality/features, press the  $\mathbb{R}$  (VSA<sup> $\otimes$ </sup> **OFF**) button until you hear a beep.

VSA<sup>®</sup> is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle.

Wehicle Stability Assist<sup>™</sup> (VSA®), aka Electronic Stability Control (ESC), System

In certain unusual conditions when your vehicle gets stuck in shallow mud or fresh snow, it may be easier to free it with the VSA® temporarily switched off.

When the B button is pressed, the traction control function becomes less effective. This allows for the wheels to spin more freely at low speed. You should only attempt to free your vehicle with the VSA® off if you are not able to free it when the VSA® is on.

Immediately after freeing your vehicle, be sure to switch VSA® on again. We do not recommend driving your vehicle with the VSA® system switched off.

You may hear a motor sound coming from the engine compartment while system checks are being performed immediately after starting the engine or while driving. This is normal.

# **Agile Handling Assist**

#### AWD models

Lightly brakes each of the front and rear wheels, as needed, when you turn the steering wheel, and helps support the vehicle's stability and performance during cornering.

## 2WD models

Lightly brakes the front wheels, as needed, when you turn the steering wheel, and helps support the vehicle's stability and performance during cornering.

#### ➢Agile Handling Assist

The agile handling assist cannot enhance stability in all driving situations. You still need to drive and corner at speeds appropriate for the conditions and always leave a sufficient margin of safety.

When the VSA® system indicator comes on and stays on while driving, the agile handling assist does not activate.

You may hear a sound coming from the engine compartment while the agile handling assist is activated. This is normal.

# Super Handling-All Wheel Drive™ (SH-AWD®)\*

The system controls and transfers varying amounts of engine torque to each wheel in accordance with the driving conditions.

SH-AWD® helps to enhance driving stability, and lets you handle situations like slippery surfaces, such as on wet, icy, or snowy roads, better than when driving with two wheel drive. However, the system does not help to enhance braking. Be precautious about the following:

- It is still your responsibility to drive safely when you steer, accelerate, and apply brakes.
- Leave a sufficient margin when braking on slippery surfaces.

Super Handling-All Wheel Drive<sup>™</sup> (SH-AWD<sup>®</sup>)\*

The SH-AWD<sup>®</sup> system may not function properly if tire type and size are mixed.


Make sure to use the same size and type of tire, and the air pressures as specified.

#### Tire and Wheel Replacement P. 620

Do not continuously spin the front tires of your vehicle. Continuously spinning the front tires can cause damage to the transmission and SH-AWD<sup>®</sup> unit.

If the Super Handling-All Wheel Drive<sup>™</sup> (SH-AWD<sup>®</sup>) indicator blinks while driving, it indicates the differential temperature is too high. If this happens, pull to the side of the road when it is safe, change the gear position to [P], and idle the engine until the indicator goes out.

# Tire Pressure Monitoring System (TPMS) with Tire Fill Assist



Monitors the tire pressure while you are driving. If your vehicle's tire pressure becomes significantly low, the low tire pressure/TPMS indicator comes on and a message appears on the multi-information display. Tire Pressure Monitoring System (TPMS) with Tire Fill Assist

Conditions such as low ambient temperature and altitude change directly affect tire pressure and can trigger the low tire pressure/TPMS indicator to come on.

#### If the Low Tire Pressure/TPMS Indicator Comes On or Blinks P. 676

Tire pressure checked and inflated in:

- Warm weather can become under-inflated in colder weather.
- Cold weather can become overinflated in warmer weather.

The low tire pressure/TPMS indicator will not come on as a result of overinflation.

Only use genuine TPMS specified wheels since your vehicle's wheels are equipped with the low tire pressure/TPMS sensor.

If you drive your vehicle without the genuine TPMS specified wheels, the low tire pressure/TPMS indicator blinks for one minutes and then stays on.

Tire and Wheel Replacement P. 620

The TPMS audibly and visually informs you of changes in tire pressure of the individual tire that you are adjusting using audible and visual indications.

If a change in tire pressure has been significant, the system beeps and the hazard lights flash continuously for five seconds when the specified tire pressure is reached. Stop filling the tire.

# Tire Pressure Monitor



To select the tire pressure monitor, set the power mode to ON, and roll the right selector wheel until you see the tire pressure screen.

The pressure for each tire is displayed in psi (U.S.) or kPa (Canada).

**Tire Pressures Low** is displayed when a tire has significantly low pressure. The specific tire is displayed on the screen.

#### ➢Tire Pressure Monitor

The pressure displayed on the multi-information display can be slightly different from the actual pressure as measured by a gauge. If there is a significant difference between the two values, or if the low tire pressure/TPMS indicator and the message on the multi-information display do not go off after you have inflated the tire to the specified pressure, have the system checked by a dealer.

**Tire Pressure Monitor System Problem. Check Tire Pressure. See Your Dealer.** may appear if you drive with the compact spare tire\*, or there is a problem with the TPMS.



# **Tire Pressure Monitoring System (TPMS) - Required Federal Explanation**

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label.

(If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale



when one or more of your tires is significantly under-inflated.

Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure.

Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly.


Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

# **Blind Spot Information System**

When the system detects vehicles approaching from behind in adjacent lanes, the appropriate indicator comes on, providing assistance when you change lanes.

# How the System works

The system activates when your vehicle is moving forward at about 20 mph (32 km/h) or above.



Alert zone range

A: Approx. 1.6 ~ 10 feet (0.5 ~ 3 meters) from vehicle side.

B: Approx. 10 feet (3 meters) from rear bumper.

C: Approx. 10 ~ 82 feet (3 ~ 25 meters) behind from rear bumper. (The faster the approaching vehicle, the further away it will be detected.)

The initially set alert zone is alert zone 1. Over time, after the vehicle has been driven on straight roads with traffic and roadside objects, the system will adapt and expand the alert zone (alert zone 1 and 2). ➢Blind Spot Information System

#### Important Safety Reminder

Like all assistance systems, the blind spot information system has limitations. Always look in your mirrors, to either side of your vehicle, and behind you for other vehicles before changing lanes. Overreliance on the blind spot information system may result in a collision.

Have your vehicle checked by a dealer in the following situations:

- The rear bumper or area around the radar sensors is strongly impacted.
- The indicator does not come on even if a vehicle in the alert zone should have been detected.
- The rear bumper or any system components need to be repaired.


If the rear bumper or any system components are repaired, the system will revert to alert zone 1 only until it is able to adapt and expand to alert zone 1 and 2.

Turn the system off when towing a trailer.

The system may not work properly for the following reasons:

- The added mass tilts the vehicle and changes the radar coverage.
- The trailer itself can be detected by the radar sensors, causing the blind spot information system alert indicators to come on.

#### When the system detects a vehicle



Blind spot information system alert indicator: Located near the pillar on both sides.

#### Comes on when:

- A vehicle approaches you from behind to overtake you at a speed difference of no more than about 31 mph (50 km/h).
- You pass a vehicle at a speed difference of no more than about 12 mph (20 km/h).

#### Blinks and a beeper sounds when:

You use the turn signal lever to signal a turn in the direction of the detected vehicle while the blind spot information system alert indicator is on.

► The beeper sounds three times.

#### ➢Blind Spot Information System

For proper blind spot information system operation:

- Always keep the rear bumper and area around the radar sensors clean.
- Do not cover the rear bumper corner area with labels or stickers of any kind.

The system is for your convenience only. Even if an object is within the alert zone, the following situations may occur:

- The blind spot information system alert indicator does not come on and the message Blind Spot Information System Not Available appears on the multi-information display.
- The blind spot information system alert indicator may come on even with the message displayed.

# Blind Spot Information System On and Off



When you turn the blind spot information system on and off, do the following.

- **1.** Press the safety support switch.
- **2.** Roll the right selector wheel to the symbol and push it.
  - The message appears on the multiinformation display when the system turns on or off.
  - ► A check mark appears in the box and the color of the 💭 symbol changes green when the system is on. The check mark disappears and the color of the 🔊 symbol changes gray when the system is off.

The blind spot information system is in the previously selected on (checked) or off (unchecked) setting each time you start the engine.

#### ➢Blind Spot Information System

You can also select the safety support content from the multi-information display.

Display P. 137

You can change the settings for the blind spot information system.

Customized Features P. 359

# Blind Spot Information System Conditions and Limitations

The blind spot information system alert indicator may not come on under the following conditions:

- There is a large speed difference between your vehicle and the vehicle in the adjacent lane.
- A vehicle is parked in a side lane.
- An object not detected by the radar sensors approaches or passes your vehicle.
- The vehicle driving in the adjacent lane is a motorcycle or other small vehicle.

The blind spot information system may not operate correctly under the following conditions:

- Making a turn at an intersection.
- Objects (guard rails, poles, trees, etc.) are detected.
- An object that does not reflect radio waves well or a motorcycle, is in the alert zone.
- Driving on a curved road.
- A vehicle is moving from a far lane to the adjacent lane.
- The system picks up signal interference such as other radar sensors from another vehicle or strong radio wave transmitted from a facility nearby.
- The rear bumper or the area around the radar sensors is covered by dirt, mud, snow, ice, etc.
- The rear bumper or the area around the radar sensors has been damaged or deformed.
- In bad weather (heavy rain, snow, and fog).
- Making a short turn or driving on a bumpy road that slightly tilts the vehicle.
- An object such as a bicycle rack is attached to the rear of the vehicle.

#### Models without Low Speed Braking Control

AcuraWatch<sup>™</sup> is a driver support system which employs the use of two distinctly different kinds of sensors, a radar sensor located behind the emblem, and a front sensor camera mounted to the interior side of the windshield, behind the rearview mirror.

#### Models with Low Speed Braking Control

AcuraWatch<sup>™</sup> is a driver support system which employs the use of three distinctly different kinds of sensors, a radar sensor located behind the emblem, a front sensor camera mounted to the interior side of the windshield, behind the rearview mirror, and the sonar sensors located in the front and rear bumpers.

AcuraWatch<sup>™</sup> has the following functions.


# ■ The functions which do not require switch operations to activate


- Collision Mitigation Braking System<sup>™</sup> (CMBS<sup>™</sup>) ₽. 486
- Low Speed Braking Control \* ₽ P. 497
- Road Departure Mitigation System ₽ P. 530
- Traffic Sign Recognition System ₽ P. 535

# ■ The functions which require switch operations to activate

- Adaptive Cruise Control (ACC) with Low Speed Follow ₽ P. 502
- Lane Keeping Assist System (LKAS) ₽ P. 522

# Operation Switches for the ACC with Low Speed Follow/ Lane Keeping Assist System (LKAS)





# 🔳 🛃 Button

Press to activate standby mode for ACC with Low Speed Follow. Or press to cancel the system.

#### LKAS Button

Press to activate standby mode for LKAS. Or press to cancel the system.

#### RES/+/SET/- Switch

Press the **RES/+/SET/–** switch up to resume the ACC with Low Speed Follow or increase the vehicle speed.

Press the **RES/+/SET/–** switch down to set the ACC with Low Speed Follow or decrease the vehicle speed.


#### Interval Button

Press to change the ACC with Low Speed Follow following-interval.

## **CANCEL Button**

Press to cancel ACC with Low Speed Follow.

# Multi-Information Display Content



You can see the current state of ACC with Low Speed Follow, and Lane Keeping Assist System (LKAS).

Indicates that ACC with Low Speed Follow is ready to be activated.

- Green: The system is on.
- White: The system is standby.
- Amber: There is a problem with the system.

2 Indicates that LKAS is ready to be activated.

- Green: The system is on.
- White: The system is standby.
- Amber: There is a problem with the system.

3 Indicates that LKAS is activated and whether or not traffic lane lines are detected.

- Solid lane outlines: The system is on.
- Lane outlines: The system is in standby.

Indicates whether or not ACC with Low Speed Follow detected the vehicle ahead.

Shows vehicle set speed in ACC with Low Speed Follow.

6 Shows set vehicle interval in ACC with Low Speed Follow.

#### Models with Head-up display

You can have the head-up display show you the current state of each function.

Head-Up Display\* P. 148

<sup>\*</sup> Not available on all models

# **Collision Mitigation Braking System™ (CMBS™)**

The system can assist you when it determines there is a possibility of your vehicle colliding with a vehicle or a pedestrian detected in front of your vehicle. The CMBS<sup>™</sup> is designed to alert you when the potential for a collision is determined, as well as to reduce your vehicle speed to help minimize collision severity when a collision is deemed unavoidable.

➢Collision Mitigation Braking System™ (CMBS™)

#### **Important Safety Reminder**

The CMBS<sup>™</sup> is designed to reduce the severity of an unavoidable collision. It does not prevent collisions nor stop the vehicle automatically. It is still your responsibility to operate the brake pedal and steering wheel appropriately according to the driving conditions.

The CMBS<sup>™</sup> may not activate or may not detect a vehicle in front of your vehicle under certain conditions:

CMBS<sup>™</sup> Conditions and Limitations P. 491

You can read about handling information for the camera equipped with this system.


Front Sensor Camera P. 541

For directions on the proper handling of the radar sensor, refer to the following page.

Radar Sensor P. 543

When the CMBS<sup>TM</sup> activates, it may automatically apply the brake. It will be canceled when your vehicle stops or a potential collision is not determined.

#### How the system works



The system starts monitoring the roadway ahead when your vehicle speed is about 3 mph (5 km/h) or above and will search for a vehicle in front of you.

The CMBS<sup>™</sup> activates when:

- The speed difference between your vehicle and a vehicle or pedestrian detected in front of you becomes about 3 mph (5 km/h) and over with a chance of a collision.
- Your vehicle speed is about 62 mph (100 km/h) or less and the system determines there is a chance of a collision with:


- Vehicles detected in front of you that are stationary, oncoming, or traveling in your same direction.

- A pedestrian who is detected in front of you.
- Your vehicle speed is above 62 mph (100 km/h), and the system determines there is a chance of a collision with a vehicle detected in front of you traveling in your same direction.

#### When the system activates

The system provides visual and audible alerts of a possible collision, and stops if the collision is avoided.

Take appropriate action to prevent a collision (apply the brakes, change lanes, etc.).



Driving

You can change the distance (**Long/Normal/Short**) between vehicles at which the system's earliest collision alert will come on through audio/information screen setting options.

Customized Features P. 359

#### ■Collision Mitigation Braking System<sup>™</sup> (CMBS<sup>™</sup>)

The camera in the CMBS<sup>™</sup> is also designed to detect pedestrians.

However, this pedestrian detection feature may not activate or may not detect a pedestrian in front of your vehicle under certain conditions.


Refer to the ones indicating the pedestrian detection limitations from the list.

CMBS<sup>™</sup> Conditions and Limitations P. 491

#### Models with Head-up display

The head-up warning uses a lens located at the front end of the dashboard.

Do not cover the lens or spill any liquid on it.



# Collision Alert Stages

The system has three alert stages for a possible collision. However, depending on circumstances, the CMBS<sup>™</sup> may not go through all of the stages before initiating the last stage.

Distance between vehicles		CMBS™		
		The radar sensor detects a vehicle	Audible & Visual WARNINGS	Braking
Stage one	Normal Long Short Your Vehicle Vehicle Ahead	There is a risk of a collision with the vehicle ahead of you.	When in <b>Long</b> , visual and audible alerts come on at a longer distance from a vehicle ahead than in <b>Normal</b> setting, and in <b>Short</b> , at a shorter distance than in <b>Normal</b> .	_
Stage two	Your Vehicle Vehicle Ahead	The risk of a collision has increased, time to respond is reduced.	Visual and audible alerts.	Lightly applied
Stage three	Your Vehicle Vehicle	The CMBS <sup>™</sup> determines that a collision is unavoidable.		Forcefully applied

# CMBS<sup>™</sup> On and Off



When you turn the  $\mathsf{CMBS}^{\mathsf{TM}}$  on and off, do the following.

- **1.** Press the safety support switch.
- **2.** Roll the right selector wheel to the symbol and push it.
  - The message appears on the multiinformation display when the system turns on or off.
  - A check mark appears in the box and the color of the symbol changes green when the system is on. The check mark disappears and the color of the symbol changes gray when the system is off.

The CMBS<sup>™</sup> is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle. ➢Collision Mitigation Braking System™ (CMBS™)

The CMBS<sup>™</sup> may automatically shut off, and the safety support indicator (amber) will come and stay on under certain conditions:

#### CMBS<sup>™</sup> Conditions and Limitations P. 491

You can also select safety support content from the multi-information display.

#### Multi-Information Display P. 137

When the CMBS<sup>TM</sup> is activated, it will continue to operate even if the accelerator pedal is partially depressed. However, it will be canceled if the accelerator pedal is fully depressed.

# CMBS<sup>™</sup> Conditions and Limitations

In the following situations, the radar sensor or camera may be unable to correctly detect vehicles, pedestrians, moving bicycles, or road conditions, potentially causing the CMBS to operate improperly.

Front Sensor Camera P. 541

Radar Sensor P. 543

#### Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between objects and the background.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Roadway objects or structures are misinterpreted as vehicles and pedestrians.
- Reflections on the interior of the windshield.
- Driving at night or in a dark condition such as a tunnel.

## ■ Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on curvy, winding, or undulating roads.
- The road is hilly or the vehicle is approaching the crest of a hill.

■Collision Mitigation Braking System<sup>™</sup> (CMBS<sup>™</sup>)

Have your vehicle checked by a dealer if you find any unusual behavior of the system (e.g., the warning message appears too frequently).

#### Vehicle conditions

- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- An abnormal tire or wheel condition (incorrect sizes, varied sizes or construction, improperly inflated, compact spare tire<sup>\*</sup>, etc.).
- When tire chains are installed.
- The vehicle is tilted due to a heavy load or suspension modifications.
- The camera temperature gets too high.
- Driving with the parking brake applied.
- When the radar sensor behind the emblem gets dirty.
- The vehicle is towing a trailer.

#### Detection limitations

- A vehicle or pedestrian suddenly crosses in front of you.
- The distance between your vehicle and the vehicle or pedestrian ahead of you is too short.
- A vehicle cuts in front of you at a slow speed, and it brakes suddenly.
- When you accelerate rapidly and approach the vehicle or pedestrian ahead of you at high speed.
- The vehicle ahead of you is a motorcycle, bicycle, mobility scooter or other small vehicle.
- When there are animals in front of your vehicle.
- When you drive on a curved, winding or undulating road that makes it difficult for the sensor to properly detect a vehicle in front of you.
- The speed difference between your vehicle and a vehicle or pedestrian in front of you is significantly large.
- An oncoming vehicle suddenly comes in front of you.
- Another vehicle suddenly comes in front of you at an intersection, etc.
- Your vehicle abruptly crosses over in front of an oncoming vehicle.
- When driving through a narrow iron bridge.
- When the lead vehicle suddenly slows down.

#### Limitations applicable to pedestrian detection only

- When there is a group of people in front of your vehicle walking together side by side.
- Surrounding conditions or belongings of the pedestrian alter the pedestrian's shape, preventing the system from recognizing that the person is a pedestrian.
- When the pedestrian is shorter than about 3.3 feet (1 meter) or taller than about 6.6 feet (2 meters) in height.
- When a pedestrian blends in with the background.
- When a pedestrian is bent over or squatting, or when their hands are raised or they are running.
- When several pedestrians are walking ahead in a group.
- When the camera cannot correctly identify that a pedestrian is present due to an unusual shape (holding luggage, body position, size).

## Automatic shutoff

The CMBS<sup>™</sup> may automatically shut itself off and the safety support indicator (amber) comes and stays on when:

- The temperature inside the system is high.
- You drive off-road or on a mountain road, or curved and winding road for an extended period.
- An abnormal tire condition is detected (wrong tire size, flat tire, etc.).
- The camera behind the rearview mirror, or the area around the camera, including the windshield, gets dirty.

Once the conditions that caused the CMBS<sup>™</sup> to shut off improve or are addressed (e.g., cleaning), the system comes back on.

# With Little Chance of a Collision


The CMBS<sup>™</sup> may activate even when you are aware of a vehicle ahead of you, or when there is no vehicle ahead. Some examples of this are:

## When Passing

Your vehicle approaches another vehicle ahead of you and you change lanes to pass.


## At an intersection

Your vehicle approaches or passes another vehicle that is making a left or right turn.



## On a curve

When driving through curves, your vehicle comes to a point where an oncoming vehicle is right in front of you.




## Through a low bridge at high speed

You drive under a low or narrow bridge at high speed.

#### Speed bumps, road work sites, train tracks, roadside objects, etc.

You drive over speed bumps, steel road plates, etc., or your vehicle approaches train tracks or roadside objects (such as a traffic sign and guard rail) on a curve or, when parking, stationary vehicles and walls.



# Low Speed Braking Control\*

Using sonar sensors located on the front and rear bumpers, the vehicle can detect if there is danger of a potential collision with a wall or other obstacle. The system is designed to alert you when a potential collision is determined, as well as assist in reducing speed, avoiding collisions, and reducing collision severity.

Low Speed Braking Control\*

# 


The Low Speed Braking Control System cannot avoid all collisions and may not reduce damage in each situation where the accelerator is mistakenly or aggressively pressed.

Overreliance on the system may result in a collision with serious injury or death. Always check your surroundings, your shift position, and your pedal use. Driver remains responsible for safely operating the vehicle.

If the Low Speed Braking Control activates in a situation where you do not want automatic brake application (such as when the vehicle is between two railroad crossing gates), simply press the brake pedal to deactivate the system and then continue to drive as intended.

# How the System Works

The Low Speed Braking Control provides a visual and audible alert when the vehicle is moving between approximately 1 and 6 mph (2 and 10 km/h) and there is the possibility of a collision with a detected wall or other obstacle, as well as providing assistance with braking.



If the only rear sensors are turned off using the parking sensor system, the assistive braking will not work when reversing.

Turning off All Rear Sensors P. 560

#### ➢Low Speed Braking Control\*

For directions on the proper handling of the sonar sensors, please refer to the following page.

Sonar Sensors\* P. 544

The vehicle will release the brake and start moving a few seconds after the system is activated. To keep the vehicle stopped, keep the brake pedal depressed or put the transmission into  $[\mathbf{P}]$ .

In order to prevent the system from activating when not needed, always turn it off during vehicle maintenance, when loading on ships, trucks, and so on, or when using a chassis dynamometer or free rollers for inspection or when washing the car in conveyor type car wash machine.

If you put any accessories (such as a towing hitch or bicycle rack) on or around the rear sensors, the Low Speed Braking Control System may activate if it detects these accessories as an obstacle. In this case, turn off the rear sensor.

Turning off All Rear Sensors P. 560

# System On and Off



When you turn the system on and off, do the following.

- **1.** Press the safety support switch.
- **2.** Roll the right selector wheel to the symbol and push it.
  - The message appears on the multiinformation display when the system turns on or off.
  - ► A check mark appears in the box and the color of the <u>S</u> symbol changes green when the system is on. The check mark disappears and the color of the <u>S</u> symbol changes gray when the system is off.

The system is turned on every time you start the engine, even if you turned it off the last time you drove the vehicle.

#### System On and Off

You can also select safety support content from the multi-information display.

Multi-Information Display P. 137

# Conditions for Cancellation

A certain amount of time has passed since activation.

# Low Speed Braking Control System Conditions and Limitations

The system may not operate correctly under the following conditions:

#### Examples of obstacles the sonar sensors cannot detect

- Obstacles that do not reflect sound waves well, such as people, snow, cloth, sponges, etc.
- Thin obstacles such as fences, bicycles, sign posts, etc.
- Short or small obstacles.
- Obstacles immediately in front of the bumper.
- Moving objects or obstacles that suddenly enter the road.
- Obstacles that are not perpendicular to the ground.

#### ➢Conditions for Cancellation

After Low Speed Braking Control has activated once, it will not activate again for the same obstacle. The system can be activated again after driving for some time after the last activation.

Low Speed Braking Control activates separately when moving forward and reversing. (For example, if it activates when moving forward, it can be activated again immediately if reversing.)

# **Examples of situations where the sonar sensors cannot detect obstacles**

- The sonar sensors are dirty (covered by snow, water, mud, etc.).
- The vehicle is too hot or cold.
- The steering wheel is turned sharply when approaching the obstacle at an angle.

## **Examples of other cases where the system may not work correctly**

- The vehicle is tilted due to heavy load in the cargo area or rear seats.
- Bad weather conditions such as heavy rain, fog, snow, sandstorms, etc.
- The ambient temperature/humidity is too high or low.
- When going down a very steep slope.
- When close to other vehicles with sonar sensors or other objects that emit ultrasonic waves.


# ■ Situations where the system may activate even without risk of a collision

- When passing through short or narrow gates.
- When driving on uneven surfaces, grassy areas, or places with steps.
- When a sloped pillar or wall is protruding from a high position.
- When there are obstacles next to the road.
- When driving toward flags, curtains, tree branches, railroad crossing bars, etc.
- When driving on flooded roads.

# Adaptive Cruise Control (ACC) with Low Speed Follow

Helps maintain a constant vehicle speed and a set following-interval behind a vehicle detected ahead of yours and, if the detected vehicle comes to a stop, can decelerate and stop your vehicle, without you having to keep your foot on the brake or the accelerator.

When ACC with Low Speed Follow slows your vehicle by applying the brakes, your vehicle's brake lights will illuminate.



Vehicle speed for ACC with Low Speed Follow: A vehicle is detected ahead within ACC with Low Speed Follow range – ACC with Low Speed Follow operates at speeds up to 90 mph (145 km/h).

No vehicle is detected within ACC with Low Speed Follow range – ACC with Low Speed Follow operates at the speed of 25 mph (40 km/h) or above. ■ Gear position for ACC with Low Speed Follow: In D or S.

Adaptive Cruise Control (ACC) with Low Speed Follow

# WARNING

Improper use of ACC with Low Speed Follow can lead to a crash.

Use ACC with Low Speed Follow only when driving on expressways or freeways and in good road and weather conditions.

# 

ACC with Low Speed Follow has limited braking capability and may not stop your vehicle in time to avoid a collision with a vehicle that quickly stops in front of you.


Always be prepared to apply the brake pedal if the conditions require.

## Important Reminder

As with any system, there are limits to ACC with Low Speed Follow. Use the brake pedal whenever necessary, and always keep a safe interval between your vehicle and other vehicles.

ACC with Low Speed Follow cannot be activated if Intelligent Dynamics System setting is **SNOW**.

## How to activate the system



#### Adaptive Cruise Control (ACC) with Low Speed Follow

For directions on the proper handling of the radar sensor, refer to the following page.

Radar Sensor P. 543

You can read about handling information for the camera equipped with this system.

Front Sensor Camera P. 541

The radar sensor for ACC with Low Speed Follow is shared with the Collision Mitigation Braking System<sup>™</sup> (CMBS<sup>™</sup>).


Collision Mitigation Braking System™ (CMBS™) P. 486

ACC with Low Speed Follow may not work properly under certain conditions.

#### ACC with Low Speed Follow Conditions and Limitations P. 509

When not using ACC with Low Speed Follow: Turn off adaptive cruise by pressing the 🛃 button.

## To Set the Vehicle Speed



When driving at about 25 mph (40 km/h) or above: Take your foot off the pedal and press down the **RES/+/SET/–** switch when you reach the desired speed. The moment you release the switch, the set speed is fixed, and ACC with Low Speed Follow begins.

When you use ACC with Low Speed Follow, Straight Driving Assist (a feature of the Electric Power Steering system) is activated.

By enabling the steering system to automatically compensate for natural steering pull, Straight Driving Assist makes it easier for you to keep your vehicle in a straight line.

**When driving slower than about 25 mph (40 km/h):** If the vehicle is moving and the brake pedal is not depressed, pressing the switch fixes the set speed to about 25 mph (40 km/h) regardless of current vehicle speed. If the vehicle is stationary, you can set the vehicle speed even with the brake pedal depressed.

#### Maptive Cruise Control (ACC) with Low Speed Follow


Do not use ACC with Low Speed Follow under the following conditions:

- On roads with frequent lane-change or continuous stop and go traffic, ACC with Low Speed Follow cannot keep an appropriate distance between your vehicle and the vehicle ahead of you.
- On roads with sharp turns.
- On roads with steep downhill sections, as the set vehicle speed can be exceeded by coasting. In such cases, ACC with Low Speed Follow will not apply the brakes to maintain the set speed.
- On roads with toll collection facilities or other objects between lanes of traffic, or in parking areas, or facilities with drive through access.
- On roads with bad weather (rain, fog, snow, etc.), ACC with Low Speed Follow may not detect the distance between your vehicle and the vehicle ahead of you properly.
- On roads with slippery or icy surfaces. The wheels may spin out and your vehicle may lose the control on the condition.

#### ➢To Set the Vehicle Speed

You can switch the displayed set speed measurements on the multi-information display or audio/information screen between mph and km/h.

Speed/Distance Units P. 142
 Customized Features P. 359




When ACC with Low Speed Follow starts operating, the vehicle icon, interval bars and set speed appear on the multi-information display.

## When in Operation

## There is a vehicle ahead

ACC with Low Speed Follow monitors if a vehicle ahead of you enters the ACC with Low Speed Follow range. If a vehicle is detected doing so, the ACC with Low Speed Follow system maintains or decelerates your vehicle's set speed in order to keep the vehicle's set following-interval from the vehicle ahead.

To Set or Change Following-interval P. 513



ACC with Low Speed Follow Range: 394 ft. (120 m)




A vehicle icon appears on the multi-information display.


When a vehicle whose speed is slower than your set speed is detected in front of you, your vehicle starts to slow down.

#### When in Operation

If the vehicle detected ahead of you slows down abruptly, or if another vehicle is detected cutting in front of you, a beeper sounds and a message appears on the multi-information display, and the head-up warning lights\* flash.



Depress the brake pedal, and keep an appropriate interval from the vehicle ahead.



## There is no vehicle ahead



A vehicle icon with dotted-line contour appears on the multi-information display.

Your vehicle maintains the set speed without having to keep your foot on the brake or accelerator pedal.

If there previously was a vehicle detected ahead that kept your vehicle from traveling at the set speed, ACC with Low Speed Follow accelerates your vehicle to the set speed, and then maintains it.

#### When in Operation

Even if the interval between your vehicle and the vehicle detected ahead is short, ACC with Low Speed Follow may start accelerating your vehicle under the following circumstances:

- The vehicle ahead of you is going at almost the same speed as, or faster than, your vehicle.
- A vehicle that cuts in front of you is going faster than your vehicle, gradually increasing the interval between the vehicles.

You can also set the system to beep when a vehicle in front of you comes in and goes out of the ACC with Low Speed Follow detecting range. A vehicle detect beep on and off can be selected.

Customized Features P. 359

#### Limitations


You may need to use the brake to maintain a safe interval when using ACC with Low Speed Follow. Additionally, ACC with Low Speed Follow may not work properly under certain conditions.

ACC with Low Speed Follow Conditions and Limitations P. 509

## When you depress the accelerator pedal

You can temporarily increase the vehicle speed. In this case, there is no audible or visual alert even if a vehicle is in the ACC with Low Speed Follow range. ACC with Low Speed Follow stays on unless you cancel it. Once you release the accelerator pedal, the system resumes an appropriate speed for keeping the following interval while a vehicle ahead is within the ACC with Low Speed Follow range.

# ■ A vehicle detected ahead is within ACC with Low Speed Follow range and slows to a stop



Your vehicle also stops, automatically. The **Stopped** message appears on the multiinformation display. When the vehicle ahead of you starts again, if you press the **RES/+/SET/–** switch up or down, or depress the accelerator pedal, ACC with Low Speed Follow will operate again within the previously set speed.


If no vehicle is ahead of you before you resume driving, depressing the accelerator pedal will resume operation of ACC with Low Speed Follow within the prior set speed. A vehicle detected ahead is within ACC with Low Speed Follow range and slows to a stop

# 

Exiting a vehicle that has been stopped while the ACC with Low Speed Follow system is operating can result in the vehicle moving without operator control.

A vehicle that moves without operator control can cause a crash, resulting in serious injury or death.

Never exit a vehicle when the vehicle is stopped by ACC with Low Speed Follow.



## ACC with Low Speed Follow Conditions and Limitations

The system may automatically shut off under certain conditions. Some examples of these conditions are listed below. Other conditions may reduce some of the ACC with Low Speed Follow functions.

Front Sensor Camera P. 541

Radar Sensor P. 543

## Environmental conditions

Driving in bad weather (rain, fog, snow, etc.).

#### Roadway conditions

Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).

## Vehicle conditions

- The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- An abnormal tire or wheel condition (incorrect sizes, varied sizes or construction, improperly inflated, compact spare tire<sup>\*</sup>, etc.).
- The camera temperature gets too high.
- The parking brake is applied.
- The radar sensor cover is dirty.
- The vehicle is tilted due to a heavy load or suspension modifications.
- Tire chains are installed.
- The vehicle is towing a trailer.

MACC with Low Speed Follow Conditions and Limitations

If you need the radar sensor to be repaired, or removed, or the radar sensor cover is strongly impacted, turn off the system by pressing the subtron and take your vehicle to a dealer.


Have your vehicle checked by a dealer if you find any unusual behavior of the system (e.g., the warning message appears too frequently).

If the front of the vehicle is impacted in any of the following situations, the radar sensor may not work properly. Have your vehicle checked by a dealer:

- The vehicle mounted onto a bump, curb, chock, embankment, etc.
- You drive the vehicle where water is deep.
- Your vehicle has a frontal collision.

## Detection limitations

- A vehicle suddenly crosses in front of you.
- The interval between your vehicle and the vehicle ahead of you is too short.
- A vehicle cuts in front of you at a slow speed, and it brakes suddenly.
- You accelerate rapidly and approach the vehicle ahead of you at high speed.
- The vehicle ahead of you is a motorcycle, bicycle, mobility scooter, or other small vehicle.
- There are animals in front of your vehicle.
- You drive on a curved or winding or undulating road that makes it difficult for the sensor to properly detect a vehicle in front of you.




- The speed difference between your vehicle and a vehicle in front of you is significantly large.
- An oncoming vehicle suddenly comes in front of you.
- Your vehicle abruptly crosses over in front of an oncoming vehicle.

• Driving through a narrow metal bridge.




- The vehicle ahead of you brakes suddenly.
- The vehicle ahead of you has a unique shape.



• Your vehicle or the vehicle ahead of you is driving on one edge of the lane.

## To Adjust the Vehicle Speed

Increase or decrease the vehicle speed using the **RES/+/SET/–** switch on the steering wheel.



- Each time you press the switch up or down, the vehicle speed is increased or decreased by about 1 mph or 1 km/h accordingly.
- If you keep the switch pressed up or down, the vehicle speed increases or decreases by about 5 mph or 5 km/h accordingly.

#### ➢To Adjust the Vehicle Speed

If a vehicle detected ahead is going at a speed slower than your increased set speed, ACC with Low Speed Follow may not accelerate your vehicle. This is to maintain the set interval between your vehicle and the vehicle ahead.

You can switch the displayed set speed measurements on the multi-information display or audio/information screen between mph and km/h.

Speedometer P. 136
 Customized Features P. 359

When you depress the accelerator pedal and then press down and release the **SET/–** switch, the current speed of the vehicle is set.

## To Set or Change Following-interval




Press the interval button to change the ACC with Low Speed Follow following-interval. Each time you press the button, the following-interval (the interval behind a vehicle detected ahead of you) setting cycles through extra long, long, middle, and short following-intervals.

Determine the most appropriate followinginterval setting based on your specific driving conditions. Be sure to adhere to any following-interval requirements set by local regulation. The higher your vehicle's following-speed is, the longer the short, middle, long or extra long following-interval becomes. See the following examples for your reference.

Following-interval		When the Set Speed is:	
		50 mph (80 km/h)	65 mph (104 km/h)
Short		83 feet 25 meters 1.1 sec	100 feet 31 meters 1.1 sec
Middle		110 feet 33 meters 1.5 sec	137 feet 42 meters 1.5 sec
Long		154 feet 47 meters 2.1 sec	200 feet 61 meters 2.1 sec
Extra Long		207 feet 63 meters 2.9 sec	272 feet 83 meters 2.9 sec

When your vehicle stops automatically because a vehicle detected ahead of you has stopped, the interval between the two vehicles will vary based on the ACC with Low Speed Follow interval setting.

## To Cancel



To cancel ACC with Low Speed Follow, do any of the following:

- Press the **CANCEL** button.
  - ► The 🛃 indicator (green) on the multiinformation display changes to the 🛃 indicator (white).
- Press the 😽 button.
- ▶ 🛃 indicator (green) goes off.
- Depress the brake pedal while the vehicle is moving forward.
  - ► The 🛃 indicator (green) on the multiinformation display changes to the 🛃 indicator (white).

#### ≫To Cancel


Resuming the prior set speed: After you have canceled ACC with Low Speed Follow, you can activate the ACC with Low Speed Follow with the prior set speed displayed on the multi-information display (in gray) by pressing the **RES/+/SET/–** switch up even if the vehicle is stopped.

When you turn the ACC with Low Speed Follow off by pressing the **CANCEL** button or depressing the brake pedal, the prior set speed is displayed on the multi-information display in gray.

When pressing the **RES/+/SET/–** switch, the ACC with Low Speed Follow is activated with displayed speed.

If the spin indicator (white) is displayed and you press the **RES/+/SET/–** switch up, but no prior set speed (in gray) is displayed, the speed will be set to your vehicle's current speed.

## ≫To Cancel



The set speed cannot be set or resumed when ACC with Low Speed Follow has been turned off using the system. Press the system the desired speed.

## Automatic cancellation

The beeper sounds and a message appears on the multi-information display when ACC with Low Speed Follow is automatically canceled. Any of these conditions may cause the ACC with Low Speed Follow to automatically cancel:


- Bad weather (rain, fog, snow, etc.)
- When the radar sensor behind the emblem gets dirty.
- The vehicle ahead of you cannot be detected.
- An abnormal tire condition is detected, or the tires are skidding.
- Driving on a mountainous road for extended periods, or driving off road.
- Abrupt steering wheel movement.
- When the ABS, VSA<sup>®</sup>, CMBS<sup>™</sup>, or Low Speed Braking Control<sup>\*</sup> is activated.
- When the ABS or VSA® system indicator comes on.
- When the vehicle is stopped on a very steep slope.
- When you manually apply the parking brake.
- When the detected vehicle within the ACC with Low Speed Follow range is too close to your vehicle.
- The camera behind the rearview mirror, or the area around the camera, including the windshield, gets dirty.
- When the Maximum Load Limit is exceeded.
- When passing through an enclosed space, such as tunnel.
- The vehicle has repeatedly applied the brakes to maintain the set speed (for example, you are descending a long slope).

The ACC with Low Speed Follow automatic cancellation can be also triggered by the following causes. In these cases, the parking brake will be automatically applied.

- The driver's seat belt is unfastened when the vehicle is stationary.
- The vehicle stops for more than 10 minutes.
- The engine is turned off.

\* Not available on all models

## To Switch ACC with Low Speed Follow to Cruise Control



Press and hold the interval button for one second. **Cruise Mode Selected** appears on the multi-information display for two seconds, and then the mode switches to Cruise. The S comes on.

• Green: The system is on.

• White: The system is standby. To switch back to ACC with Low Speed Follow, press and hold the interval button again for one second.

#### To Switch ACC with Low Speed Follow to Cruise Control

Always be aware which mode you are in. When you are driving in Cruise mode, the system will not assist you to maintain a following-interval from a vehicle ahead of you.

You can switch the displayed set speed measurements on the multi-information display or audio/information screen between mph and km/h.

Speedometer P. 136

**Customized Features** P. 359

## When to use

Desired speed in a range above roughly 25 mph (40 km/h).

## To Set the Vehicle Speed

Take your foot off the pedal and press the **RES/+/SET/–** switch down when you reach the desired speed.

The moment you release the **RES/+/SET/–** switch, the set speed is fixed, and cruise control begins. The indicator (green) comes on.

When you use cruise control, Straight Driving Assist (a feature of the Electric Power Steering system) is activated.

By enabling the steering system to automatically compensate for natural steering pull, Straight Driving Assist makes it easier for you to keep your vehicle in a straight line.

## To Adjust the Vehicle Speed

Each time you press the **RES/+/SET/–** switch up or down, the vehicle speed is increased or decreased by about 1 mph (1.6 km/h). If you keep the **RES/+/SET/–** switch pressed up or down, the vehicle speed increases or decreases until you release it. This speed is then set.

## To Cancel

To cancel cruise control, do any of the following:

- Press the CANCEL button.
  - The indicator (green) on the multi-information display changes to the indicator (white).
- Press the 💦 button.
  - ▶ 🔊 indicator (green) goes off.
- Depress the brake pedal.
  - The indicator (green) on the multi-information display changes to the indicator (white).

#### ≫To Cancel

Resuming the prior set speed:

After you have canceled cruise mode, you can activate the cruise mode with the prior set speed displayed on the multi-information display (in gray) by pressing the **RES/+/SET/–** switch up while driving at a speed of at least 25 mph (40 km/h) or more. When you turn the cruise mode off by pressing the **CANCEL** button or depressing the brake pedal, the prior set speed is displayed on the multi-information display in gray.

When pressing the **RES/+/SET/–** switch up, the cruise mode is activated with displayed speed. If the 🐑 indicator (white) is displayed and you press the **RES/+/SET/–** switch up, but no prior set speed (in gray) is displayed, the speed will be set to your vehicle's current speed.



You cannot set or resume in the following situations:

- When vehicle speed is less than 25 mph (40 km/h)
  When the R button is turned off


At vehicle speeds of 22 mph (35 km/h) or less, cruise mode is canceled automatically.

# Lane Keeping Assist System (LKAS)

Provides steering input to help keep the vehicle in the middle of a detected lane and provides tactile and visual alerts if the vehicle is detected drifting out of its lane.

#### ■ Steering input assist

The system applies torque to the steering to keep the vehicle between the left and right lane lines. The applied torque becomes stronger as the vehicle gets closer to either of the lane lines.



When you operate the turn signals to change lanes, the system is suspended, and resumes after the signals are off.

If you make a lane change without operating the turn signals, the LKAS alerts activate, and torque is applied to the steering.

≥Lane Keeping Assist System (LKAS)

#### Important Safety Reminders

The LKAS is for your convenience only. It is not an autonomous driving system and always requires driver attention and control. The system does not work if you take your hands off the steering wheel or fail to steer the vehicle.

#### Multi-Information Display Warning and Information Messages P. 107

The LKAS is convenient when it is used on expressways or freeways.

Do not place objects on the instrument panel. Objects may reflect on the windshield and prevent correct detection of the traffic lanes.

The LKAS only alerts you when lane drift is detected without a turn signal in use. The LKAS may not detect all lane markings or lane departures; accuracy will vary based on weather, speed, and lane marker condition.

It is always your responsibility to safely operate the vehicle and avoid collisions.

The LKAS may not work properly or may work improperly under the certain conditions:


## LKAS Conditions and Limitations P. 527

You can read about handling information for the camera equipped with this system.

Front Sensor Camera P. 541

## Lane Keep Support Function

Provides assistance to keep the vehicle in the center of the lane. When the vehicle nears a white or yellow line, steering force of the electric power steering will become stronger.



## Lane Departure Warning Function

When the vehicle enters the warning area, the LKAS alerts you with slight steering wheel vibration as well as a warning display.

Warning Area	
Warning Area	

#### ■Lane Keeping Assist System (LKAS)

The LKAS may not function as designed while driving in frequent stop and go traffic, or on roads with sharp curves.


When it fails to detect lanes, the system will temporarily be canceled. When a lane is detected, the system will recover automatically.

## When the System can be Used

The system can be used when the following conditions are met.

- The lane in which you are driving has detectable lane markers on both sides, and your vehicle is in the center of the lane.
- The vehicle is traveling between about 45 and 90 mph (72 and 145 km/h).
- You are driving on a straight or slightly curved road.
- The turn signals are off.
- The brake pedal is not depressed.
- The wipers are not in high speed operation.

## How to activate the system



- **1.** Press the LKAS button.
  - LKAS indicator (white) and lane outlines appear on the multi-information display. The system is ready to use.

#### When the System can be Used

If the vehicle drifts toward either left or right lane line due to the system applying torque, turn off the LKAS and have your vehicle checked by a dealer.



- **2.** Keep your vehicle near the center of the lane while driving.
  - The LKAS indicator changes from white to green and the lane outlines change to solid ones once the system starts operating after detecting the left and right lane markings.

## To Cancel



Press the LKAS button.

The LKAS is turned off every time you stop the engine, even if you turned it on the last time you drove the vehicle.

# (white) is on.

When the LKAS is suspended, the lane lines on the multiinformation display change to lane outlines, and the beeper sounds (if activated).

# The system operation is suspended if you:

- Set the wipers to **HI**.
  - Turning the wipers off or setting it to LO resumes the LKAS.

## Models with automatic intermittent wipers

- Set the wiper switch to AUTO and the wipers operate at high speed.
  - The LKAS resumes when the wipers stop or operate at low speed.

## All models

- Decrease the vehicle speed to about 40 mph (64 km/h) or less.
  - Increasing the vehicle speed to about 45 mph (72 km/h) or more resumes the LKAS.
- Depress the brake pedal.
  - The LKAS resumes and starts detecting the lane lines again once you release the brake pedal.

## The LKAS may be automatically suspended when:

- The system fails to detect lane lines.
- The steering wheel is quickly turned.
- You fail to steer the vehicle.
- Driving through a sharp curve.
- Driving at a speed in excess of approximately 90 mph (145 km/h).
- Once these conditions no longer exist, the LKAS automatically resumes.

### The system operation is suspended if you:

You can change the setting for the LKAS.

- LKAS suspended beep on and off can be selected.
  - **Customized Features** P. 359

## The LKAS may be automatically canceled when:

- The camera temperature gets extremely high or low.
- The camera behind the rearview mirror, or the area around the camera, including the windshield, gets dirty.
- The ABS or VSA® system engages.

The beeper sounds if the LKAS is automatically canceled.

## **LKAS Conditions and Limitations**


The system may not detect lane markings and therefore may not keep the vehicle in the middle of the lane under certain conditions, including the following:

## Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between lane lines and the roadway surface.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Shadows of adjacent objects are parallel to lane markings.
- Roadway objects or structures are misinterpreted as lane markers.
- Reflections on the interior of the windshield.
- Driving at night or in a dark condition such as a tunnel.

## Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on a road with temporary lane markings.
- Faint, multiple, or varied lane markings are visible on the roadway due to road repairs or old lane markings.




- The roadway has merging, split, or crossing lines (e.g., such as at an intersection or crosswalk).
- The lane markings are extremely narrow, wide, or changing.

### Very wide or narrow traffic lane



- The vehicle in front of you is driving near the lane lines.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on rough or unpaved roads, or over bumpy surfaces.

- When objects on the road (curb, guard rail, pylons, etc.) are recognized as white (or yellow) lines.
- Driving on roads with double lines.




## Vehicle conditions

- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is streaked or blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- The camera temperature gets too high.
- An abnormal tire or wheel condition (incorrect sizes, varied sizes or construction, improperly inflated, compact spare tire\*, etc.).
- The vehicle is tilted due to a heavy load or suspension modifications.
- The vehicle is towing a trailer.

# **Road Departure Mitigation System**

Alerts and helps to assist you when the system detects a possibility of your vehicle unintentionally crossing over detected lane markings and/or leaving the roadway altogether.

## How the System Works



The front camera behind the rearview mirror monitors left and right lane markings (in white or yellow). If your vehicle is getting too close to detected lane markings without a turn signal activated, the system, in addition to a visual alert, applies steering torque and alerts you with rapid vibrations on the steering wheel, to help you remain within the detected lane.

Customized Features P. 359

As a visual alert, the **Lane Departure** message appears on the multi-information display.

If the system determines that its steering input is insufficient to keep your vehicle on the roadway, it may apply braking.

► Braking is applied only when the lane markings are solid continuous lines. The system cancels assisting operations when you turn the steering wheel to avoid crossing over detected lane markings.

If the system operates several times without detecting driver response, the system beeps to alert you.

➢Road Departure Mitigation System

#### **Important Safety Reminder**

Like all assistance systems, the Road Departure Mitigation system has limitations. Overreliance on the Road Departure Mitigation system may result in a collision. It is always your responsibility to keep the vehicle within your driving lane.

The Road Departure Mitigation system only alerts you when lane drift is detected without a turn signal in use. The Road Departure Mitigation system may not detect all lane markings or lane or roadway departures; accuracy will vary based on weather, speed and lane marker condition. It is always your responsibility to safely operate the vehicle and avoid collisions.

You can read about handling information for the camera equipped with this system.

Front Sensor Camera P. 541

The Road Departure Mitigation system may not work properly or may work improperly under the certain conditions:

Road Departure Mitigation Conditions and Limitations P. 533

There are times when you may not notice the Road Departure Mitigation functions due to your operation of the vehicle, or road surface conditions.

## How the System Activates

The system activates when all of the following conditions are met:

- The vehicle is traveling between about 45 and 90 mph (72 and 145 km/h).
- The vehicle is on a straight or slightly curved road.
- The turn signals are off.
- The brake pedal is not depressed.
- The wipers are not in high speed operation.
- The system makes a determination that the driver is not actively accelerating, braking, or steering.

#### ➢How the System Activates

The Road Departure Mitigation system may automatically shut off and the indicator comes and stays on.

## ► Indicators P. 80

Road Departure Mitigation system function can be impacted when the vehicle is:

- Not driven within a traffic lane.
- Driven on the inside edge of a curve, or outside of a lane.
- Driven in a narrow lane.

## Road Departure Mitigation On and Off



When you turn the Road Departure Mitigation on and off, do the following.

- **1.** Press the safety support switch.
- 2. Roll the right selector wheel to the symbol and push it.
  - The message appears on the multiinformation display when the system turns on or off.
  - A check mark appears in the box and the color of the  $\boxed{\left| \frac{1}{\sqrt{3}} \right|}$  symbol changes green when the system is on. The check mark disappears and the color of the  $\boxed{\left| \frac{1}{\sqrt{3}} \right|}$  symbol changes gray when the system is off.

The Road Departure Mitigation is in the previously selected on (checked) or off (unchecked) setting each time you start the engine.

#### ≥Road Departure Mitigation On and Off

When you have selected **Warning Only** from the customized options using the audio/information screen, the system does not operate the steering wheel and braking.

## Customized Features P. 359

You can also select safety support content from the multi-information display.

Multi-Information Display P. 137

## **Road Departure Mitigation Conditions and Limitations**

The system may not properly detect lane markings and the position of your vehicle under certain conditions. Some examples of these conditions are listed below.

## Environmental conditions

- Driving in bad weather (rain, fog, snow, etc.).
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- There is little contrast between lane lines and the roadway surface.
- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Driving in the shadows of trees, buildings, etc.
- Shadows of adjacent objects are parallel to lane markings.
- Roadway objects or structures are misinterpreted as lane markers.
- Reflections on the interior of the windshield.
- Driving at night or in a dark condition such as a tunnel.

## Roadway conditions

- Driving on a snowy or wet roadway (obscured lane marking, vehicle tracks, reflected lights, road spray, high contrast).
- Driving on a road with temporary lane markings.
- Faint, multiple, or varied lane markings are visible on the roadway due to road repairs or old lane markings.
- The roadway has merging, split, or crossing lines (e.g., such as at an intersection or crosswalk).
- The lane markings are extremely narrow, wide, or changing.
- The vehicle in front of you is driving near the lane lines.
- The road is hilly or the vehicle is approaching the crest of a hill.
- Driving on rough or unpaved roads, or over bumpy surfaces.
- When objects on the road (curb, guard rail, pylons, etc.) are recognized as white (or yellow) lines.
- Driving on roads with double lines.

## Vehicle conditions

- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is streaked or blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- The camera temperature gets too high.
- An abnormal tire or wheel condition (incorrect sizes, varied sizes or construction, improperly inflated, compact spare tire<sup>\*</sup>, etc.).
- The vehicle is tilted due to a heavy load or suspension modifications.
- When tire chains are installed.
- The vehicle is towing a trailer.

# **Traffic Sign Recognition System**

Reminds you of road sign information of the current speed limit your vehicle has just passed through, showing it on the multi-information display and the head-up display<sup>\*</sup>.

#### Traffic Sign Recognition System

Not all signs may be displayed, but any signs posted on roadsides should not be ignored. The system does not work on the designated traffic signs of all the countries you travel, nor in all situations. Do not rely too much on the system. Always drive at speeds appropriate for the road conditions.


Never apply a film or attach any objects to the windshield that could obstruct the camera's field of vision and cause the system to operate abnormally. Scratches, nicks, and other damage to the windshield within the camera's field of vision can cause the system to operate abnormally. If this occurs, we recommend that you replace the windshield with a genuine Acura replacement windshield. Making even minor repairs within the camera's field of vision or installing an aftermarket replacement windshield may also cause the system to operate abnormally. After replacing the windshield, have a dealer recalibrate the camera. Proper calibration of the camera is necessary for the system to operate properly.

To help reduce the likelihood that high interior temperatures will cause the camera's sensing system to shut off, when parking, find a shady area or face the front of the vehicle away from the sun. If you use a reflective sun shade, do not allow it to cover the camera housing. Covering the camera can concentrate heat on it.

You can read about handling information for the camera equipped with this system.

## How the System Works

Shows the current speed limit based on either information compiled through the navigation system<sup>\*</sup> or speed limit signs captured by the front sensor camera. The system displays the ones that are recognized as designated for your vehicle. The sign icon will be displayed until the vehicle reaches a predetermined time and distance. If the system does not detect any traffic signs while you are driving, the sign icon will not be displayed.



Driving

The sign icon also may switch to another one or disappear when:

- The other designated limit is detected.
- You make a turn with a turn signal at an intersection.

#### ➢Traffic Sign Recognition System

#### Models with navigation system

You can select whether the source of the speed limit information is the front sensor camera or the navigation system.

You can also turn off speed limit information.

## **Customized Features** P. 359

#### Models without navigation system

## Traffic Sign Recognition System Conditions and Limitations

The Traffic Sign Recognition system may incorrectly recognize, be slow to identify, or fail to recognize the traffic sign in the following cases.

## Vehicle conditions


- Headlight lenses are dirty or the headlights are not properly adjusted.
- The outside of the windshield is blocked by dirt, mud, leaves, wet snow, etc.
- The inside of the windshield is fogged.
- There are portions remaining to be wiped.
- An abnormal tire or wheel condition (incorrect sizes, varied sizes or construction, improperly inflated, compact spare tire<sup>\*</sup>, etc.).
- The vehicle is tilted due to a heavy load or suspension modifications.

## Environmental conditions

- Driving into low sunlight (e.g., at dawn or dusk).
- Strong light is reflected onto the roadway.
- Sudden changes between light and dark, such as an entrance or exit of a tunnel.
- When you drive in the shadows of trees, buildings, etc.
- Driving at night, in dark areas such as long tunnels.
- Driving in bad weather (rain, fog, snow, etc.).
- A vehicle in front of you is kicking up spray or snow.

Traffic Sign Recognition System Conditions and Limitations

When the Traffic Sign Recognition system malfunctions, a ppears on the multi-information display and the head-up display<sup>\*</sup>. If this message does not disappear, have your vehicle checked by a dealer.



## The position or the condition of the traffic sign

- A sign is hard to be found since it is in a complicated area.
- A sign is located far away from your vehicle.
- A sign is located where the beam of the headlight is hard to reach.
- A sign is on a corner or bend in the road.
- Faded or bent signs.
- Rotated or damaged signs.
- A sign is covered with mud, snow, or frost.
- A part of the sign is hidden by the trees, or the sign itself is hidden by a vehicle and others.
- Light (a streetlight) or a shadow is reflected on the surface of the sign.
- A sign is too bright or too dark (an electric sign).
- A sign of a small size.

## Other conditions


• When you are driving at a high speed.

The Traffic Sign Recognition system may not operate correctly, such as displaying a sign that does not follow the actual regulation for the roadway or does not exist at all in the following cases.

- ► A speed limit sign may display at a higher or lower speed than the actual speed limit.
- There is a supplementary sign with further information such as weather, time, vehicle type, school zone, etc.
- Figures on the sign are hard to read (electric signs, numbers on the sign are blurred, etc.).
- The sign is in the vicinity of the lane you are driving in, even though it is not for the lane, such as a speed limit sign situated at an exit or an intersection between the side road and the main road.
- There are things that look similar to the color or shape of the recognition object (similar sign, electric sign, signboard, structure, etc.).
- A truck or another large vehicle with a sticker of the speed limit sign on the back is traveling in front of you.

# Signs Displayed on the Multi-Information Display and Headup Display\*


The speed limit sign icon is displayed on the right half of the screen.



# **Front Sensor Camera**

The camera, used in systems such as Lane Keeping Assist System (LKAS), Road Departure Mitigation system, Adaptive Cruise Control (ACC) with Low Speed Follow, Traffic Sign Recognition system, and Collision Mitigation Braking System<sup>™</sup> (CMBS<sup>™</sup>), is designed to detect an object that triggers any of the systems to operate their functions.

# Camera Location and Handling Tips



This camera is located behind the rearview mirror.

To help reduce the likelihood that high interior temperatures will cause the camera's sensing system to shut off, when parking, find a shady area or face the front of the vehicle away from the sun. If you use a reflective sun shade, do not allow it to cover the camera housing. Covering the camera can concentrate heat on it.

### ➢Front Sensor Camera

Never apply a film or attach any objects to the windshield, the hood, or the front grille that could obstruct the camera's field of vision and cause the system to operate abnormally.

Scratches, nicks, and other damage to the windshield within the camera's field of vision can cause the system to operate abnormally. If this occurs, we recommend that you replace the windshield with a genuine Acura replacement windshield. Making even minor repairs within the camera's field of vision or installing an aftermarket replacement windshield may also cause the system to operate abnormally. After replacing the windshield, have a dealer recalibrate the camera. Proper calibration of the camera is necessary for the system to operate properly.

Do not place an object on the top of the instrument panel. It may reflect onto the windshield and prevent the system from detecting lane lines properly.

#### ➢Front Sensor Camera


If the Some Driver Assist Systems Cannot Operate: Camera Temperature Too High message appears:

- Use the climate control system to cool down the interior and, if necessary, also use defroster mode with the airflow directed towards the camera.
- Start driving the vehicle to lower the windshield temperature, which cools down the area around the camera.

#### If the Some Driver Assist Systems Cannot Operate: Clean Front Windshield message appears:

• Park your vehicle in a safe place, and make sure the windshield is clean. Clean the windshield if it is dirty. If the message does not disappear after driven for a while, have your vehicle checked by a dealer.

# **Radar Sensor**



The radar sensor is behind the emblem.

### ≫Radar Sensor

Avoid strong impacts to the radar sensor cover.

For the system to work properly, observe the following precautions.

- Always keep the emblem and front grille clean.
- Never use chemical solvents or polishing powder for cleaning the emblem and front grille. Clean it with water or a mild detergent.
- Do not put any stickers or paint on the emblem or front grille.
- Do not scratch or damage the emblem or front grille.
- Do not replace the emblem, front grille, or bumper.
- Do not remove or disassemble the radar sensor.

Consult a dealer if:

- The radar sensor cover is strongly impacted.
- The front grille or bumper needs to be repaired.


If the vehicle is involved in any of the following situations, the radar sensor may not work properly. Have your vehicle checked by a dealer:


- Your vehicle is involved in a frontal collision
- Your vehicle drives through deep water or is submerged in deep water
- Your vehicle strongly strikes a bump, curb, chock, slope, or embankment that could jar the radar sensor


# Sonar Sensors\*

### ■ Location and range of sensors

The sonar sensors are situated in the front and rear bumpers.







### Sonar Sensors <sup>∗</sup>

For the sonar sensors to work properly, do not:

- Place stickers or other objects on or around the sensors.
- Hit the area around the sensors.
- Attempt to take apart any sensor.
- Put any accessories on or around the sensors.

Consult with a dealer if:

- A sensor has been subjected to shock.
- Work needs to be done to the area around a sensor.

In the following cases, the sonar sensors may not work properly. Have your vehicle checked by a dealer.

- The front or rear bumper has made contact with a hill, parking block, curb, embankment, etc.
- The vehicle has been involved in frontal or rear collision.
- The vehicle has been driven through a deep puddle.

# Braking

# **Brake System**

# Parking Brake

Use the parking brake to keep the vehicle stationary when parked. When the parking brake is applied, you can manually or automatically release it.



### To apply

The electric parking brake can be applied any time the vehicle has battery, no matter which position the power mode is in.

Press the electric parking brake switch gently and securely.

- ► The indicator in the switch comes on.
- The Parking Brake and Brake System indicator (red) comes on.

#### ≫Brake System

When you depress the brake pedal, you may hear a whirring sound coming from the engine compartment. This is because the brake system is in operation, and it is normal.

### ■Parking Brake

You may hear the electric parking brake system motor operating from the rear wheel area when you apply or release the parking brake. This is normal.

The brake pedal may slightly move due to the electric parking brake system operation when you apply or release the parking brake. This is normal.

You cannot apply or release the parking brake if the battery goes dead.

If the Battery Is Dead P. 667

If you press and hold the electric parking brake switch while driving, the brakes on all four wheels are applied by the electric servo brake system until the vehicle come to a stop. The electric parking brake then applies, and the switch should be released.



### To release

The power mode must be in ON in order to release the electric parking brake.

- **1.** Depress the brake pedal.
- **2.** Pull the electric parking brake switch up gently and securely.
  - ► The indicator in the switch goes off.
  - ► The Parking Brake and Brake System indicator (red) goes off.

Manually releasing the parking brake using the switch helps your vehicle start slowly and smoothly when facing downhill on steep hills.

### ➢Parking Brake

In the following situations, the parking brake automatically operates.

- When the vehicle stops more than 10 minutes while ACC with Low Speed Follow is activated.
- When the driver's seat belt is unfastened while your vehicle is stopped automatically by ACC with Low Speed Follow.
- When the engine is turned off, except by Auto Idle Stop system, while ACC with Low Speed Follow is activated.
- When the vehicle stops with the automatic brake hold system activated for more than 10 minutes.
- When the driver's seat belt is unfastened while your vehicle is stopped and automatic brake hold is applied.
- When the engine is turned off, except by Auto Idle Stop system, while automatic brake hold system is applied.
- When there is a problem with the automatic brake hold system while Automatic Brake Hold is applied.

### Automatic parking brake feature operation


If the automatic parking brake feature has been activated:

- The parking brake is applied automatically when you set the power mode to VEHICLE OFF.
- To confirm that the parking brake is applied, check if the Parking Brake and Brake System indicator (red) is on.

Activating and deactivating the automatic parking brake feature P. 548

### To release automatically

Depressing the accelerator pedal releases the parking brake. Use the accelerator pedal to release the brake when you are starting the vehicle facing uphill, or in a traffic jam.



Gently depress the accelerator pedal. When on a hill, it may require more accelerator input to release.

► The Parking Brake and Brake System indicator (red) goes off.

### ➢Parking Brake

If the parking brake cannot be released automatically, release it manually.

When the vehicle is traveling uphill, the accelerator pedal may need to be pressed farther to automatically release the electric parking brake.

The parking brake cannot be released automatically while the following indicators are on:

- Malfunction indicator lamp
- Transmission system indicator

The parking brake may not be released automatically while the following indicators are on:

- Parking brake and brake system indicator (amber)
- VSA® system indicator
- ABS indicator
- Supplemental restraint system indicator

You can release the parking brake automatically when:

- You are wearing the driver's seat belt.
- The engine is running.
- The transmission is not in  $[\mathbf{P}]$  or  $[\mathbf{N}]$ .

### ■ Activating and deactivating the automatic parking brake feature

With the power mode in ON, carry out the following steps to either activate or deactivate the automatic parking brake feature.

- **1.** Put the transmission into **P**.
- Without depressing the brake pedal, press and release the parking brake switch.
   ▶ Check that the Parking Brake and Brake System indicator (red) has come on.
- **3.** Press and hold the parking brake switch. When you hear a beeping sound, release the switch and within 3 seconds press and hold the switch again.
- **4.** When you hear a sound indicating that the procedure is completed, release the switch.
  - Two beeps indicates that the feature has been activated.
  - ▶ One beep indicates that the feature has been deactivated.
  - ▶ When you have completed activating the feature, the parking brake will remain applied after you turn off the engine.
  - ► To confirm that the parking brake is applied, check if the Parking Brake and Brake System indicator (red) is on.

If you need to temporarily deactivate the feature while putting your vehicle through a conveyor type car wash or when having your vehicle towed. You can follow the procedure explained below.

- **1.** Depress the brake pedal and bring the vehicle to a stop.
- **2.** Set the power mode to VEHICLE OFF and then within 2 seconds pull up the parking brake switch.
  - Activation and deactivation settings for the feature will not be affected.
  - Before temporarily deactivating the feature, make sure to first turn off both ACC with Low Speed Follow and the automatic brake hold system.
  - ► To confirm that the parking brake is applied, check if the Parking Brake and Brake System indicator (red) is on.

### ➢Parking Brake

In cold climates, the parking brake may freeze in place if applied.

When parking the vehicle, chock the wheels and make sure the automatic parking brake feature is deactivated.

Also, when putting your vehicle through a conveyortype car wash or when having your vehicle towed, deactivate the automatic parking brake feature and leave the parking brake released.

### Foot Brake

Your vehicle is equipped with disc brakes at all four wheels. The brake assist system increases the stopping force when you depress the brake pedal hard in an emergency situation. The anti-lock brake system (ABS) helps you retain steering control when braking very hard.

Brake Assist System P. 554

Anti-lock Brake System (ABS) P. 553

### ≫Foot Brake

Check the brakes after driving through deep water, or if there is a buildup of road surface water. If necessary, dry the brakes by lightly depressing the pedal several times.

If you hear a continuous metallic friction sound when applying the brakes, this is caused by the brake wear indicator rubbing on the brake rotor and indicates that the brake pads need to be replaced. Have the vehicle checked by a dealer. If you hear only an occasional squeak or squeal when you initially apply the brake pedal, this may be normal and caused by high frequency vibration of the brake pads against the rotating brake disc.


Constantly using the brake pedal while going down a long hill builds up heat, which reduces the brake effectiveness. Apply engine braking by taking your foot off the accelerator pedal and downshifting to a lower gear.

Do not rest your foot on the brake pedal while driving, as it will lightly apply the brakes and cause them to lose effectiveness over time and reduce pad life. It will also confuse drivers behind you.

Whenever the brakes are activated by CMBS<sup>TM</sup> or another system that automatically controls braking, the brake pedal is depressed and released in accordance with braking function.

# Automatic Brake Hold

Keeps the brake applied after releasing the brake pedal until the accelerator pedal is pressed. You can use this system while the vehicle is temporarily stopped, like at traffic lights and in heavy traffic.



 The automatic brake hold system indicator comes on. The system is turned on.

The automatic brake

- hold system indicator changes to the automatic brake hold indicator. Braking is kept for up to 10 minutes.
- Release the brake pedal after the automatic brake hold indicator comes on.

or N. The system is canceled and the vehicle starts to move.

• The automatic brake hold indicator changes to the automatic brake hold system indicator. The system continues to be on.

#### Automatic Brake Hold

# 

Activating the automatic brake hold system on steep hills or slippery roads may still allow the vehicle to move if you remove your foot from the brake pedal.

If a vehicle unexpectedly moves, it may cause a crash resulting in serious injury or death.

Never activate the automatic brake hold system or rely on it to keep a vehicle from moving when stopped on a steep hill or slippery roads.

# 

Using the automatic brake hold system to park the vehicle may result in the vehicle unexpectedly moving.

If a vehicle moves unexpectedly, it may cause a crash, resulting in serious injury or death.

Never leave the vehicle when braking is temporarily kept by automatic brake hold and always park the vehicle by putting the transmission in P and applying the parking brake

### The system automatically cancels when:

- You engage the parking brake.
- You depress the brake pedal and put the transmission into  $\mathbf{P}$  or  $\mathbf{R}$ .

### The system automatically cancels and the parking brake is applied when:

- Braking is kept for more than 10 minutes.
- The driver's seat belt is unfastened.
- The engine is turned off.
- There is a problem with automatic brake hold system.

### ➢Automatic Brake Hold

# 

When using the automatic brake hold, keep your foot on the brake pedal until the automatic brake hold indicator comes on. If the vehicle unexpectedly moves, it may cause a crash resulting in serious injury or death.

Release your foot from the brake pedal after the automatic brake hold indicator comes on.


While the system is activated, you can turn off the engine or park the vehicle through the same procedure as you normally do.

When Stopped P. 555

Whether the system is on, or the system is activated, the automatic brake hold turns off once the engine is off.

You may hear an operating noise if the vehicle moves while the automatic brake hold system is in operation.

### ■ Turning off the automatic brake hold system



While the system is on, press the automatic brake hold button again.

► The automatic brake hold system indicator goes off.

If you want to turn off automatic brake hold while the system is in operation, press the automatic brake hold button with the brake pedal depressed.

#### Turning off the automatic brake hold system

Make sure to turn off the automatic brake hold system before using an automated car wash.

# Anti-lock Brake System (ABS)

# 

Helps prevent the wheels from locking up, and helps you retain steering control by pumping the brakes rapidly, much faster than you can.

The electronic brake distribution (EBD) system, which is part of the ABS, also balances the front-to-rear braking distribution according to vehicle loading.

You should never pump the brake pedal. Let the ABS work for you by always keeping firm, steady pressure on the brake pedal. This is sometimes referred to as "stomp and steer."

### ABS operation

The brake pedal may pulsate slightly when the ABS is working. Depress the brake pedal and keep holding the pedal firmly down. On dry pavement, you will need to press on the brake pedal very hard before the ABS activates. However, you may feel the ABS activate immediately if you are trying to stop on snow or ice.

ABS may activate when you depress the brake pedal when driving on:

- Wet or snow covered roads.
- Roads paved with stone.
- Roads with uneven surfaces, such as potholes, cracks, manholes, etc.

When the vehicle speed goes under 6 mph (10 km/h), the ABS stops.

#### Manti-lock Brake System (ABS)

### NOTICE

The ABS may not function correctly if you use a tire of the incorrect size or type.

If the **ABS** indicator comes on while driving, there may be a problem with the system.

While normal braking will not be affected, there is a possibility that the ABS will not be operating. Have your vehicle checked by a dealer immediately.

The ABS is not designed for the purpose of reducing the time or distance it takes for a vehicle to stop: It is designed to limit brake lockup which can lead to skidding and loss of steering control.

In the following cases, your vehicle may need more distance to stop than a vehicle without the ABS:

- You are driving on rough or uneven road surfaces, such as gravel or snow.
- The tires are equipped with tire chains.

The following may be observed with the ABS system:

- Motor sounds coming from the engine compartment when the brakes are applied, or when system checks are being performed after the engine has been started and while the vehicle accelerates.
- Brake pedal and/or the vehicle body vibration when ABS activates.

These vibrations and sounds are normal to ABS systems and are no cause for concern.

# **Brake Assist System**

Designed to assist the driver by generating greater braking force when you depress the brake pedal hard during emergency braking.

### Brake assist system operation

Press the brake pedal firmly for more powerful braking.

When brake assist operates, the pedal may wiggle slightly and an operating noise may be heard. This is normal. Keep holding the brake pedal firmly down.

# When Stopped

- **1.** Depress the brake pedal firmly and come to a complete stop.
- **2.** With the brake pedal depressed, press the electric parking brake switch slowly, but fully.
- **3.** Change the shift position to **P**.
  - ▶ Do not release the brake pedal until you have confirmed that **P** is shown on the shift position indicator.
- 4. Turn off the engine.
  - ► The Parking Brake and Brake System indicator (red) goes off in about 30 seconds.

Always set the parking brake, in particular if you are parked on an incline.

### Parking Your Vehicle

# 

The vehicle can roll away if left unattended without confirming that Park is engaged.

A vehicle that rolls away could cause a crash resulting in serious injury or death.

Always keep your foot on the brake pedal until you have confirmed that P is shown on the gear position indicator.

Do not park your vehicle near flammable objects, such as dry grass, oil, or timber. Heat from the exhaust can cause a fire.

### When Stopped

### NOTICE

The following can damage the transmission:

- Depressing the accelerator and brake pedals simultaneously.
- Holding the vehicle in place when facing uphill by depressing the accelerator pedal.
- Changing to **P** before the vehicle stops completely.


#### When Stopped

In extremely cold temperatures, the parking brake may freeze up if applied. If such temperatures are expected, do not apply the parking brake but, if parking on a slope, either turn the front wheels so they will contact the curb if the vehicle rolls down the slope or block the wheels to keep the vehicle from moving. If you do not take either precaution, the vehicle may roll unexpectedly, leading to a crash.

# Parking Sensor System\*

The corner and center sensors monitor obstacles around your vehicle, and the beeper, multi-information display and audio/information screen let you know the approximate distance between your vehicle and the obstacle.

# The sensor location and range



Parking Sensor System\*

Even when the system is on, always confirm if there is no obstacle near your vehicle before parking.

The system may not work properly when:

- The sensors are covered with snow, ice, mud, or dirt.
- The vehicle has been out in hot or cold weather.
- There is something nearby that emits ultrasonic waves or high frequency sounds.
- Driving in bad weather (rain, fog, snow, etc.).
- Any accessories have been put on or around the sensors.


The system may not detect these obstacles:

- Thin or low objects.
- Sonic-absorptive materials, such as snow, cotton, or sponge.
- Objects directly under the bumper.

The system may falsely detect obstacles in the following situations:

- The vehicle is on uneven surface, such as grass, bumps, or a hill.
- When close to other vehicles with sonar sensors or other objects that emit ultrasonic waves.
- There is splashing water near the sensors due to heavy rains, etc.

### Parking sensor system on and off



With the power mode in ON, press the parking sensor system button to turn on or off the system. The indicator in the button comes on when the system is on.

The front center and front corner sensors start to detect an obstacle when the transmission is in any position other than P or R, and the vehicle speed is less than 5 mph (8 km/h).

The front corner, rear center and rear corner sensors start to detect an obstacle when the transmission is in  $[\mathbf{R}]$ , and the vehicle speed is less than 5 mph (8 km/h).

#### Parking Sensor System\*

Do not put any accessories on or around the sensors. If you put any accessories (such as a towing hitch or bicycle rack) on or around the rear sensors, the system may activate if it detects these accessories as an obstacle. In this case, turn off the rear sensor.

### Turning off All Rear Sensors P. 560

### ≥Parking sensor system on and off

When you set the power mode to ON, the system will be in the previously selected condition.

If the rear sensors are turned off when using the parking sensor system, the Low Speed Braking Control System will not activate while reversing.

Low Speed Braking Control\* P. 497

Interval between beeps	Distance between the Bumper and Obstacle		Indicator	Multi-Information Display
	Corner Sensors	Center Sensors	Indicator	Audio/information Screen
Moderate	—	Rear: About 43-24 in (110-60 cm) Front: About 39-24 in (100-60 cm)	Blinks in Yellow*1	Multi-Information Display Indicators light up where the sensor detects
Short	About 24-18 in (60-45 cm)	About 24-18 in (60-45 cm)	Blinks in Amber Audio/information screen Models with multi-view rear camera system	an obstacle.
Very short	About 18-14 in (45-35 cm)	About 18-14 in (45-35 cm)		Audio/information screen Models with multi-view rear camera system
Continuous	About 14 in (35 cm) or less	About 14 in (35 cm) or less	Blinks in Red	Indicators light up where the sensor detects an obstacle.

### ■ When the distance between your vehicle and obstacles becomes shorter

\*1: At this stage, only the center sensors detect obstacles.

### Turning off All Rear Sensors

To deactivate the rear sensors, please take the following steps:

- 1. Make sure that the parking sensor system is not activated.
  - ► The indicator in the button turns off.
- 2. Set the power mode to VEHICLE OFF.
- 3. Press and hold the parking sensor system button, and set the power mode to ON.
- **4.** Keep pressing the button for 10 seconds. Release the button when the indicator in the button flashes.
  - ► The beeper sounds once.
- **5.** While the indicator is flashing, press the button again. The indicator in the button turns off.
  - ▶ The beeper sounds twice. The rear sensors are now turned off. They will remain turned off until manually turned back on again. To turn the rear sensors on again, follow the above procedure. The beeper sounds three times when the rear sensors come back on.

#### ➢Turning off All Rear Sensors

When you shift to  $[\underline{\mathbf{R}}]$ , the indicator in the parking sensor system button blinks as a reminder that the rear sensors have been turned off.

If the rear sensors are turned off when using the parking sensor system, the Low Speed Braking Control System will not activate while reversing. Low Speed Braking Control\* P. 497

# **Cross Traffic Monitor**

Monitors the rear corner areas using the radar sensors when reversing, and alerts you if a vehicle approaching from a rear corner is detected.

The system is convenient when you are backing out of a parking space.

Cross Traffic Monitor

# **ACAUTION**

Cross Traffic Monitor cannot detect all approaching vehicles and may not detect an approaching vehicle at all.


Failure to visually confirm that it is safe to back up the vehicle before doing so may result in a collision.

Do not solely rely on the system when reversing; always also use your mirrors, and look behind and to the sides of your vehicle before reversing.

#### Models with Parking Sensor System

The parking sensor system's alerting buzzer overrides the Cross Traffic Monitor buzzer when the sensors are detecting obstacles at the closest range.

### How the System Works



The system activates when:

- The power mode is in ON.
- The Cross Traffic Monitor is turned on.
   Cross Traffic Monitor On and Off P. 564
- The transmission is in **R**.
- Your vehicle is moving at 3 mph (5 km/h) or lower.

Radar sensors: Underneath the rear bumper corners

When a vehicle is detected approaching from a rear corner, Cross Traffic Monitor alerts you with a buzzer and a displayed warning.

The system will not detect a vehicle that approaches from directly behind your vehicle, nor will it provide alerts about a detected vehicle when it moves directly behind your vehicle.

The system does not provide alerts for a vehicle that is moving away from your vehicle, and it may alert for pedestrians, bicycles, or stationary objects.

#### ➢Cross Traffic Monitor

Cross traffic monitor may not detect or may delay alerting an approaching vehicle, or may alert without an approaching vehicle under the following conditions:


- An obstacle, such as another vehicle and a wall, near your vehicle's rear bumper, is blocking the radar sensor's scope.
- Your vehicle is moving at the speed of about 3 mph (5 km/h) or higher.
- A vehicle is approaching at the speed other than between about 6 mph (10 km/h) and 16 mph (25 km/h).
- The system picks up external interference such as other radar sensors from another vehicle or strong radio wave transmitted from a facility nearby.
- Either corner of the rear bumper is covered with snow, ice, mud or dirt.
- When there is bad weather.
- Your vehicle is on an incline.
- Your vehicle is tilted due to a heavy load in the rear.
- Your vehicle is reversing towards a wall, a pole, a vehicle, and so on.

The rear bumper or the sensors have been improperly repaired or the rear bumper has been deformed. Have your vehicle checked by a dealer.

For proper operation, always keep the rear bumper corner area clean.

Do not cover the rear bumper corner area with labels or stickers of any kind.

# When the System Detects a Vehicle



An arrow icon appears on the side a vehicle is approaching on the audio/information screen.

#### When the System Detects a Vehicle

If the  $\Re$  on the lower right changes to  $\Re$  in amber when the gear position is in  $\mathbb{R}$ , mud, snow or ice, etc. may have accumulated in the vicinity of the sensor. The system is temporarily canceled. Check the bumper corners for any obstructions, and thoroughly clean the area if necessary.

If the <u>R</u> comes on when the gear position is in **R**, there may be a problem with the Cross Traffic Monitor system. Do not use the system and have your vehicle checked by a dealer.

If the display remains the same with the transmission in  $[\mathbf{R}]$ , there may be a problem with the rear camera system and the Cross Traffic Monitor system.

Do not use the system and have your vehicle checked by a dealer.

# Cross Traffic Monitor On and Off



Cross Traffic Monitor Icon

You can switch the system on and off using the audio/information screen.


**Customized Features** P. 359

The system can also be turned on and off on the audio/information screen by pressing the Cross Traffic Monitor icon.

# About Your Multi-View Rear Camera

The audio/information screen can display your vehicle's rear view. The display automatically changes to the rear view when the transmission is put into  $[\mathbf{R}]$ .

# Multi-View Rear Camera Display Area



#### About Your Multi-View Rear Camera

The rear camera view is restricted. You cannot see the corner ends of the bumper or what is underneath the bumper. Its unique lens also makes objects appear closer or farther than they actually are.

Visually confirm that it is safe to drive before backing up. Certain conditions (such as weather, lighting, and high temperatures) may also restrict the rear view. Do not rely on the rearview display which does not give you all information about conditions at the back of your vehicle.

If the rear camera lens is covered with dirt or moisture, activate the rearview camera washer\* or use a soft, moist cloth to keep the lens clean and free of debris.

Rear Wiper/Washer P. 206

 $\label{eq:Guidelines} \begin{array}{l} \textbf{Guidelines} \text{ appear when you put the transmission} \\ \textbf{into } \boxed{\textbf{R}}. \end{array}$ 

You can change the **Guidelines** setting.

Customized Features P. 359

Off: Guidelines do not appear.

**Fixed:** Fixed Guidelines appear.

**Dynamic:** Guidelines that move according to the steering wheel direction appear.

**Both:** Fixed guidelines and dynamic guidelines appear.

You can view three different camera modes on the rearview display. Swipe to highlight the view mode icon and click the A-zone touchpad to change the mode.

- True Touchpad Interface P. 261
- : Wide view mode
- L: Normal view mode
- E: Top down view mode
- If the last used viewing mode was Wide or Normal view mode, the same mode is selected the next time you put the transmission into **R**.
- If Top down view mode was last used before you turned the power mode to OFF, Wide View mode is selected next time you set the power mode to ON and put the transmission into **R**.
- If Top down view mode was last used more than 10 seconds after you change from R, Wide View mode is selected the next time you put the transmission into R.

Is a four camera system that views areas commonly known as "blind spots" from different angles, then displays the images on the audio/information screen. This system can be used to:

• Check for obstacles when you are moving in  $[\mathbf{R}]$ .

### Using the Surround View Camera System P. 571

• Check the right and left sides of the vehicle while crossing at intersections with poor visibility (obstructed view, etc.).

### Checking from the front wide view at intersections P. 573

• Check for obstacles in front of the vehicle when parking or maneuvering in confined areas.

Checking the sides of your vehicle P. 573

### Surround View Camera System\*

# 

Failure to visually assess the area around the vehicle (directly or by use of the mirrors) may result in a crash causing serious injury or death.

The areas shown in the surround view camera system display are limited. The display may not show all pedestrians or other objects around your vehicle.


Do not solely rely only on the surround view camera system display to assess whether it is safe to move your vehicle.

# 

Failure to pay proper attention to your surroundings while driving may result in a crash causing serious injury or death.

To help mitigate the chances of a collision, only look at the surround view camera system display when it is safe to do so.

# Displaying an Image From the Surround View Cameras



### For frontal views:

Press the **CAMERA** button when the vehicle is stationary or moving at 12 mph (20 km/h) or slower. Press the button again to switch camera views.

### For rear reviews:

Change the gear position to **R** when the vehicle is stationary. Press the **CAMERA** button to switch to rear view mode.

You can customize the display setting. Customized Features P. 359 Surround View Camera System\*

The surround view camera system does not eliminate all blind spots. The system is for your convenience only.

Always keep the camera lenses clean and free from debris.

If the rear camera lens is covered with dirt or moisture, activate the rearview camera washer or use a soft, moist cloth to keep the lens clean and free of debris.

### Rear Wiper/Washer P. 206

Displaying an Image From the Surround View Cameras


The navigation system is disabled when the gear position is in  $[\mathbf{R}]$ .

Pressing the (home) or (back) button while the surround view camera system screen is displayed cancels the front view screen of the surround view camera system.

If you press the **CAMERA** button while the vehicle speed is more than 16 mph (25 km/h), the standby screen appears.

When the vehicle speed is reduced below 12 mph (20 km/h), the screen switches to a surround view camera system image.

# Camera Locations and Images



### Reference Lines and Guides

Following can be displayed when the system is on.

**Guidelines**: Help you to get a sense of a distance between your vehicle and the rear surroundings. The distance may appear differently than the actual distance. **Projection lines**: Indicate vehicle direction while the steering wheel is in the current position.

#### ➢Reference Lines and Guides

The positions/distances indicated by the guidelines and camera views on the display may differ from the actual positions/distances due to the changes in the vehicle height, road conditions, and other factors. The guidelines should be used as a reference only.

The guidelines can be turned on and off using the audio/information screen.


**Customized Features** P. 359

If you turn the guidelines off, they remain off until you turn them back on.

# Using the Surround View Camera System

### Checking for Obstacles at the Back of Your Vehicle


The display automatically changes to the rear view when the gear position is changed to  $[\mathbf{R}]$ .



#### Using the Surround View Camera System

The ground view can be displayed even with the door mirrors folded. However, the viewable angle and blind spot change.

Do not refer to the surround view camera system when the door mirrors are folded.




### Checking for Obstacles at the Back of Your Vehicle

When changing the gear position from/to  $[\mathbf{R}]$ , you may experience a delay in switching between the audio/information screen and a rear view image.


### Checking for the sides of your vehicle

You can display the front ground view screen using all the four cameras for the system. Pressing the **CAMERA** button when the vehicle speed is at below 12 mph (20 km/h) changes the image as follows.




#### Checking for the sides of your vehicle

If the vehicle speed exceeds 16 mph (25 km/h) while the front or side view image from the multi-view camera is displayed, the screen automatically switches to the audio/information screen.




### Checking from the front wide view at intersections

The front wide view screen is useful when you need to check for vehicles crossing from either direction at an intersection with poor visibility.



### Checking the sides of your vehicle

The side view screens are convenient when you pull over at a curb or tollbooth, or slowly pass by oncoming vehicles on a narrow road.



Checking from the front wide view at intersections

The front wide view image is a wide-angled view. The displayed image will be largely distorted, and objects may appear closer or more distant than they actually are.

#### ➢Checking the sides of your vehicle

When the door mirrors are folded, the side views cannot be displayed.

# Surround View Camera System Limitations

The system may not work properly under the following conditions.

	Conditions	Solutions	
The images may not appear clearly when:	<ul> <li>You activate the system in bad weather (heavy rain, snow, fog, etc.) or in the dark.</li> <li>Camera temperatures are high.</li> <li>A sudden change between light and dark such as an entrance or exit of a tunnel.</li> <li>You drive into the sunlight (e.g., at dawn or dusk.)</li> </ul>	Do not use the surround view camera system but rely only on visual confirmation until the conditions allow the system to work properly.	
	<ul><li>A camera lens is covered with dirt, moisture, or debris.</li><li>A camera lens is scratched.</li></ul>	Clean rear camera lenses with the rearview camera washer or a soft cloth moisturized with water, mild detergent or glass cleaner. Rear Wiper/Washer P. 206	
	The audio/information screen is dirty.	Wipe off the screen using a soft dry cloth.	
A camera angle is altered.	A camera or the area around the camera has been severely impacted.	Do not use the surround view camera system and contact a dealer.	
An error message is displayed while the surround view camera system is in use.			

## Refueling

## **Fuel Information**

### Fuel recommendation

### Unleaded premium gasoline, pump octane number 91 or higher

Use of a lower octane gasoline can cause occasional metallic knocking noise in the engine and will result in decreased engine performance. Use of a gasoline with a pump octane less than 87 can lead to engine damage.

### Top tier detergent gasoline

Because the level of detergency and additives in gasoline vary in the market, Acura endorses the use of "TOP TIER Detergent Gasoline" where available to help maintain the performance and reliability of your vehicle. TOP TIER Detergent Gasoline meets a new gasoline standard jointly established by leading automotive manufacturers to meet the needs of today's advanced engines.

Qualifying gasoline retailers will, in most cases, identify their gasoline as having met "TOP TIER Detergent Gasoline" standards at the retail location. This fuel is guaranteed to contain the proper level of detergent additives and be free of metallic additives. The proper level of detergent additives, and absence of harmful metallic additives in gasoline, help avoid buildup of deposits in your engine and emission control system.

For further important fuel-related information for your vehicle, or on information on gasoline that does not contain MMT, visit Acura Owners at *owners.acura.com* In Canada, visit *www.acura.ca* for additional information on gasoline. For more information on top tier gasoline, visit *www.toptiergas.com*.

### Fuel tank capacity: 17.1 US gal (64.7 L)

#### ➢Fuel Information


### NOTICE

We recommend quality gasoline containing detergent additives that help prevent fuel system and engine deposits. In addition, in order to maintain good performance, fuel economy, and emissions control, we strongly recommend the use of gasoline that does NOT contain harmful manganese-based fuel additives such as MMT, if such gasoline is available.

Use of gasoline with these additives may adversely affect performance, and cause the malfunction indicator lamp on your instrument panel to come on. If this happens, contact a dealer for service. Some gasoline today is blended with oxygenates such as ethanol. Your vehicle is designed to operate on oxygenated gasoline containing up to 15% ethanol by volume. Do not use gasoline containing methanol. If you notice any undesirable operating symptoms, try another service station or switch to another brand of gasoline.

## How to Refuel

Your fuel tank is not equipped with a fuel filler cap. You can insert the filler nozzle directly into the filler neck. The tank seals itself again when you pull out the filler nozzle.



- **1.** Stop your vehicle with the service station pump on the left side of the vehicle in the rear.
- 2. Turn off the engine.
- **3.** Unlock the driver's door using the master door lock switch.
  - ► The fuel fill door on the outer side of the vehicle will unlock.

### Using the Master Door Lock Switch P. 171

- **4.** Press and release the area indicated by the arrow to release the fuel fill door. You will hear a click and the lid will open slightly.
- **5.** Manually pull the fuel fill door to a fully open position.

#### ➢How to Refuel

## 


Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flames away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

The fuel filler opening is designed to accept only service station filler nozzles for refueling. Use of smaller diameter tubes (e.g., those used to siphon fuel for other uses) or other non-service station devices can damage the area in and around the filler opening.

Use the master door lock switch to unlock the fuel fill door.

The vehicle doors and fuel fill door automatically relock if the remote unlock function is used. This can be deactivated by briefly opening then closing the driver's door.



- **6.** Place the end of the filler nozzle on the lower part of filler opening, then insert it slowly and fully.
  - Make sure that the end of the filler nozzle goes down along with the filler pipe.
  - ► Keep the filler nozzle level.
  - ► When the tank is full, the filler nozzle will click off automatically.
  - ▶ If you do not fill up the tank to full, always add a minimum of 3.5 US gal (13.3 L) of fuel.
  - ► After filling, wait about five seconds before removing the filler nozzle.
- **7.** Shut the fuel fill door by hand.

### ➢How to Refuel

If the filler nozzle keeps turning off when the tank is not full, there may be a problem with the pump's fuel vapor recovery system. Try filling at another pump. If this does not fix the problem, consult a dealer.

The filler nozzle automatically stops to leave space in the fuel tank so that fuel does not overflow as a result of changes in air temperature.

Do not continue to add fuel after the filler nozzle has automatically stopped. Additional fuel can exceed the full tank capacity.

If you repeatedly fill the tank with less than the specified minimum amount of fuel, the malfunction indicator lamp may come on. If this happens, have your vehicle checked by a dealer.

If you have to refuel your vehicle from a portable container, use the funnel provided with your vehicle.

Refueling From a Portable Fuel Container P. 688

## Improving Fuel Economy and Reducing CO<sub>2</sub> Emissions

Achieving fuel economy and reducing  $CO_2$  emissions is dependent on several factors, including driving conditions, load weight, idling time, driving habits, and vehicle condition. Depending on these and other factors, you may not achieve the rated fuel economy of this vehicle.

### Maintenance and Fuel Economy

You can optimize your fuel economy with proper maintenance of your vehicle. Always maintain your vehicle in accordance with the messages displayed on the multi-information display.

- Use engine oil with the viscosity recommended.
  - Recommended Engine Oil P. 595
- Maintain the specified tire pressure.
- Do not load the vehicle with excess cargo.
- Keep your vehicle clean. A buildup of snow or mud on your vehicle's underside adds weight and increases wind resistance.

➢Improving Fuel Economy and Reducing CO₂ Emissions

Direct calculation is the recommended method to determine actual fuel consumed while driving.



In Canada, posted fuel economy numbers are established following a simulated test.

For more information on how this test is performed, please visit *https://www.nrcan.gc.ca* and search for "fuel consumption testing" in the search field at the top of the page.

## **Handling Precautions**

The turbocharger is a high-precision device to obtain greater horsepower by delivering a large volume of compressed air into the engine using a turbine driven by the engine's exhaust gas pressure.

- When the engine is cold just after starting, avoid revving the engine or sudden acceleration.
- Always replace the engine oil and engine oil filter according to the Maintenance Minder. The turbine rotates at very high speeds over 100,000 rpm and its temperature reaches over 1,292°F (700°C). It is lubricated and cooled by engine oil. If you fail to replace the engine oil and filter at the scheduled distance or interval, deteriorated engine oil may cause failure such as sticking and abnormal noise of the turbine bearing.

### Turbo Engine Vehicle

The scheduled maintenance intervals for replacing the filter is indicated on the multi-information display. Follow the information of when to replace them.

### Description 2017 Descr

The temperature gauge pointer is at the H mark when you restart the engine after driving under high load conditions such as at high speed or in hilly terrain. This is normal. The gauge goes down after you idle or drive the vehicle for about one minute. This page intentionally left blank.

# Maintenance

This chapter discusses basic maintenance.

#### **Before Performing Maintenance**

Changing the Engine Oil and Oil Filter		
Engine Coolant	600	
Transmission Fluid		
Brake Fluid	603	
Refilling Window Washer Fluid	604	
Replacing Light Bulbs	605	
Checking and Maintaining Wiper		
Blades	. 609	
Checking and Maintaining Tires		
Checking Tires	614	
Tire and Loading Information Label	615	
Tire Labeling	615	
DOT Tire Quality Grading (U.S. Vehicles		

Wear Indicators	619
Tire Service Life	619
Tire and Wheel Replacement	620
Tire Rotation	621
Winter Tires	622
Battery	623
Remote Transmitter Care	
Replacing the Remote Battery	625
Climate Control System Maintenance	627
Cleaning	
Interior Care	629
Exterior Care	632
Accessories and Modifications	636

### **Inspection and Maintenance**

For your safety, perform all listed inspections and maintenance to keep your vehicle in good condition. If you become aware of any abnormality (noise, smell, insufficient brake fluid, oil residue on the ground, etc.), have your vehicle inspected by a dealer. (Note, however, that service at a dealer is not mandatory to keep your warranties in effect.) Refer to the separate maintenance booklet for detailed maintenance and inspection information.

### Types of Inspection and Maintenance

### Routine inspections

Perform inspections before long distance trips, when washing the vehicle, or when refueling.

Maintenance P. 26

### Periodic inspections

- Check the brake fluid level monthly.
   Checking the Brake Fluid P. 603
- Check the tire pressure monthly. Examine the tread for wear and foreign objects.
   Checking and Maintaining Tires P. 614
- Check the operation of the exterior lights monthly.
   Replacing Light Bulbs P. 605
- Check the condition of the wiper blades at least every six months.
   Checking and Maintaining Wiper Blades P. 609

#### ➢Inspection and Maintenance

### U.S. models

Maintenance, replacement, or repair of emissions control devices and systems may be done by any automotive repair establishment or individuals using parts that are "certified" to EPA standards.

According to state and federal regulations, failure to perform maintenance on the maintenance main items marked with # will not void your emissions warranties. However, all maintenance services should be performed in accordance with the intervals indicated by the multi-information display.

### Maintenance Service Items P. 589

If you want to perform complex maintenance tasks that require more skills and tools, you can purchase a subscription to the Service Express website at *www.techinfo.acura.com*.

### Authorized Manuals P. 700

If you want to perform maintenance yourself, make sure that you have the necessary tools and skills first. After performing maintenance, update the records in the separate maintenance booklet.

## Safety When Performing Maintenance

Some of the most important safety precautions are given here. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether you should perform a given task.

### Maintenance Safety

- To reduce the possibility of fire or explosion, keep cigarettes, sparks, and flames away from the battery and all fuel related parts.
- Never leave rags, towels, or other flammable objects under the hood.
   Heat from the engine and exhaust can ignite them, causing a fire.
- To clean parts, use a commercially available degreaser or parts cleaner, not gasoline.
- Wear eye protection and protective clothing when working with the battery or compressed air.
- Engine exhaust contains carbon monoxide, which is poisonous and can kill you.
   Only operate the engine if there is sufficient ventilation.

### Vehicle Safety

- The vehicle must be in a stationary condition.
  - Make sure your vehicle is parked on level ground, the parking brake is set, and the engine is off.
- Be aware that hot parts can burn you.
  - Make sure to let the engine and exhaust system cool thoroughly before touching vehicle parts.
- Be aware that moving parts can injure you.
  - Do not start the engine unless instructed, and keep your hands and limbs away from moving parts.
  - ▶ Do not open the hood while the Auto Idle Stop function is activated.

Safety When Performing Maintenance

## 

Improperly maintaining this vehicle or failing to correct a problem before driving can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations according to the schedules in this owner's manual.

## 

Failure to properly follow maintenance instructions and precautions can cause you to be seriously hurt or killed.

Always follow the procedures and precautions in this owner's manual.

### Parts and Fluids Used in Maintenance Service

The use of Acura genuine parts and fluids is recommended when maintaining and servicing your vehicle. Acura genuine parts are manufactured according to the same high quality standards used in Acura vehicles.

Parts and Fluids Used in Maintenance Service

### NOTICE

Do not press the engine cover forcibly. This may damage the engine cover and component parts.

If the engine oil life is less than 15%, you will see the Maintenance Minder messages appear on the multi-information display every time you set the power mode to ON. The messages notify you when to change the engine oil, or when to bring your vehicle to a dealer for indicated maintenance services.


## To Use Maintenance Minder™

### Displaying the Maintenance Minder Information

Maintenance items, which should be serviced at the same time that you replace the engine oil, appear on the multi-information display.

You can view them on the engine oil life screen at any time.

- 1. Set the power mode to ON.
- 2. Press the right selector wheel until the content is displayed.
- **3.** Roll the right selector wheel until the **Maintenance** screen is displayed. The engine oil life appears on the multi-information display along with maintenance items due soon.



Displaying the Maintenance Minder Information

Based on the engine operating conditions, the remaining engine oil life is calculated and displayed as a percentage.

Displayed Engine Oil Life (%)	Calculated Engine Oil Life (%)
100	100 to 91
90	90 to 81
80	80 to 71
70	70 to 61
60	60 to 51
50	50 to 41
40	40 to 31
30	30 to 21
20	20 to 16
15	15 to 11
10	10 to 6
5	5 to 1
0	0

There is a list of maintenance main and sub items you can view on the multi-information display.

Maintenance Service Items P. 589

### Maintenance Minder Messages on the Multi-Information Display

Maintenance Message	Oil Life Display	Explanation	Information
—	Maintenance	When you select the <b>Maintenance</b> screen, it displays codes for maintenance items due at the next engine oil change, along with the percentage of engine oil life remaining.	_
Maintenance Due Soon	15% Maintenance	The remaining engine oil life is 15 to 6 percent. Once you switch the display by rolling the right selector wheel, this message will go off.	The engine oil is approaching the end of its service life, and the maintenance items should be inspected and serviced soon.


Maintenance Message	Oil Life Display	Explanation	Information
Maintenance Due Now Meintenance Due Now A12345	5% Maintenance	The remaining engine oil life is 5 to 1 percent. Roll the right selector wheel to switch to another display.	The engine oil has almost reached the end of its service life, and the maintenance items should be inspected and serviced as soon as possible.
Maintenance Past Due Maintenance Past Due -10miles A12345	Negative Distance Maintenance	The remaining engine oil life has passed its service life, and a negative distance appears after driving over 10 miles (U.S. models) or 10 km (Canadian models). Roll the right selector wheel to switch to another display.	The engine oil life has passed. The maintenance items must be inspected and serviced immediately.

The maintenance minder indicator (Jac) comes on along with the Maintenance message.

recommended by the Maintenance Minder. If you regularly drive your vehicle under these conditions, have the differential fluid changed at 7,500 miles (12,000 km), then every 15,000 miles (24,000 km). \*5: If a Maintenance Minder Indicator does not appear more than 36 months after the display for item 7 is

reset, change the brake fluid every 3 years.

### Maintenance Service Items



### U.S. models

CODE	Maintenance Main Items	CODE	Maintenance Sub Items
А	• Replace engine oil <sup>*1</sup>	1	Rotate tires
В	<ul> <li>Replace engine oil<sup>*1</sup> and oil filter</li> <li>Inspect front and rear brakes</li> <li>Check expiration date for Temporary Tire Repair Kit bottle (If</li> </ul>	2	<ul> <li>Replace air cleaner element<sup>*2</sup></li> <li>Replace dust and pollen filter<sup>*3</sup></li> <li>Inspect drive belt</li> </ul>
	<ul> <li>equipped)</li> <li>Inspect tie rod ends, steering gearbox, and boots</li> <li>Inspect suspension components</li> </ul>	3 4	<ul> <li>Replace transmission fluid and transfer* fluid</li> <li>Replace spark plugs</li> </ul>
	<ul> <li>Inspect driveshaft boots</li> <li>Inspect brake hoses and lines (Including ABS/VSA<sup>®</sup>)</li> <li>Inspect all fluid levels and condition of fluids</li> </ul>	5 6 7	<ul> <li>Inspect valve clearance</li> <li>Replace engine coolant</li> <li>Replace rear differential fluid<sup>*, *4</sup></li> <li>Replace brake fluid<sup>*5</sup></li> </ul>
,	<ul> <li>Inspect exhaust system<sup>#</sup></li> <li>Inspect fuel lines and connections<sup>#</sup></li> <li>st the valves during services A, B, 1, 2, or 3 if they are noisy.</li> </ul>	from *4: Drivi	J drive primarily in urban areas that have high concentrations of soot in the air from industry and diesel-powered vehicles, replace the dust and pollen filter every 15,000 miles (24,000 km). ng in mountainous areas at very low vehicle speeds or trailer towing results in higher level of fanical (Shear) stress to fluid. This requires differential fluid changes more frequently than

- \*1: If a Maintenance Minder Indicator and message does not appear more than 12 months after the display is reset, change the engine oil every year.
- #: See information on maintenance and emissions warranty.
- \*2: If you drive in dusty conditions, replace the air cleaner element every 15,000 miles (24,000 km).
- \* Not available on all models

Maintenance

#### Canadian models

CODE	Maintenance Main Items	CODE	
А	Replace engine oil <sup>*1</sup>	1	• Rotate ti
0	<ul> <li>Replace engine oil<sup>*1</sup> and oil filter</li> </ul>	2	• Replace
<ul> <li>Adjus</li> </ul>	t the valves during services A, 0, 9, 1, 2, or 3 if they are noisy.		Replace
*1: If a Maintenance Minder Indicator and message does not appear more than 12 months after the display is reset, change the engine oil every year.			• Inspect of
		3	• Replace
	Irive in dusty conditions, replace every 24,000 km (15,000 miles). Irive primarily in urban areas that have high concentrations of soot in the air from industry and	4	• Replace
	iesel-powered vehicles, replace every 24,000 km (15,000 miles).		<ul> <li>Inspect v</li> </ul>
*4: Driving in mountainous areas at very low vehicle speeds or trailer towing results in higher level of mechanical (Shear) stress to fluid. This requires differential fluid changes more frequently than recommended by the Maintenance Minder. If you requarly drive your vehicle under these conditions, have the differential fluid changed at 12,000		5	Replace
		6	• Replace
km (7,5	500 miles), thén every 24,000 km (15,000 miles).	7	Replace
	intenance Minder Indicator does not appear more than 36 months after the display for item 7 is hange the brake fluid every 3 years.	9	• Service f


- reset, change the brake fluid every 3 years. #: See information on maintenance and emissions warranty.

#### Maintenance Sub Items

- tires
- e air cleaner element\*2
  - e dust and pollen filter\*3
  - drive belt
- e transmission fluid and transfer fluid
- spark plugs
  - valve clearance
- e engine coolant
- e rear differential fluid\*4
- e brake fluid\*5
- Service front and rear brakes
  - Inspect these items:
    - Tie rod ends, steering gearbox, and boots
    - Suspension components
    - Driveshaft boots
    - Brake hoses and lines (including ABS/VSA®)
    - All fluid levels and condition of fluids
    - Exhaust system<sup>#</sup>
    - Fuel lines and connections<sup>#</sup>

### Resetting the Display

Reset the maintenance minder information display if you have performed the maintenance service.



- **1.** Set the power mode to ON.
- **2.** Press the right selector wheel until the content is displayed.
- 3. Roll the right selector wheel until the Maintenance screen is displayed.
- 4. Press and hold the right selector wheel for about 10 seconds to enter the reset mode.
- Roll the right selector wheel to select a maintenance item to reset, or to select All Due Items (You can also press the right selector wheel to the left to end the process).
- 6. Press the right selector wheel to reset the selected item.
- 7. Repeat from step 4 for other items you wish to reset.

#### Resetting the Display

### NOTICE

Failure to reset the Maintenance Minder<sup>™</sup> display after a maintenance service results in the system showing incorrect maintenance intervals, which can lead to serious mechanical problems.


The dealer will reset the Maintenance Minder<sup>™</sup> display after completing the required maintenance service. If someone other than a dealer performs maintenance service, reset the Maintenance Minder<sup>™</sup> display yourself.

You can also reset the Maintenance Minder<sup>™</sup> display using the audio/information screen.

Customized Features P. 359

## Maintenance Under the Hood

### **Maintenance Items Under the Hood**



## **Opening the Hood**



- **1.** Park the vehicle on a level surface, and set the parking brake.
- **2.** Pull the hood release handle under the driver's side lower corner of the dashboard.

**3.** Push the hood latch lever (located under

the front edge of the hood to the center) to

the side and raise the hood. Once you have raised the hood slightly, you can release the

The hood will pop up slightly.

lever.

### ➢Opening the Hood

### NOTICE

Do not open the hood when the wiper arms are raised. The hood will strike the wipers, resulting in possible damage to the hood and/or the wipers.


### NOTICE

Do not press the engine cover forcibly. This may damage the engine cover and component parts.

When closing the hood, check that the hood is securely latched.

If the hood latch lever moves stiffly, or if you can open the hood without lifting the lever, the latch mechanism should be cleaned and lubricated.

Do not open the hood while the Auto Idle Stop function is activated.





4. Lift the hood up most of the way.
► The hydraulic supports will lift it up the rest of the way and hold it up.

When closing, lower it to approximately 12 inches (30 cm), then press down firmly with your hands.

### **Engine Compartment Cover**

The component parts in the engine compartment are protected by a cover. You may need to remove the cover when you perform certain maintenance work. Pull up on the engine compartment cover carefully until all pins are removed from their grommets.



Remove the Engine Compartment Cover

## **Recommended Engine Oil**

Use a genuine engine oil or another commercial engine oil of suitable type and viscosity (for the ambient temperature) as shown in the image that follows.

Oil is a major contributor to your engine's performance and longevity. If you drive the vehicle with insufficient or deteriorated oil, the engine may fail or be damaged.

Genuine Engine Oil	Commercial Engine Oil
Acura Genuine Motor Oil	<ul> <li>API service SN or higher grade fuel- efficient oil</li> <li>API Certification Mark "Starburst"</li> </ul>
Acura Genuino Motor Oil 0W-20 <sup>-1</sup> -20 0 20 40 60 80 100(°F) -30 -20 -10 0 10 20 30 40(°C) Ambient Temperature	-20 0 20 40 60 80 100(°F) -30 -20 -10 0 10 20 30 40(°C) Ambient Temperature

\*1:Formulated to improve fuel economy.

### Synthetic oil

You may also use synthetic motor oil if it is labeled with the API Certification Seal and is the specified viscosity grade.

### Recommended Engine Oil

Engine Oil Additives

Your vehicle does not require oil additives. In fact, they may adversely affect the engine performance and durability.

The following seal indicates the oil is energy conserving and that it meets the American Petroleum Institute's latest requirements.



## **Oil Check**

We recommend that you check the engine oil level every time you refuel. Park the vehicle on level ground.

Wait approximately three minutes after turning the engine off before you check the oil.




- **1.** Remove the dipstick (orange).
- **2.** Wipe the dipstick with a clean cloth or paper towel.
- **3.** Insert the dipstick back all the way into its hole.

**4.** Remove the dipstick again, and check the lower marks. Add oil if necessary.

### ≫Oil Check

If the oil level is near or below the lower mark, slowly add oil, being careful not to overfill.



level. It should be between the upper and

## Adding Engine Oil



- **1.** Unscrew and remove the engine oil fill cap.
- 2. Add oil slowly.
- **3.** Reinstall the engine oil fill cap, and tighten it securely.
- **4.** Wait for three minutes and recheck the engine oil dipstick.

➢Adding Engine Oil

### NOTICE


Do not fill the engine oil above the upper mark. Overfilling the engine oil may result in leaks and engine damage.

If any oil spills, wipe it away immediately. Spilled oil may damage the engine compartment components.

## Changing the Engine Oil and Oil Filter

You must change the engine oil and oil filter regularly in order to maintain the engine's lubrication. The engine may be damaged if they are not changed regularly.

Change the oil and filter in accordance with the maintenance message on the multiinformation display.



Drain Bolt Washer

- **1.** Run the engine until it reaches normal operating temperature, and then turn the engine off.
- **2.** Open the hood and remove the engine oil fill cap.
- **3.** Remove the slotted head screws by turning 90° counterclockwise on the undercarriage and remove the under cover.
- **4.** Remove the drain bolt and washer from the bottom of the engine, and drain the oil into a suitable container.

#### Changing the Engine Oil and Oil Filter

### NOTICE

You may damage the environment if you do not dispose of the oil in a suitable way. If you are changing the oil by yourself, appropriately dispose of the used oil. Put the oil in a sealed container and take it to a recycling center. Do not throw the oil away into a garbage can or onto the ground.



- **5.** Remove the oil filter and dispose of the remaining oil.
- **6.** Check that the filter gasket is not stuck to the engine contact surface.

▶ If it is stuck, you must detach it.

- **7.** Wipe away dirt and dust adhering to the contact surface of the engine block, and install a new oil filter.
  - Apply a light coat of new engine oil to the filter gasket.
- **8.** Put a new washer on the drain bolt, then reinstall the drain bolt.
  - ► Tightening torque:
    - 29 lbf·ft (40 N·m, 4.0 kgf·m)
- **9.** Pour the recommended engine oil into the engine.
  - Engine oil change capacity (including filter):

5.0 US qt (4.8 L)

- **10.** Reinstall the engine oil fill cap securely and start the engine.
- **11.** Run the engine for a few minutes, and then check that there is no leak from the drain bolt or oil filter.
- **12.** Stop the engine, wait for three minutes, and then check the oil level on the dipstick.
  - ▶ If necessary, add more engine oil.

### Changing the Engine Oil and Oil Filter

You will need a special wrench to replace the oil filter. You can buy this wrench from a dealer.

When installing the new oil filter, follow the instructions supplied with the oil filter.

Reinstall the engine oil fill cap. Start the engine. The low oil pressure indicator should go off within five seconds. If it does not, turn off the engine, and check your work.


## **Engine Coolant**

### Specified coolant: Acura Long Life Antifreeze/Coolant Type 2

This coolant is premixed with 50% antifreeze and 50% water. Do not add any straight antifreeze or water.

We recommend you check the engine coolant level every time you refuel. Check the reserve tank first. If it is completely empty, also check the coolant level in the radiator. Add the engine coolant accordingly.

### Reserve Tank



- 1. Make sure the engine and radiator are cool.
- **2.** Check the amount of coolant in the reserve tank.
  - If the coolant level is below the MIN mark, add the specified coolant until it reaches the MAX mark.
- **3.** Inspect the cooling system for leaks.

#### ➢Engine Coolant


### NOTICE

Genuine Acura engine coolant is a 50/50 mixture of antifreeze and water that can withstand freezing at temperatures as low as about -31°F (-35°C). If your vehicle is consistently subjected to temperatures below this, the concentration of antifreeze in the coolant should be increased. Consult a dealer for details.

If Acura antifreeze/coolant is not available, you may use another major brand of non-silicate coolant as a temporary replacement. Check that it is a high quality coolant recommended for aluminum engines. Continued use of any non-Acura coolant can result in corrosion, causing the cooling system to malfunction or fail. Have the cooling system flushed and refilled with Acura antifreeze/coolant as soon as possible.

Do not add rust inhibitors or other additives to your vehicle's cooling system. They may not be compatible with the coolant or with the engine components.

### Radiator



- 1. Make sure the engine and radiator are cool.
- 2. Remove the engine compartment cover. ⇒ Engine Compartment Cover P. 594
- **3.** Turn the radiator cap 1/8 turn counterclockwise and relieve any pressure in the cooling system.
- **4.** Push down and turn the radiator cap counterclockwise to remove it.
- **5.** The coolant level should be up to the base of the filler neck. Add coolant if it is low.
- **6.** Put the radiator cap back on, and tighten it fully.

### Radiator

## 

Removing the radiator cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the radiator cap.

### NOTICE

Pour the fluid slowly and carefully so you do not spill any. Clean up any spills immediately; they can damage components in the engine compartment.

### **Transmission Fluid**

### Automatic Transmission Fluid

### Specified fluid: Acura ATF-type 2.0

Have a dealer check the fluid level and replace if necessary.

Do not attempt to check or change the automatic transmission fluid yourself.

#### ➢Automatic Transmission Fluid

#### NOTICE

## Do not mix Acura ATF-type 2.0 with other transmission fluids.


Using a transmission fluid other than Acura ATF-type 2.0 may adversely affect the operation and durability of your vehicle's transmission, and damage the transmission.

Any damage caused by using a transmission fluid that is not equivalent to Acura ATF-type 2.0 is not covered by Acura's new vehicle limited warranty.

## **Brake Fluid**

### Specified fluid: Acura Heavy Duty Brake Fluid DOT 3

### Checking the Brake Fluid



The fluid level should be between the **MIN** and **MAX** marks on the side of the reserve tank.

#### ≫Brake Fluid

### NOTICE

Brake fluid marked DOT 5 is not compatible with your vehicle's braking system and can cause extensive damage.

If the specified brake fluid is not available, you should use only DOT 3 or DOT 4 fluid from a sealed container as a temporary replacement.

Using any non-Acura brake fluid can cause corrosion and decrease the longevity of the system. Have the brake system flushed and refilled with Acura Heavy Duty Brake Fluid DOT 3 as soon as possible.

If the brake fluid level is at or below the **MIN** mark, have a dealer inspect the vehicle for leaks or worn brake pads as soon as possible.

## **Refilling Window Washer Fluid**

Cap

Open the cap and check the amount of window washer fluid.

If the level is low, fill the washer reservoir.

### Canadian models

If the washer fluid is low, a message appears on the multi-information display.

#### Refilling Window Washer Fluid

### NOTICE

Do not use engine antifreeze or a vinegar/water solution in the windshield washer reservoir. Antifreeze can damage your vehicle's paint. A vinegar/water solution can damage the windshield washer pump.

Use only commercially available windshield washer fluid.

Avoid prolonged use of hard water to prevent lime scale buildup.

Pour the washer fluid carefully. Do not overflow the reservoir.

## **Replacing Light Bulbs**

## Headlights

Headlights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

## Front Turn Signal, Parking/Chicane<sup>™</sup> Daytime Running and Front Side Marker Lights

Front turn signal, parking/daytime running and front side marker lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

## Fog Lights\*

Fog lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

## Side Turn Signal/Emergency Indicator Lights

Door mirror side turn lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.


### Headlights

The headlight aim is set by the factory, and does not need to be adjusted. However, if you regularly carry heavy items in the cargo area or tow a trailer, have the aiming readjusted at a dealer or by a qualified technician.

## **Rear Turn Signal Light Bulbs**


When replacing, use the following bulbs.

### Rear Turn Signal Light: 21 W (PY21W Amber/Silver)



- **1.** Remove the cover by prying on the edge using a flat-tip screwdriver.
  - ▶ Wrap the flat-tip screwdriver with a cloth to prevent scratches.

- **2.** Use a Phillips-head screwdriver to remove the bolts.
- **3.** Pull the light assembly out of the rear pillar.



- **4.** Turn the socket counterclockwise and remove it.
- **5.** Remove the old bulb and insert a new bulb.

## Chicane<sup>™</sup> Taillights, Brake and Rear Side Marker Lights

Taillights, brake and rear side marker lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

## Chicane<sup>™</sup> Taillights/Brake and Back-Up Lights

Taillights/brake and back-up lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

### **Rear License Plate Light**

Rear license plate light is LED type. Have an authorized Acura dealer inspect and replace the light assembly.

### **High-Mount Brake Light**

High-mount brake light is LED type. Have an authorized Acura dealer inspect and replace the light assembly.

### Puddle Lights\*

Puddle lights are LED type. Have an authorized Acura dealer inspect and replace the light assembly.

## **Checking Wiper Blades**

If the wiper blade rubber has deteriorated, it will leave streaks, become noisy, and the hard surfaces of the blade may scratch the window glass.

### **Changing the Front Wiper Blade Rubber**



- **1.** Set the power mode to VEHICLE OFF.
- 2. While holding the wiper switch in the **MIST** position, set the power mode to ON, then to VEHICLE OFF.
  - Both wiper arms are set to the maintenance position as shown in the image.
- 3. Lift both wiper arms.

Changing the Front Wiper Blade Rubber

### NOTICE


When lifting the wiper arms, always follow the instructions to move them into the maintenance position.

The wiper arms may be damaged if they are moved manually.

### NOTICE

Avoid dropping the wiper arm onto the windshield, it may damage the wiper arm and/or the windshield.






4. Press up on and hold the tab, then slide the holder off the wiper arm.

5. Pull the end of the wiper blade in the direction of the arrow in the image until it is out of the holder's end cap.

- **6.** Pull the wiper blade in the opposite direction to slide it out of the holder.



- **7.** Insert the flat side of the new wiper blade onto the bottom part of the holder. Insert the blade all the way.
- **8.** Install the end of the wiper blade into the cap.
- **9.** Slide the holder onto the wiper arm until it locks.
- **10.** Lower both wiper arms.
- **11.** Set the power mode to ON and hold the wiper switch in the **MIST** position until both wiper arms return to the standard position.

## **Changing the Rear Wiper Blade Rubber**



**1.** Raise the wiper arm off.

Blade

**2.** Slide the wiper blade out from the end with the indent.

Retainer


**3.** Remove the retainers from wiper blade and mount to a new rubber blade.

➢Changing the Rear Wiper Blade Rubber

#### NOTICE

Avoid dropping the wiper arm, it may damage the rear window.





- **4.** Slide the new wiper blade onto the holder.
  - Make sure it is engaged correctly, then install the wiper blade assembly onto the wiper arm.

## **Checking Tires**

To safely operate your vehicle, your tires must be of the proper type and size, in good condition with adequate tread, and properly inflated.

#### ■ Inflation guidelines

Properly inflated tires provide the best combination of handling, tread life, and comfort. Refer to the driver's doorjamb label or specifications page for the specified pressure.

Underinflated tires wear unevenly, adversely affect handling and fuel economy, and are more likely to fail from overheating.

Overinflated tires make your vehicle ride harshly, are more prone to road hazards, and wear unevenly.

Every day before you drive, look at each of the tires. If one looks lower than the others, check the pressure with a tire gauge.

At least once a month or before long trips, use a gauge to measure the pressure in all tires, including the spare<sup>\*</sup>. Even tires in good condition can lose 1–2 psi (10–20 kPa, 0.1-0.2 kgf/cm<sup>2</sup>) per month.

#### Inspection guidelines

Every time you check inflation, also examine the tires and valve stems. Look for:

- Bumps or bulges on the side or in the tread. Replace the tire if you find any cuts, splits, or cracks in the side of the tire. Replace it if you see fabric or cord.
- Remove any foreign objects and inspect for air leaks.
- Uneven tread wear. Have a dealer check the wheel alignment.
- Excessive tread wear.
  - Wear Indicators P. 619
- Cracks or other damage around valve stem.
- 614 \* Not available on all models

#### Checking Tires

## **A**WARNING

Using tires that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tire inflation and maintenance.


Measure the air pressure when tires are cold. This means the vehicle has been parked for at least three hours, or driven less than 1 mile (1.6 km). If necessary, add or release air until the specified pressure is reached.

If checked when hot, tire pressure can be as much as 4–6 psi (30–40 kPa, 0.3–0.4 kgf/cm<sup>2</sup>) higher than if checked when cold.


Have a dealer check the tires if you feel a consistent vibration while driving. New tires and any that have been removed and reinstalled should be properly balanced.

## **Tire and Loading Information Label**

The label attached to the driver's doorjamb provides necessary tire and loading information.



## **Tire Labeling**



The tires that came on your vehicle have a number of markings. Those you should be aware of are described as shown.

#### ■Tire and Loading Information Label

The tire and loading information label attached to the driver's doorjamb contains:

- 1 The number of people your vehicle can carry.
- 2 The total weight your vehicle can carry. Do not exceed this weight.
- 3 The original tire sizes for front, rear, and spare.

The proper cold tire pressure for front, rear, and spare.

#### ≫Tire Sizes

Following is an example of tire size with an explanation of what each component means. **P235/60 R18 102T** P: Vehicle type (P indicates passenger vehicle). 235: Tire width in millimeters. 60: Aspect ratio (the tire's section height as a percentage of its width). R: Tire construction code (R indicates radial). 18: Rim diameter in inches. 102: Load index (a numerical code associated with the maximum load the tire can carry). T: Speed symbol (an alphabetical code indicating the maximum speed rating).

#### Tire Sizes

Whenever tires are replaced, they should be replaced with tires of the same size.

#### Tire Identification Number (TIN)

The tire identification number (TIN) is a group of numbers and letters that look like the example in the side column. TIN is located on the sidewall of the tire.

#### Glossary of Tire Terminology

**Cold Tire Pressure** – The tire air pressure when the vehicle has been parked for at least three hours or driven less than 1 mile (1.6 km).

**Load Rating** – Means the maximum load that a tire is rated to carry for a given inflation pressure.

**Maximum Inflation Pressure** – The maximum tire air pressure that the tire can hold.

**Maximum Load Rating** – Means the load rating for a tire at the maximum permissible inflation pressure for that tire.

**Recommended Inflation Pressure** – The cold tire inflation pressure recommended by the manufacturer.

**Treadwear Indicators (TWI)** – Means the projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread.

➢Tire Identification Number (TIN)

#### DOT B97R FW6X 2209

DOT: This indicates that the tire meets all requirements of the U.S. Department of Transportation. B97R: Manufacturer's identification mark. FW6X: Tire type code. 22 09: Date of manufacture.

Year Week

## **DOT Tire Quality Grading (U.S. Vehicles)**

The tires on your vehicle meet all U.S. Federal Safety Requirements. All tires are also graded for treadwear, traction, and temperature performance according to Department of Transportation (DOT) standards. The following explains these gradings.

#### Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

#### Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half (1 1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate. Uniform Tire Quality Grading

For example: Treadwear 200 Traction AA Temperature A

All passenger car tires must conform to Federal Safety Requirements in addition to these grades.

#### Traction

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

#### Temperature

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.


#### ≫Traction

Warning: The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

#### ≫Temperature

Warning: The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

## **Wear Indicators**



The groove where the wear indicator is located is about 1/16 inch (about 1.6 mm) shallower than elsewhere on the tire. If the tread has worn so that the indicator is exposed, replace the tire. **Worn out tires have poor traction on wet roads.** 

## **Tire Service Life**

The life of your tires is dependent on many factors, including driving habits, road conditions, vehicle loading, inflation pressure, maintenance history, speed, and environmental conditions (even when the tires are not in use).

In addition to regular inspections and inflation pressure maintenance, it is recommended that you have annual inspections performed once the tires reach five years old. All tires, including the spare<sup>\*</sup>, should be removed from service after 10 years from the date of manufacture, regardless of their condition or state of wear.

## **Tire and Wheel Replacement**

Replace your tires with radials of the same size, load range, speed rating, and maximum cold tire pressure rating (as shown on the tire's sidewall). Using tires of a different size or construction can cause certain vehicle systems such as the ABS and Vehicle Stability Assist™ (VSA®) system to work incorrectly.

It is best to replace all four tires at the same time. If that isn't possible, replace the front or rear tires in pairs.

Whenever you have a tire replaced or reset, make sure that the rubber valve stem is replaced and that the TPMS sensor is transferred from the old valve stem to the new one.

If you replace a wheel, make sure that the wheel's specifications match those of the original wheels.

➢Tire and Wheel Replacement

## 

Installing improper tires on your vehicle can affect handling and stability. This can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tires recommended in this owner's manual.

## **Tire Rotation**


Front

Rotating tires according to the maintenance messages on the multi-information display helps to distribute wear more evenly and increase tire life.

#### Tires without rotation marks

Rotate the tires as shown here.






Rotate the tires as shown here.

#### ➢Tire Rotation

Tires with directional tread patterns should only be rotated front to back (not from one side to the other). Directional tires should be mounted with the rotation indication mark facing forward, as shown below.



## Winter Tires

If driving on snowy or frozen roads, mount all season marked M+S tires, snow tires, or tire chains; reduce speed; and maintain sufficient distance between vehicles when driving.

Be particularly careful when operating the steering wheel or brakes to prevent skidding.

Use tire chains, snow tires, or all season tires when necessary or according to the law.

When mounting, refer to the following points.

For winter tires:

- Select the size and load ranges that are the same as the original tires.
- Mount the tires to all four wheels.

For tire chains:

- Install them on the front tires only.
- Because your vehicle has limited tire clearance, we strongly recommend using the chains listed below:

#### Cable-type: QCC Cobra 1046

- Follow the chain manufacturer's instruction when installing. Mount them as tightly as you can.
- Check that the chains do not touch the brake lines or suspension.
- Drive slowly.

#### Winter Tires

## 

Using the wrong chains, or not properly installing chains, can damage the brake lines and cause a crash in which you can be seriously injured or killed.

Follow all instructions in this owner's manual regarding the selection and use of tire chains.

#### NOTICE


Traction devices that are the wrong size or improperly installed can damage your vehicle's brake lines, suspension, body, and wheels. Stop driving if they are hitting any part of the vehicle.

When tire chains are mounted, follow the chain manufacturer's instructions regarding vehicle operational limits.

If your vehicle is equipped with summer tires, be aware that these tires are not designed for winter driving conditions. For more information, contact a dealer.

## Battery

## **Checking the Battery**



The condition of the battery is monitored by a sensor located on the negative terminal of the battery. If there is a problem with this sensor, the multi-information display will display a warning message. If this happens, have your vehicle inspected by a dealer.

Check the battery terminals for corrosion monthly.

If your vehicle's battery is disconnected or goes dead:

• The audio system is disabled.

Audio System Theft Protection P. 257

The clock resets.
 Clock P. 154

#### Canadian models only

The immobilizer system needs to be reset.
 Immobilizer System Indicator P. 99

#### ≫Battery

## 

The battery gives off explosive hydrogen gas during normal operation.

A spark or flame can cause the battery to explode with enough force to kill or seriously hurt you.

When conducting any battery maintenance, wear protective clothing and a face shield, or have a skilled technician do it.

**WARNING:** Battery post, terminals, and related accessories contain lead and lead compounds. **Wash your hands after handling.** 

When you find corrosion, clean the battery terminals by applying a baking powder and water solution. Clean the terminals with a damp towel. Cloth/towel dry the battery. Coat the terminals with grease to help prevent future corrosion.

When replacing the battery, the replacement must be of the same specifications. Consult a dealer for more information.

## **Charging the AGM Battery**

AGM labeled batteries like those installed in your vehicle require a compatible charger to be properly charged. Damage to the battery can result if the battery is charged improperly or with the wrong equipment. For more information on how to charge your vehicle's AGM battery, consult a dealer.


#### ➢Battery

The battery installed in this vehicle is specifically designed for a model with Auto Idle Stop. Using a battery other than this specified type may shorten the battery life, and prevent Auto Idle Stop from activating. If you need to replace the battery, make sure to select the specified type and size. Ask a dealer for more details.

## **Replacing the Remote Battery**

#### Models without two-way keyless remote

If the indicator does not come on when the button is pressed, replace the battery.



# Cover Cover

#### Battery type: CR2032

**1.** Remove the built-in key.

- **2.** Pry on the edge of the cover using a flat-tip screwdriver to remove the cover.
  - Wrap the flat-tip screwdriver with a cloth to prevent scratches.
- **3.** Make sure to replace the battery with the correct polarity.

➢Replacing the Remote Battery

## 

CHEMICAL BURN HAZARD The battery that powers the remote transmitter can cause severe internal burns and can even lead to death if swallowed. Keep new and used batteries away from children.

If you suspect that a child has swallowed the battery, seek medical attention immediately.


#### NOTICE

An improperly disposed of battery can damage the environment. Always confirm local regulations for battery disposal.

Replacement batteries are commercially available or at a dealer.

#### Models with two-way keyless remote

If the indicator does not come on when the button is pressed, replace the battery.




#### Battery type: CR2032

**1.** Remove the built-in key.

#### ➢Replacing the Remote Battery

## Models with two-way keyless remote NOTICE

The Remote transmitter is equipped with two batteries: A standard replaceable CR2032 coin button battery and an integral non-replaceable rechargeable battery. To prevent permanent damage to the rechargeable battery, replace the CR2032 battery every three to four years.



- **2.** Pry on the edge of the cover using a flat-tip screwdriver to remove the cover.
  - Wrap the flat-tip screwdriver with a cloth to prevent scratches.
- **3.** Make sure to replace the battery with the correct polarity.

## **Air Conditioning**

To ensure proper and safe operation, the Society of Automotive Engineers (SAE J2845) recommends that the refrigerant system only be serviced by trained and certified technicians.

Never repair or replace the air conditioning evaporator (cooling coil) with one removed from a used or salvaged vehicle.

New replacement mobile air conditioning evaporators must be certified (and labeled) as meeting SAE Standard J2842.

#### Climate Control System Maintenance

#### NOTICE

Vented refrigerant is harmful to the environment. To avoid refrigerant from venting, never replace the evaporator with one removed from a used or salvaged vehicle.

Refrigerant in your vehicle's air conditioning system is flammable and can be ignited during servicing if proper procedures are not followed.

The air conditioner label is found under the hood:

Safety Labels P. 78
 Specifications P. 690

#### Canadian models



- 🕂 : Caution
  - · : Flammable Refrigerant
- : Requires Registered Technician to Service
- System

## **Dust and Pollen Filter**

The climate control system is equipped with a dust and pollen filter that collects pollen, dust, and other debris in the air. The Maintenance Minder<sup>™</sup> messages will let you know when to replace the filter.

We recommend that you replace the dust and pollen filter sooner when using your vehicle in areas with high concentrations of dust.

#### ➢Dust and Pollen Filter

If the airflow from the climate control system deteriorates noticeably, and the windows fog up easily, the filter may need to be replaced. Please contact a dealer for replacement.


## Cleaning

## **Interior Care**

Use a damp cloth with a mixture of mild detergent and warm water to remove dirt. Use a clean cloth to remove detergent residue.

#### **Cleaning Seat Belts**

Use a soft brush with a mixture of mild soap and warm water to clean the seat belts. Let the belts air dry. Wipe the openings of the seat belt anchors using a clean cloth.



#### ➢Interior Care

Do not spill liquids inside the vehicle. Electrical devices and systems may malfunction if liquids are splashed on them.

Do not use silicone based sprays on electrical devices such as audio devices and switches. Doing so may cause the items to malfunction or cause a fire inside the vehicle.

If a silicone based spray is inadvertently used on electrical devices, consult a dealer.

Depending on their composition, chemicals and liquid aromatics may cause discoloration, wrinkles, and cracking to resin-based parts and textiles. Do not use alkali solvents or organic solvents such as benzene or gasoline.


After using chemicals, make sure to gently wipe them away using a dry cloth.

Do not place used cloths on top of resin based parts or textiles for long periods of time without washing.

#### Cleaning the Window

Wipe using a glass cleaner.

#### Floor Mats



The driver's floor mat hooks over floor anchors, which keep the mat from sliding forward.

Do not put any additional floor mats on top of the anchored mat.

#### Cleaning the Window

Wires are mounted to the inside of the rear window. Wipe along the same direction as the wires with a soft cloth so as not to damage them.

Be careful not to spill fluids, such as water or glass cleaner, on or around the cover of both the electrical components around the rearview mirror.

#### ➢Floor Mats

If you use any floor mats that were not originally provided with your vehicle, make sure they are designed for your specific vehicle, fit correctly, and are securely anchored by the floor anchors. Position any rear seat floor mats properly. If not properly positioned, the floor mats can interfere with the front seat functions.

#### Maintaining Genuine Leather

To properly clean leather:

- 1. Use a vacuum or soft dry cloth first to remove any dirt or dust.
- **2.** Clean the leather with a soft cloth dampened with a solution comprised of 90% water and 10% neutral soap.
- 3. Wipe away any soap residue with a clean damp cloth.
- 4. Wipe away residual water and allow leather to air dry in the shade.

#### Maintaining Genuine Leather

It is important to clean or wipe away dirt or dust as soon as possible. Spills can soak into leather resulting in stains. Dirt or dust can cause abrasions in the leather. In addition, please note that some dark colored clothing can rub onto the leather seats resulting in discoloration or stains.

## **Exterior Care**

Dust off the vehicle body after you drive. Regularly inspect your vehicle for scratches on painted surfaces. A scratch on a painted surface can result in body rust. If you find a scratch, promptly repair it.

#### Washing the Vehicle

Wash the vehicle regularly. Wash more frequently when driving in the following conditions:

- If driving on roads with road salt.
- If driving in coastal areas.
- If tar, soot, bird droppings, insects, or tree sap are stuck to painted surfaces.

Washing the Vehicle

Do not spray water into the air intake vents. It can cause a malfunction.



Lock the doors when washing the vehicle. Do not spray water onto the fuel fill door directly. A high-pressure spray may cause it to open.

Do not spray water onto the capless unit when the fuel fill door is open. It can cause damage to the fuel system or engine.

If you need to lift the wiper arms away from the windshield, first set the wiper arms to the maintenance position.

Changing the Front Wiper Blade Rubber P. 609

#### Using an Automated Car Wash

- Make sure to follow the instructions indicated on the automated car wash.
- Fold in the door mirrors.
- For models equipped with automatic intermittent wipers, turn the wipers off.

#### Using High Pressure Cleaners

- Keep sufficient distance between the cleaning nozzle and the vehicle body.
- Take particular care around the windows. Standing too close may cause water to enter the vehicle interior.
- Do not spray high pressure water directly into the engine compartment. Instead, use low pressure water and a mild detergent.
- Do not spray water directly onto the camera or the area around it. Water may enter the lens and cause the camera to malfunction.

#### ▶ Using an Automated Car Wash

When using an automated car wash that pulls the vehicle through with a conveyor, make sure vehicle is in car wash mode.

#### If you want to keep the transmission in N position [car wash mode] P. 455

Always wash the vehicle by hand with a mild car wash detergent and plenty of water.

#### Applying Wax

A good coat of automotive body wax helps protect your vehicle's paint from the elements. Wax will wear off over time and expose your vehicle's paint to the elements, so reapply as necessary.

#### Maintaining the Bumpers and Other Resin Coated Parts

If you get gasoline, oil, engine coolant, or battery fluid on resin coated parts, they may be stained or the coating may peel. Promptly wipe it away using a soft cloth and clean water.

#### Cleaning the Window

Wipe using a glass cleaner.

#### ➢Applying Wax

#### NOTICE

Chemical solvents and strong cleaners can damage the paint, metal, and plastic on your vehicle. Wipe away spills immediately.

#### Maintaining the Bumpers and Other Resin Coated Parts

Ask a dealer about the correct coating material when you want to repair the painted surface of the parts made of resin.

#### Maintaining Aluminum Wheels

Aluminum is susceptible to deterioration caused by salt and other road contaminants. When necessary, as early as possible use a sponge and mild detergent to wipe away these contaminants. Do not use a stiff brush or harsh chemicals (including some commercial wheel cleaners). These can damage the protective finish on aluminum alloy wheels, resulting in corrosion. Depending on the type of finish, the wheels also may lose their luster or appear burnished. To avoid water stains, wipe the wheels dry with a cloth while they are still wet.

#### Fogged Exterior Light Lenses

The inside lenses of exterior lights (headlights, brake lights, etc.) may fog temporarily if you have driven in the rain, or after the vehicle has been run through a car wash. Dew condensation also may build up inside the lenses when there is a significant enough difference between the ambient and inside lens temperatures (similar to vehicle windows fogging up in rainy conditions). These conditions are natural processes, not structural design problems in the exterior lights.

Lens design characteristics may result in moisture developing on the light lens frame surfaces. This also is not a malfunction.

However, if you see large amounts of water accumulation, or large water drops building up inside the lenses, have your vehicle inspected by a dealer.

## Accessories

When installing accessories, check the following:

- Do not install accessories on the windshield. They can obstruct your view and delay your reaction to driving conditions.
- Do not install any accessories over areas marked SRS Airbag, on the sides or backs of the front seats, on front or side pillars, or near the side windows. Accessories installed in these areas may interfere with proper operation of the vehicle's airbags or may be propelled into you or another occupant if the airbags deploy.
- Be sure electronic accessories do not overload electrical circuits or interfere with proper operation of your vehicle.

**Fuses** P. 678

- Before installing any electronic accessory, have the installer contact a dealer for assistance. If possible, have a dealer inspect the final installation.
- It is recommended to use genuine Acura roof bicycle racks for carrying bicycles. Do not install load-carrying (strap-type) accessory racks to the tailgate, as they may interfere with normal operation, which may result in damage to the tailgate.

Accessories and Modifications

## 

Improper accessories or modifications can affect your vehicle's handling, stability, and performance, and cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

Acura Genuine accessories are recommended to ensure proper operation on your vehicle.

## **Modifications**

Do not modify your vehicle in a manner that may affect its handling, stability, or reliability, or install non-genuine Acura parts or accessories that may have a similar effect.

Even minor modifications to vehicle systems can affect overall vehicle performance. Always make sure all equipment is properly installed and maintained, and do not make any modification to your vehicle or its systems that might cause your vehicle to no longer meet federal, state, province, territory, and local regulations.

The on-board diagnostic port (OBD-II/SAE J1962 connector) installed on this vehicle is intended to be used with automobile system diagnostic devices or with other devices that Acura has approved. Use of any other type of device may adversely affect the vehicle's electronic systems or allow them to be compromised, possibly resulting in a system malfunction, drained battery, or other unexpected problems.

Do not modify or attempt to repair any of the electrical components.

This page intentionally left blank.

## Handling the Unexpected

This chapter explains how to handle unexpected troubles.


l ools
If a Tire Goes Flat
Vehicles with a compact spare tire
Changing a Flat Tire641
Vehicles with temporary tire repair kit
Temporarily Repairing a Flat Tire 649
Models with temporary tire repair kit
Handling of the Jack
Engine Does Not Start
Checking the Engine
If the Keyless Remote Battery is Weak 665
Emergency Engine Stop

if the Battery is Dead	
Jump Starting Procedure	667
Overheating	
Indicator, Coming On/Blinking	
If the Engine Oil Pressure Low Warning	
Appears	671
If the Charging System Indicator Comes On	672
If the Malfunction Indicator Lamp Co	omes
On or Blinks	672
If the Brake System Indicator (Red) Co	nes
On or Blinks	. 673
If the Electric Power Steering (EPS) Syst	em
Indicator Comes On	674

If the Brake System Indicator (Red) Comes Or
or Blinks at the Same Time When the Brake
System Indicator (Amber) Comes On675
If the Low Tire Pressure/TPMS Indicator
Comes On or Blinks 676
If the Transmission System Indicator Blinks
along with the Warning Message 677
Fuses
Emergency Towing 685
If You Cannot Unlock the Fuel Fill Door 686
If You Cannot Open the Tailgate 687
Refueling 688

## Tools

## **Types of Tools**



#### ➢Types of Tools

The tools are stored in the cargo area.

#### Vehicles with a compact spare tire Changing a Flat Tire

If a tire goes flat while driving, grasp the steering wheel firmly and brake gradually to reduce speed. Then, stop in a safe place. Replace the flat tire with a compact spare tire. Go to a dealer as soon as possible to have the full-size tire repaired or replaced.

- **1.** Park the vehicle on a firm, level, non-slippery surface and apply the parking brake.
- **2.** Change the gear position to **P**.
- 3. Turn on the hazard warning lights and set the power mode to VEHICLE OFF.

#### ➢Changing a Flat Tire

Follow compact spare precautions: Periodically check the tire pressure of the compact spare. It should be set to the specified pressure. Specified Pressure: 60 psi (420 kPa, 4.2 kgf/cm<sup>2</sup>)

When driving with the compact spare tire, keep the vehicle speed under 50 mph (80 km/h). Replace with a full-size tire as soon as possible.

The compact spare tire and wheel in your vehicle are specifically for this model. Do not use them with another vehicle. Do not use another type of compact spare tire or wheel with your vehicle.

Do not mount tire chains on a compact spare tire. If a chain-mounted front tire goes flat, remove one of the full-size rear tires and replace it with the compact spare tire. Remove the flat front tire and replace it with the full-size tire that was removed from the rear. Mount the tire chains on the front tire.

Do not use a puncture-repairing agent on a flat tire, as it can damage the tire pressure sensor.

#### Getting Ready to Replace the Flat Tire




**1.** Push the rear edge of the handle on the floor lid and open the lid.


#### ➢Changing a Flat Tire

#### NOTICE

Do not use the jack if it doesn't work properly. Call your dealer or a professional towing service.


The wheel nut wrench supplied with your vehicle is specially adapted to fit the holder shaft. Do not use any other tool.






**2.** Push the tabs to open the tool box lid.


**3.** Take the jack, wheel nut wrench, and jack handle bar out of the tool box.






**4.** Remove the cover and the rubber plug on the cargo area lining to access the shaft for the spare tire hoist.

**5.** Put the wheel nut wrench with the jack handle bar on the hoist shaft. Turn the wrench to the left to lower the spare tire to the ground.



- **6.** Keep turning the wheel nut wrench to create slack in the cable.
- 7. Remove the bracket from the spare tire.



**8.** Place a wheel block or rock in front and rear of the wheel diagonal to the flat tire.




**9.** Place the compact spare tire (wheel side up) under the vehicle body, near the tire that needs to be replaced.



**10.** Loosen each wheel nut about one turn using the wheel nut wrench.

#### How to Set Up the Jack





**1.** Place the jack under the jacking point closest to the tire to be changed.

- **2.** Turn the end bracket clockwise as shown in the image until the top of the jack contacts the jacking point.
  - Make sure that the jacking point tab is resting in the jack notch.

**3.** Raise the vehicle, using the jack handle bar and the jack handle, until the tire is off the ground.

#### ➢How to Set Up the Jack

## 

The vehicle can easily roll off the jack, seriously injuring anyone underneath.

Follow the directions for changing a tire exactly, and never get under the vehicle when it is supported only by the jack.


Do not use the jack with people or luggage in the vehicle.

Use the jack provided in your vehicle.

Other jacks may not support the weight ("load") or may not fit the jacking point.


The following instructions must be followed to use the jack safely:

- Do not use while the engine is running.
- Use only where the ground is firm and level.
- Use only at the jacking points.
- Do not get in the vehicle while using the jack.
- Do not put anything on top of or underneath the jack.



#### Replacing the Flat Tire





1. Remove the wheel nuts and flat tire.

- **2.** Wipe the mounting surfaces of the wheel with a clean cloth.
- **3.** Mount the compact spare tire.
- **4.** Screw the wheel nuts until they touch the lips around the mounting holes, then stop rotating.




**5.** Lower the vehicle and remove the jack. Tighten the wheel nuts in the order indicated in the image. Go around tightening the nuts two to three times in this order.

Wheel nut torque: 80 lbf·ft (108 N·m, 11 kgf·m)

#### ■Replacing the Flat Tire

Do not over tighten the wheel nuts by applying extra torque using your foot or a pipe.

#### Storing the Flat Tire




- **1.** Put the flat tire in the storage bag provided with your vehicle.
  - ► The storage bag is in the tool box.
- **2.** Knot the top of the storage bag.
- **3.** Securely put the jack, jack handle bar, and wheel nut wrench back in the tool box.
- **4.** Bore through the bag, and pass the holding belt through the hole of the bag and the wheel of the flat tire as shown.


#### Storing the Flat Tire

# 

Loose items can fly around the interior in a crash and can seriously injure the occupants.

Store the wheel, jack, and tools securely before driving.





- **5.** Place the flat tire in the cargo area, and thread the belt through the tie-down anchor as shown.
- **6.** Pass the belt through the ring, and tighten the belt to secure the flat tire in place.

#### TPMS and the Compact Spare Tire

If you replace a flat tire with the spare tire, the low tire pressure/TPMS indicator comes on while you are driving. After driving for a few miles (kilometers), **Tire Pressure Monitor System Problem. Check Tire Pressure. See Your Dealer** will appear on the multi-information display and the indicator will start blinking for a short time and then stay on; however, this is normal and is no cause for concern.

If you replace the tire with a full-size tire, the warning message on the multiinformation display and the low tire pressure/TPMS indicator will go off after a few miles (kilometers).

#### ➢TPMS and the Compact Spare Tire

The system cannot monitor the pressure of the spare tire. Manually check the spare tire pressure to be sure that it is correct.

Use the TPMS specific wheels. Each is equipped with a tire pressure sensor mounted inside the tire behind the valve stem.

#### Vehicles with temporary tire repair kit Temporarily Repairing a Flat Tire

If the tire has a large cut or is otherwise severely damaged, you will need to have the vehicle towed. If the tire only has a small puncture, from a nail for instance, you can use the temporary tire repair kit so that you can drive to the nearest service station for a more permanent repair.


If a tire goes flat while driving, grasp the steering wheel firmly and brake gradually to reduce speed. Then, stop in a safe place.

- **1.** Park the vehicle on a firm, level, and non-slippery surface and apply the parking brake.
- **2.** Change the gear position to **P**.
- 3. Turn on the hazard warning lights and set the power mode to VEHICLE OFF.

#### ➢Temporarily Repairing a Flat Tire

The kit should not be used in the following situations. Instead, contact a dealer or roadside assistance to have the vehicle towed.


- The tire sealant has expired.
- More than one tire is punctured.
- The puncture or cut is larger than 3/16 inch (4.8 mm).
- The tire side wall is damaged or the puncture is outside the contact area.



When the puncture is:	Kit Use
Smaller than 3/16 inch (4.8 mm)	Yes
Larger than 3/16 inch (4.8 mm)	No

- Damage has been caused by driving with the tire extremely under inflated.
- The tire bead is no longer seated.
- The rim is damaged.

Do not remove a nail or screw that punctured the tire. If you remove it from the tire, you may not be able to repair the puncture using the kit.



#### Getting Ready to Temporarily Repair the Flat Tire

# Handle

**1.** Push the rear edge of the handle on the floor lid and open the lid.

#### Temporarily Repairing a Flat Tire


#### NOTICE

Do not use a puncture-repairing agent other than the one provided in the kit that came with your vehicle. If a different agent is used, you may permanently damage the tire pressure sensor.

#### Setting Ready to Temporarily Repair the Flat Tire


Repair notification label and speed restriction label are applied to the side of the temporary tire repair kit.

When making a temporary repair, carefully read the instruction manual provided with the kit.



- 2. Push the tabs to open the tool box lid.
- **3.** Take the kit out of the tool box.
- **4.** Place the kit face up, on flat ground near the flat tire, and away from traffic. Do not place the kit on its side.

#### Injecting Sealant and Air



un du

Sealant/Air Hose

**1.** Remove the valve cap from the tire valve stem.

**2.** Remove the sealant/air hose from the packaging.

#### ➢Injecting Sealant and Air

# 


Tire sealant contains substances that are harmful if inhaled, ingested or if contact is made with the eyes or skin.

Always use in a well-ventilated area and use gloves and safety glasses for protection; do not ingest.


For skin or eye contact, flush with cool water; if ingested, rinse mouth with water. In all cases, seek medical attention if necessary.

In cold temperatures, the sealant may not flow easily. In this situation, warm it up for five minutes before using.

The sealant can permanently stain clothing and other materials. Be careful during handling and wipe away any spills immediately.



**3.** Attach the sealant/air hose onto the tire valve stem. Screw it until it is tight.



- **4.** Plug in the compressor to the accessory power socket.
  - Be careful not to pinch the cord in a door or window.
  - Do not plug any other electric devices into other accessory power sockets.
  - Accessory Power Sockets P. 239
- 5. Start the engine.
  - Starting the Engine P. 443
  - Keep the engine running while injecting sealant and air.
    - Carbon Monoxide Gas P. 77
- 6. Turn the selector switch to REPAIR.

#### ➢Injecting Sealant and Air

# 

Running the engine with the vehicle in an enclosed or even partly enclosed area can cause a rapid buildup of toxic carbon monoxide.


Breathing this colorless, odorless gas can cause unconsciousness and even death.


Only run the engine to power the air compressor with the vehicle outdoors.


#### NOTICE

Do not operate the temporary tire repair kit compressor for more than 15 minutes. The compressor can overheat and become permanently damaged.

Until the sealant injection is complete, the pressure shown on the pressure gauge will appear higher than actual. After the sealant injection is complete the pressure will drop and then begin to rise again as the tire is inflated with air. This is normal. To accurately measure the air pressure using the gauge, turn the air compressor off only after the sealant injection is complete.







- **7.** Press the inflator switch to turn on the compressor.
  - The compressor starts injecting sealant and air into the tire.
  - ▶ When the sealant injection is complete continue to add air.

#### 8. Models with 235/55R19 101H tires

After the air pressure reaches 33 psi (230 kPa), turn off the kit.

#### Models with 255/45R20 101V tires


After the air pressure reaches 36 psi (250 kPa), turn off the kit.

- ► To check the pressure, occasionally turn off the compressor and read the gauge.
- **9.** Unplug the power plug from the accessory power socket.
- **10.** Unscrew the sealant/air hose from the tire valve stem. Reinstall the valve cap.

#### ➢Injecting Sealant and Air

If the required air pressure is not reached within 10 minutes, the tire may be too severely damaged for the kit to provide the necessary seal, and your vehicle will need to be towed.

See an Acura dealer for a replacement sealant bottle and proper disposal of an empty bottle.






**11.** Press the pressure relief button until the gauge returns 0 psi (0 kPa).

- **12.** Apply the repair notification label to the flat surface of the wheel.
  - ► The wheel surface must be clean to ensure the label adheres properly.

#### Distributing the Sealant in the Tire



©``


Sealant/Air Hose

ſ

- **1.** Apply the speed restriction label to the location as shown.
- 2. Drive the vehicle for about 10 minutes.▶ Do not exceed 50 mph (80 km/h).
- **3.** Stop the vehicle in a safe place.

**4.** Recheck the air pressure using the sealant/ air hose on the compressor.





- 5. Turn the selector switch to AIR.
  - Do not turn the air compressor on to check the pressure.

▶ Inflating an Under-inflated Tire P. 660

- 6. If the air pressure is
  - Less than 25 psi (175 kPa):

Do not add air or continue driving. The leak is too severe. Call for help and have your vehicle towed.


Emergency Towing P. 685

#### Models with 235/55R19 101H tires

• 33 psi (230 kPa) or more:

#### Models with 255/45R20 101V tires

- 36 psi (250 kPa) or more: Continue driving for another 10 minutes or until you reach the nearest service station, whichever is sooner. Do not exceed 50 mph (80 km/h). If you have not reached a service station, stop and check the tire pressure.
- If the air pressure does not go down after the 10 minute driving, you do not need to check the pressure any more.



#### Models with 235/55R19 101H tires

 Greater than 25 psi (175 kPa), but less than 33 psi (230 kPa): Turn the air compressor on to inflate the tire until the tire pressure reaches 33 psi (230 kPa).

#### Models with 255/45R20 101V tires

 Greater than 25 psi (175 kPa), but less than 36 psi (250 kPa): Turn the air compressor on to inflate the tire until the tire pressure reaches 36 psi (250 kPa).

#### Inflating an Under-inflated Tire P. 660

Then, drive carefully for 10 more minutes or until you reach the nearest service station, whichever is sooner. Do not exceed 50 mph (80 km/h). If you have not reached a service station, stop and check the tire pressure.

- You should repeat this procedure as long as the air pressure is within this range.
- **7.** Unplug the kit from the accessory power socket.
- **8.** Unscrew the sealant/air hose from the tire valve stem. Reinstall the valve cap.


Distributing the Sealant in the Tire

# 

Running the engine with the vehicle in an enclosed or even partly enclosed area can cause a rapid buildup of toxic carbon monoxide.

Breathing this colorless, odorless gas can cause unconsciousness and even death.


Only run the engine to power the air compressor with the vehicle outdoors.





9. Press the pressure relief button until the gauge returns 0 psi (0 kPa).10. Repackage and properly stow the kit.

#### Inflating an Under-inflated Tire

You can use the kit to inflate a non-punctured under-inflated tire.








- 1. Open the cargo area floor lid.
  - Getting Ready to Temporarily Repair the Flat Tire P. 650
- 2. Push the tabs to open the tool box lid.
- **3.** Remove the kit from the box.
- **4.** Place the kit, face up, on flat ground near the tire to be inflated, away from traffic. Do not place the kit on its side.
- 5. Remove the sealant/air hose from the kit.
- 6. Remove the valve cap.

**7.** Attach the sealant/air hose onto the tire valve stem. Screw it until it is tight.

#### ➢Inflating an Under-inflated Tire

#### NOTICE

Do not operate the temporary tire repair kit compressor for more than 15 minutes. The compressor can overheat and become permanently damaged.



- **8.** Plug in the kit to the accessory power socket.
  - Be careful not to pinch the cord in a door or window.
  - Do not plug any other electronic devices into other accessory power sockets.
    - Accessory Power Sockets P. 239
- 9. Start the engine.
  - Starting the Engine P. 443
  - Keep the engine running while injecting air.
    - Carbon Monoxide Gas P. 77
- 10. Turn the selector switch to AIR.
- **11.** Press the inflator switch to turn on the kit.
  - The compressor starts to inject air into the tire.
- **12.** Inflate the tire to the specified air pressure.


#### ▶ Inflating an Under-inflated Tire

# 


Running the engine with the vehicle in an enclosed or even partly enclosed area can cause a rapid buildup of toxic carbon monoxide.

Breathing this colorless, odorless gas can cause unconsciousness and even death.

Only run the engine to power the air compressor with the vehicle outdoors.



Handling the Unexpected






- 13. Turn off the kit.
  - Check the pressure gauge on the air compressor.
  - If overinflated, press the pressure relief button.
- **14.** Unplug the kit from the accessory power socket.
- **15.** Unscrew the sealant/air hose from the tire valve stem. Reinstall the valve cap.
- **16.** Press the pressure relief button until the gauge returns 0 psi (0 kPa).
- **17.** Repackage and properly stow the kit.

# Handling of the Jack

#### Models with temporary tire repair kit

Your vehicle has jacking points as shown. When replacing your tires, consult a dealer.



## **Checking the Engine**

If the engine does not start, check the starter.

Starter condition	Checklist	
Starter doesn't turn or turns	Check for a message on the multi-information display.	
over slowly.	<ul> <li>If the To Start, Hold Remote Near Start Button message appears</li> </ul>	
The battery may be dead. Check	If the Keyless Remote Battery is Weak P. 665	
each of the items on the right and	Make sure the keyless remote is in its operating range. E ENGINE START/STOP Button P. 193	
respond accordingly.	Check the fuses.	
	Check all fuses, or have your vehicle checked by a dealer. Dispecting and Changing Fuses P. 684	
The starter turns over normally	Review the engine start procedure.	
but the engine doesn't start.	Follow its instructions, and try to start the engine again. D Starting the Engine P. 443	
There may be a problem with a	Check the immobilizer system indicator.	
fuse. Check each of the items on	When the immobilizer system indicator is blinking, the engine cannot be started.	
the right and respond accordingly.	Immobilizer System P. 183	
	Immobilizer System Indicator P. 99	
	Check the fuel level.	
	There should be enough fuel in the tank. <b>D Fuel Gauge</b> P. 136	
	Check the fuses.	
	Check all fuses, or have the vehicle checked by a dealer.  ■ Inspecting and Changing Fuses P. 684	
	If the problem continues: Demogency Towing P. 685	


If you cannot start the engine after checking all the items in the list above, have your vehicle checked by a dealer.


If you must start the vehicle immediately, use an assisting vehicle or booster battery to jump start it.

If the Battery Is Dead P. 667

## If the Keyless Remote Battery is Weak

If the beeper sounds, the **To Start, Hold Remote Near Start Button** message appears on the multi-information display, the **ENGINE START/STOP** button flashes, and the engine won't start, start the engine as follows:





- Press the ENGINE START/STOP button.
   The beeper sounds and the ENGINE
  - **START/STOP** button flashes for about 30 seconds.
- 2. Touch the center of the ENGINE START/ STOP button with the A logo on the keyless remote while the ENGINE START/STOP button is flashing. The buttons on the keyless remote should be facing you.
  - The beeper sounds, and the ENGINE START/STOP button stays on for about 10 seconds.
- 3. Depress the brake pedal and press the ENGINE START/STOP button while the ENGINE START/STOP button is on.
  - ► The engine starts.
  - If you don't depress the pedal, the mode will change to ACCESSORY.

## **Emergency Engine Stop**

The **ENGINE START/STOP** button may be used to stop the engine due to an emergency situation even while driving. If you must stop the engine, do either of the following operations:

- Press and hold the ENGINE START/STOP button for about two seconds.
- Firmly press the **ENGINE START/STOP** button three times.

The steering wheel will not lock. However, because turning off the engine disables the power assist the engine provides to the steering and braking systems, it will require significantly more physical effort and time to steer and slow the vehicle. Use both feet on the brake pedal to slow down the vehicle and stop immediately in a safe place.

The gear position automatically changes to **P** after the vehicle comes to a complete stop. Then, the power mode changes to VEHICLE OFF.

#### Emergency Engine Stop


#### NOTICE

Do not press the **ENGINE START/STOP** button while driving unless it is absolutely necessary for the engine to be turned off.

If you press the **ENGINE START/STOP** button while driving, the beeper sounds.

# **Jump Starting Procedure**

Turn off the power to electric devices, such as audio and lights. Turn off the engine, then open the hood.



**1.** Open the fuse box cover on your vehicle's 12-volt battery positive ⊕ terminal.

- 2. Connect the first jumper cable to your vehicle's battery ⊕ terminal.
- **3.** Connect the other end of the first jumper cable to the booster battery ⊕ terminal.
  - ► Use a 12-volt booster battery only.
  - When using an automotive battery charger to boost your 12-volt battery, select a lower charging voltage than 15volt. Check the charger manual for the proper setting.
- **4.** Connect the second jumper cable to the booster battery ⊖ terminal.

#### ➢If the Battery Is Dead


# 

A battery can explode if you do not follow the correct procedure, seriously injuring anyone nearby.

Keep all sparks, open flames, and smoking materials away from the battery.

Securely attach the jumper cables clips so that they do not come off when the engine vibrates. Be careful not to tangle the jumper cables or allow the cable ends to touch each other while attaching or detaching the jumper cables.

Battery performance degrades in cold conditions and may prevent the engine from starting.



- **5.** Connect the other end of the second jumper cable to the engine mounting bolt as shown. Do not connect this jumper cable to any other part.
- **6.** If your vehicle is connected to another vehicle, start the assisting vehicle's engine and increase its rpm slightly.
- **7.** Attempt to start your vehicle's engine. If it turns over slowly, check that the jumper cables have good metal-to-metal contact.

### What to Do After the Engine Starts

Once your vehicle's engine has started, remove the jumper cables in the following order.

- **1.** Disconnect the jumper cable from your vehicle's ground.
- **2.** Disconnect the other end of the jumper cable from the booster battery  $\bigcirc$  terminal.
- **3.** Disconnect the jumper cable from your vehicle's battery  $\oplus$  terminal.
- **4.** Disconnect the other end of the jumper cable from the booster battery  $\oplus$  terminal.

Have your vehicle inspected by a nearby service station or a dealer.

# How to Handle Overheating

Overheating symptoms are as follows:

- The temperature gauge is at the  $\mathbb{H}$  mark or the engine suddenly loses power.
- Engine Temperature Too Hot. Do Not Drive. Allow Engine To Cool. message appears on the multi-information display.
- Steam or spray comes out of the engine compartment.

#### First thing to do

- **1.** Immediately park the vehicle in a safe place.
- 2. Turn off all accessories and turn on the hazard warning lights.
  - **No steam or spray present:** Keep the engine running and open the hood.
  - Steam or spray is present: Turn off the engine and wait until it subsides. Then, open the hood.

➢How to Handle Overheating

# 

Steam and spray from an overheated engine can seriously scald you.

Do not open the hood if steam is coming out.

#### NOTICE

Continuing to drive with the temperature gauge at the [H] mark may damage the engine.

#### Next thing to do



- **1.** Check that the cooling fan is operating and stop the engine once the temperature gauge goes down.
  - If the cooling fan is not operating, immediately stop the engine.
- **2.** Once the engine has cooled down, inspect the coolant level and check the cooling system components for leaks.
  - If the coolant level in the reserve tank is low, add coolant until it reaches the MAX mark.
  - If there is no coolant in the reserve tank, check that the radiator is cool. Cover the radiator cap with a heavy cloth and open the cap. If necessary, add coolant up to the base of the filler neck, and put the cap back on.

#### ➢How to Handle Overheating

# 

Removing the radiator cap while the engine is hot can cause the coolant to spray out, seriously scalding you.

Always let the engine and radiator cool down before removing the radiator cap.

If the coolant is leaking, contact a dealer for repairs.

Use water as an emergency/temporary measure only. Have a dealer flush the system with proper antifreeze as soon as possible.

Continuing to drive with the **Engine Temperature Too Hot. Do Not Drive. Allow Engine To Cool.** message on the multi-information display may damage the engine.

#### Last thing to do

Once the engine has cooled sufficiently, restart it and check the temperature gauge. If the temperature gauge has gone down, resume driving. If it has not gone down, contact a dealer for repairs.

# If the Engine Oil Pressure Low Warning Appears



Reasons for the warning to appear
 Appears when the engine oil pressure is low.
 What to do as soon as the warning

- What to do as soon as the warning appears
- **1.** Immediately park the vehicle on level ground in a safe place.
- **2.** If necessary, turn the hazard warning lights on.

#### What to do after parking the vehicle

- **1.** Stop the engine and let it sit for approximately three minutes.
- 2. Open the hood and check the oil level.
  - Add oil as necessary.
    - Oil Check P. 596
- **3.** Start the engine and check the **Engine Oil Pressure Low** warning.
  - ► The warning disappears: Start driving again.
  - The warning does not disappear within 10 seconds: Immediately stop the engine and contact a dealer for repairs.

■If the Engine Oil Pressure Low Warning Appears

#### NOTICE

Running the engine with low oil pressure can cause serious mechanical damage almost immediately.

# If the Charging System Indicator Comes On



#### Reasons for the indicator to come on

Comes on when there is a problem with the charging system.

What to do when the indicator comes on

Stop in a safe place and have your vehicle checked by a dealer immediately.

# If the Malfunction Indicator Lamp Comes On or Blinks



#### Reasons for the indicator lamp to come on or blink

- Comes on when there is a problem with the engine emissions control system.
- Blinks when engine misfiring is detected.

#### What to do when the indicator lamp comes on

Avoid high speeds and immediately get your vehicle inspected at a dealer.

#### What to do when the indicator lamp blinks

Park the vehicle in a safe place with no flammable items and wait at least 10 minutes or more with the engine stopped until it cools.

#### ➢If the Charging System Indicator Comes On

If you need to stop temporarily, do not turn off the engine. Restarting the engine may rapidly discharge the battery.

▶ If the Malfunction Indicator Lamp Comes On or Blinks

#### NOTICE

If you drive with the malfunction indicator lamp on, the emissions control system and the engine could be damaged.

If the malfunction indicator lamp blinks again when restarting the engine, drive to the nearest dealer at 31 mph (50 km/h) or less. Have your vehicle inspected.

# If the Brake System Indicator (Red) Comes On or Blinks



- Reasons for the indicator to come on
- The brake fluid is low.
- There is a malfunction in the brake system.



#### ■ What to do when the indicator comes on while driving Depress the brake pedal lightly to check pedal pressure.

- If normal, check the brake fluid level the next time you stop.
- If abnormal, take immediate action. If necessary, downshift the transmission to slow the vehicle using engine braking.

#### Reasons for the indicator to blink

- There is a problem with the electric parking brake system.
- What to do when the indicator blinks
- Avoid using the parking brake and have your vehicle checked by a dealer immediately.

If the Brake System Indicator (Red) Comes On or Blinks

Have your vehicle repaired immediately. It is dangerous to drive with low brake fluid. If there is no resistance from the brake pedal, stop immediately in a safe place. If necessary downshift the gears.

If the brake system indicator (red) and **ABS** indicator come on simultaneously, the electronic brake distribution system is not working. This can result in vehicle instability under sudden braking. Have your vehicle inspected by a dealer immediately.

If the Brake System Indicator (Red) blinks at the same time when the Brake System Indicator (Amber) comes on, the parking brake may not work.

Avoid using the parking brake and have your vehicle checked by a dealer immediately.

If the Brake System Indicator (Red) Comes On or Blinks at the Same Time When the Brake System Indicator (Amber) Comes On P. 675

# If the Electric Power Steering (EPS) System Indicator Comes On



#### Reasons for the indicator to come on

Comes on when there is a problem with the EPS system.

#### ■ What to do when the indicator comes on

- Stop the vehicle in a safe place and restart the engine. If the indicator comes on and stays on, immediately have your vehicle inspected by a dealer.
- If **Do Not Drive** displays on the multi-information display, immediately stop in a safe place and contact a dealer.

# If the Brake System Indicator (Red) Comes On or Blinks at the Same Time When the Brake System Indicator (Amber) Comes On



- If the brake system indicator (red) comes on or blinks at the same time when the brake system indicator (amber) comes on, release the parking brake manually or automatically
   ▶ Parking Brake P. 545
- If the brake system indicator (red) continuously comes on or blinks at the same time when the brake system indicator (amber) comes on, stop the vehicle in a safe place and have it inspected by a dealer immediately.
  - $\blacktriangleright$  To prevent the vehicle from moving, put the transmission into  $\mathbf{P}$ .
- If only the brake system indicator (red) is turned off, avoid using the parking brake and have your vehicle checked by a dealer immediately.

If the Brake System Indicator (Red) Comes On or Blinks at the Same Time When the Brake System Indicator (Amber) Comes On

If you apply the parking brake, you may not be able to release it.

If the brake system indicator (red) and the brake system indicator (amber) come on at the same time, the parking brake is working.

If the brake system indicator (red) blinks at the same time when the brake system indicator (amber) comes on, the parking brake may not work because it is checking the system.

If you repeatedly operate the electric parking brake in a short period of time, the brake stops operating to prevent heating of the system and the indicator blinks.

It returns to its original state in approximately 1 minute.



# If the Low Tire Pressure/TPMS Indicator Comes On or Blinks



#### Reasons for the indicator to come on or blink

A tire pressure is significantly low.

If there is a problem with the TPMS, the indicator blinks for about one minute, and then stays on.

If the compact spare tire<sup>\*</sup> is installed, the indicator will either come on or it will first blink for about one minute, then stay on.

#### What to do when the indicator comes on

Drive carefully and avoid abrupt cornering and hard braking.

Stop your vehicle in a safe place. Check the tire pressure and adjust the pressure to the specified level. The specified tire pressure is on a label on the driver side doorjamb.

If the compact spare tire<sup>\*</sup> causes the indicator to come on, change the tire to a full-size tire.

#### What to do when the indicator blinks

Have the tire inspected by a dealer as soon as possible. If the compact spare tire<sup>\*</sup> causes the indicator to first blink, and then stay on, change the tire to a full-size tire. The indicator goes off after driving for a few miles (kilometers).

▶ If the Low Tire Pressure/TPMS Indicator Comes On or Blinks

#### NOTICE

Driving on an extremely underinflated tire can cause it to overheat. An overheated tire can fail. Always inflate your tires to the prescribed level.

TPMS with Tire Fill Assist provides visual and audible assistance during tire pressure adjustment. With the power mode in ON and transmission in  $[\mathbf{P}]$ , while you adjust tire pressure up or down, the system alerts you as follows:

**Below recommended pressure:** The beeper sounds and exterior lights flash once every five seconds.

**At recommended pressure:** The beeper sounds and exterior lights flash rapidly for three seconds with five seconds intervals.

**Above recommended pressure:** The beeper sounds and lights flash twice every two seconds.

When a certain amount of time has passed since activation, Tire Fill Assist will be canceled until you set the power mode to OFF.

You cannot use Tire Fill Assist if the engine was started by the remote engine start, or if there is a malfunction in the system.

If Tire Fill Assist does not work, use a tire pressure gauge.

# If the Transmission System Indicator Blinks along with the Warning Message





#### Reasons for the indicator to blink

The transmission is malfunctioning.

#### What to do when the indicator blinks

- Immediately have your vehicle inspected by a dealer.
- Change the gear position to **N** after starting the engine.
  - Check if the N position in the instrument panel and the indicator on the N button light/blink.
  - ► The engine cannot be turned on unless the parking brake is set.

Starting the Engine P. 443

If the Transmission System Indicator Blinks along with the Warning Message

You may not be able to start the engine.

Make sure to set the parking brake when parking your vehicle.

Call a professional towing service if you need to tow your vehicle.

Emergency Towing P. 685


## **Fuse Locations**

If any electrical devices are not working, set the power mode to VEHICLE OFF and check to see if any applicable fuse is blown.

Fuse locations are shown on the fuse box cover. Locate the fuse in question by the fuse number and box cover number.

#### Engine Compartment Fuse Box Type A

Located near the battery. Push the tabs to open the box.




Circuit protected and fuse rating		
	Circuit Protected	Amps
1	-	-
2	-	-
3	IG1 VBSOL2	10 A
4	IG1 RR WIPER	10 A
5	IG1 VSA	10 A
6	HTR MTR	40 A
7	DBW	15 A
8	TCU	15 A
9	FI MAIN	15 A
10	STARTER CUT	30 A
11	INJ	20 A
12	HAZARD	15 A
13	TCU 2	10 A
14	TCU 3	10 A
15	FET MODULE	20 A
16	SUB FAN	30 A
17	HORN	15 A
18	BACK UP	10 A
19	STOP	7.5 A
20	FET MODULE	20 A

	Circuit Protected	Amps
21	VBU	10 A
22	FRT DEICER*	15 A
23	IG COIL	15 A
24	WASHER	15 A
25	MAIN FAN	30 A
26	STRLD	7.5 A
27	IGPS	10 A
28	_	_
29	R H/L LO	10 A
30	L H/L LO	10 A
31	VBACT	10 A
32	IGPS (LAF)	10 A
33	-	_

#### Engine Compartment Fuse Box Type B

Fuse locations are shown on the fuse box cover. Locate the fuse in question by the fuse number and box cover number. Located near the battery. Push the tabs to open the box.



Circuit protected and fuse rating		
	Circuit Protected	Amps
	-	(50 A)
	ABS/VSA MTR	40 A
	F/B MAIN 2	50 A
1 —	F/B MAIN	60 A
	ABS VSA FSR	40 A
	WIPER	30 A
	IDLE STOP	30 A
	IDLE STOP	30 A
2	-	-
3	-	-
4	4WD*	(30 A)
5	IG MAIN 2	20 A
6	IG MAIN	30 A
7	-	-
8	DR P/SEAT 3	30 A
9	EBB	40 A
10	TRL SMALL*	(7.5 A)


	Circuit Protected	Amps
11	PTG CLOSER MTR	20 A
12	<b>RR ACC SOCKET</b>	(20 A)
13	DR P/SEAT 1	30 A
14	AS P/SEAT 2	30 A
15	AS P/SEAT 1	30 A
16	RR DEF	40 A
17	AMP	30 A <sup>*1</sup> 40 A <sup>*2</sup>
18	SUNSHADE	20 A
19	DR P/SEAT 2	30 A
20	AS P/SEAT 3	30 A
21	SBW	10 A
22	TRL HAZARD*	(7.5 A)
23	BMS	10 A
24	PTG MTR	40 A

\*1:Models without seat ventilator

\*2:Models with seat ventilator

#### Engine Compartment Fuse Box Type C

Located near the  $\oplus$  terminal on the battery.



Remove the cover on the  $\oplus$  terminal (as shown).


Replacement of this fuse should be done by a dealer.

#### ■ Circuit protected and fuse rating

	•	5
	Circuit Protected	Amps
а	MAIN	150 A
b	-	70 A
С	R/B 1	70 A
d	R/B 2	70 A
е	EPS	70 A
f	FET	60 A

#### Interior Fuse Box Type A

Located under the dashboard.



Fuse locations are shown on the label on

the side panel.


Locate the fuse in question by the fuse number and label number.

Circuit protected and fuse rating		
	Circuit Protected	Amps
1	BACK-UP LIGHT	10 A
2	STARTER MOTOR	10 A
3	OPTION	10 A
4	_	-
5	-	-
6	-	(10 A)
7	-	-
8	-	-
9	IG1 R/B	15 A
10	DR REAR DOOR LOCK	10 A
11	DR DOOR LOCK	10 A
12	AS SIDE DOOR LOCK	10 A
13	AS SIDE DOOR UNLOCK	10 A
14	DR DOOR UNLOCK	10 A
15	OPTION 2	10 A
16	SMART	10 A
17	SUNROOF	20 A
18	HEATED STRG WHEEL*	(10 A)
19	REAR LEFT P/W	20 A
20	SRS	10 A

	Circuit Protected	Amps
21	FUEL PUMP	20 A
22	FRONT ACC SOCKET	20 A
23	LEFT H/L HI	10 A
24	RIGHT H/L HI	10 A
24	DRIVER P/W	20 A
26	DR REAR DOOR UNLOCK	10 A
27	ACCESSORY	10 A
28	PASS SRS IND	10 A
29	PDM	10 A
30	ADS*	(15 A)
31	REAR RIGHT P/W	20 A
32	-	-
33	TRANSMISSION	10 A
34	ACG	10 A
35	DRL	10 A
36	A/C	10 A
37	AUDIO	15 A
38	DOOR LOCK	20 A
39	AS P/W	20 A
А	REAR SEAT HEATER*	20 A
В	-	-

#### Interior Fuse Box Type B

Located under the dashboard.



Fuse locations are shown on the label on the side panel.

Locate the fuse in question by the fuse number and label number.

#### ■ Circuit protected and fuse rating

	•	•
	Circuit Protected	Amps
А	METER	10 A
В	VSA	10 A
С	OPTION	10 A
D	BCM	10 A
E	AUDIO	20 A
F	BACKUP	10 A
G	ACCESSORY	(10 A)

## Interior Fuse Box Type C

Located inside the driver's side outer panel.





Replacement of this fuse should be done by a dealer.

## Circuit protected and fuse rating

	Circuit Protected	Amps
1	-	-
2	-	-
3	A/C MG CL	10 A
4	_	-
5	FR H/SEAT	20 A

# **Inspecting and Changing Fuses**





- **1.** Set the power mode to VEHICLE OFF. Turn headlights and all accessories off.
- 2. Remove the fuse box cover.
- **3.** Check the large fuse in the engine compartment.
  - If the fuse is blown, use a Phillips-head screwdriver to remove the screw and replace it with a new one.
- **4.** Inspect the small fuses in the engine compartment and the vehicle interior.
  - If there is a blown fuse, remove it with the fuse puller and replace it with a new one.

➢Inspecting and Changing Fuses

#### NOTICE

Replacing a fuse with one that has a higher rating greatly increases the chances of damaging the electrical system.

Use the charts to locate the fuse in question and confirm the specified amperage on the fuse label.

#### Fuse Locations P. 678

Replace a fuse with a spare fuse of the same specified amperage.

There is a fuse puller on the back of the cover of the engine compartment fuse box type A.

Call a professional towing service if you need to tow your vehicle.

#### All models

#### Flatbed equipment

The operator loads your vehicle on the back of a truck. **This is the best way to transport your vehicle.** 

#### 2WD models

## Wheel lift equipment

The tow truck uses two pivoting arms that go under the front tires and lift them off the ground. The rear tires remain on the ground. **This is an acceptable way to tow your vehicle.** 

#### Emergency Towing

## NOTICE

Trying to lift or tow your vehicle by the bumpers will cause serious damage. The bumpers are not designed to support the vehicle's weight.

#### 2WD models

Make sure the parking brake is released. If you cannot release the parking brake, your vehicle must be transported by the flatbed equipment.

Parking Brake P. 545

## NOTICE

Improper towing such as towing behind a motorhome or other motor vehicle can damage the transmission.

Never tow your vehicle with just a rope or chain. It is very dangerous, since ropes or chains may shift from side to side or break.

## What to Do If Unable to Unlock the Fuel Fill Door

If you cannot unlock the fuel fill door, use the following procedure.


- 1. Open the tailgate.
- **2.** Push the tabs to open the cover on the left side of cargo area.

- 3. Pull the release cord toward you.
  - The release cord unlocks the fuel fill door when it is pulled.

What to Do If Unable to Unlock the Fuel Fill Door

After taking these steps, contact a dealer to have the vehicle checked.


Handling the Unexpected





## What to Do If Unable to Open the Tailgate

If you cannot open the tailgate, use the following procedure.



- **1.** Use a flat-tip screwdriver and remove the cover on the back of the tailgate.
  - Wrap the flat-tip screwdriver with a cloth to prevent scratches.


**2.** To open the tailgate, push the tailgate while sliding the lever to the right.

#### What to Do If Unable to Open the Tailgate

#### Following up:


After taking these steps, contact a dealer to have the vehicle checked.


When you open the tailgate from inside, make sure there is enough space around the tailgate, and it does not hit anyone or any object.



# **Refueling From a Portable Fuel Container**

If you have run out of fuel and need to refuel your vehicle from a portable fuel container, use the funnel provided with your vehicle.





- **1.** Turn off the engine.
- 2. Open the fuel fill door.
  - How to Refuel P. 576
- **3.** Take the funnel out of tool box in the cargo area.
  - Types of Tools P. 640
- **4.** Place the end of the funnel on the lower part of filler opening, then insert it slowly and fully.
  - Make sure that the end of the funnel goes down along with the filler pipe.
- **5.** Fill the tank with fuel from the portable fuel container.
  - Pour fuel carefully so you do not spill any.
- **6.** Remove the funnel from the filler neck.
  - Wipe up any fuel from the funnel before storing it.
- 7. Shut the fuel fill door by hand.

Refueling From a Portable Fuel Container

# 

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flames away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

#### NOTICE

Do not insert the nozzle of a portable fuel container or any funnel other than the one provided with your vehicle. Doing so can damage the fuel system. Do not try to pry open or push open the sealed fuel tank with foreign objects. This can damage the fuel system and its seal.

Make sure the fuel in the portable fuel container is gasoline before you refuel.

# Information

This chapter includes your vehicle's specifications, locations of identification numbers, and other information required by regulation.

Specifications	690	
Identification Numbers		
Vehicle Identification Number (VIN),		
Engine Number, and Transmission		
Number	. 692	
Devices that Emit Radio Waves 693		
Reporting Safety Defects	. 694	

#### **Emissions Testing**

Testing of Readiness Codes	695
Warranty Coverages	697
Authorized Manuals	700
Client Service Information	701

#### Vehicle Specifications

Model	RDX		
No. of Passengers:			
Front	2		
Rear	3		
Total	5		
Weights:			
Gross Vehicle Weight Rating	See the certification label on the driver's doorjamb		
Gross Axle Weight Rating (Front)	See the certification label on the driver's doorjamb		
Gross Axle Weight Rating (Rear)	See the certification label on the driver's doorjamb		
Gross Combined Weight Rating	U.S.: 5,975 lbs (2,710 kg) Canada: 2,710 kg		

#### Air Conditioning

Refrigerant Type	HFO-1234yf (R-1234yf)
Charge Quantity	17.8 – 19.6 oz (505 – 555 g)
Lubricant Type	ND-OIL14 (POE)
Quantity	4.27 - 5.19 cu-in (70 - 85 cm <sup>3</sup> )

#### Engine Specifications

<b>J</b>		-	
Displacement	121.76 cu-in (1,996 cm <sup>3</sup> )		
Spark Plugs	NGK	DILKAR8P8SY	
Fuel			
Туре	Unleaded premium gasoline, pump octane number 91 or higher		
Fuel Tank Capacity	17.1 US gal (64.7 L)		

#### Washer Fluid

Tank Capacity	U.S.: 2.6 US qt (2.5 L)		
Talik Capacity	Canada: 5.8 US qt (5.5 L)		

#### Light Bulbs

Headlights (Low Beam)	LED
Headlights (High Beam)	LED
Fog Lights*	LED
Parking/Chicane <sup>™</sup> Daytime Running Lights	LED
Front Turn Signal Lights	LED
Side Turn Signal Lights (on Door Mirrors)	LED
Front Side Marker Lights	LED
Brake Lights	LED
Rear Side Marker Lights	LED
Brake/Chicane™ Taillights	LED
Chicane <sup>™</sup> Taillights	LED
Back-Up Lights	LED
Rear Turn Signal Lights	21 W (Amber/Silver)
High-Mount Brake Light	LED
Rear License Plate Light	LED
Puddle Lights*	LED
Interior Lights	
Front and Rear Map Lights	LED
Front and Rear Ambient Lights	LED
Vanity Mirror Lights	1.4 W
Door Pocket Lights*	LED
Center Pocket Light	LED
Door Courtesy Lights	3.4 W
Glove Box Light	1.4 W
Cargo Area Light	LED
Door Inner Handle Lights	LED
Foot Lights	LED

Specified

Acura Heavy Duty Brake Fluid DOT 3

#### Automatic Transmission Fluid

Specified	Acura ATF-type 2.0	
Capacity	Change	4.5 US qt (4.3 L)*1 5.1 US qt (4.8 L)*2
*1: 2WD m	nodels	

\*2: AWD models

#### Rear Differential Fluid\*

Specified	Acura DPS	F-11
Capacity	Change	1.76 US qt (1.67 L)

#### Transfer Assembly Fluid\*

Specified	Acura HGO-	1
Capacity	Change	0.61 US qt (0.58 L)

Acura Genuine Motor Oil 0W-20           -API service SN or higher grade 0W-20           Change         4.6 US qt (4.4 L)           Change         including           5.0 US qt (4.8 L)           filter	Engine Oil		
Capacity Change including 5.0 US qt (4.8 L)	Recommended		
including 5.0 US qt (4.8 L)		Change	4.6 US qt (4.4 L)
inter	Capacity	5	5.0 US qt (4.8 L)

#### Engine Coolant

- --

Specified	Acura Long Life Antifreeze/Coolant Type 2
Ratio	50/50 with distilled water
Capacity	1.43 US gal (5.40 L) (change including the remaining 0.23 US gal (0.86 L) in the reserve tank)

#### Tire

Regular	Size	235/55R19 101H*1
		255/45R20 101V*2
Negulai	Pressure	33 (230 [2.3])*1
	psi (kPa [kgf/cm <sup>2</sup> ])	36 (250 [2.5])* <sup>2</sup>
Compact Spare*	Size	T155/90D17 101M
	Pressure psi (kPa [kgf/cm²])	60 (420 [4.2])
Wheel Size	Regular	19 x 8J*1
		20 x 8J*2
	Compact Spare*	17 x 4T
*1. Madala	1401 1	


\*1: Models with 19 inch wheel

\*2: Models with 20 inch wheel

# **Identification Numbers**

# Vehicle Identification Number (VIN), Engine Number, and Transmission Number

Your vehicle has a 17-digit vehicle identification number (VIN) used to register your vehicle for warranty purposes, and for licensing and insuring your vehicle. The locations of your vehicle's VIN, engine number, and transmission number are shown as follows.



Vehicle Identification Number (VIN), Engine Number, and Transmission Number

The interior vehicle identification number (VIN) is located under the cover.



Each radio frequency device installed in the vehicle conforms to the requirements and standards of the regulation listed below:

As required by the FCC:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

In the U.S.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying American Honda Motor Co., Inc.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or American Honda Motor Co., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to *http://www.safercar.gov*; or write to: Administrator, NHTSA, 1200 New Jersey Avenue, SE., Washington, DC 20590. You can also obtain other information about motor vehicle safety from *http:// www.safercar.gov*.

## In Canada

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform Honda Canada Inc. and you may also inform Transport Canada.

If Transport Canada receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may lead to a recall and remedy campaign. However, Transport Canada cannot become involved in individual problems between you, your dealer, or Honda Canada Inc.

To contact Transport Canada's Defect Investigations and Recalls Division, you may call 1-800-333-0510. For more information on reporting safety defects or about motor vehicle safety, go to *http://www.tc.gc.ca/ roadsafety*.

# **Testing of Readiness Codes**

Your vehicle has readiness code as part of the onboard self diagnostic system. Some states use these codes for testing to verify whether your vehicle's emissions components are working properly.

The codes may not be read properly if testing is performed just after the battery has gone dead or been disconnected.

To check if they are set, set the power mode to ON, without starting the engine. The malfunction indicator lamp will come on for several seconds. If it then goes off, the readiness codes are set. If it blinks five times, the readiness codes are not set.

If you are required to have your vehicle tested before the readiness codes are ready, prepare the vehicle for retesting by doing the following:

- **1.** Fill the gas tank to approximately 3/4 full.
- 2. Park the vehicle and leave the engine off for 6 hours or more.
- 3. Make sure the ambient temperature is between 40°F and 95°F (4°C and 35°C).
- **4.** Start the engine without touching the accelerator pedal, and let it idle for 20 seconds.
- **5.** Keep the vehicle in **P**. Increase the engine speed to 2,000 rpm, and hold it there for about 3 minutes.
- **6.** Let the engine idle with your foot off the accelerator for 20 seconds.

#### ➢Testing of Readiness Codes

The readiness codes are erased when the battery is disconnected, and set again only after several days of driving under a variety of conditions.

If a testing facility determines that the readiness codes are not set, you may be requested to return at a later date to complete the test.

If the testing facility determines the readiness codes are still not set, see a dealer.

- 7. Select a nearby, lightly traveled major highway where you can maintain a speed of 50 to 60 mph (80 to 97 km/h) for at least 20 minutes. Drive on the highway in D. Do not use cruise control. When traffic allows, drive for 90 seconds without moving the accelerator pedal. (Vehicle speed may vary slightly; this is okay.) If you cannot do this for a continuous 90 seconds because of traffic conditions, drive for at least 30 seconds, then repeat it two more times (for a total of 90 seconds).
- **8.** Drive in city or suburban traffic for at least 10 minutes. When traffic conditions allow, let the vehicle coast for several seconds without using the accelerator pedal or the brake pedal.
- 9. Park the vehicle and leave the engine off for 30 minutes.

#### U.S. Owners

Your new vehicle is covered by these warranties:

*New Vehicle Limited Warranty* – covers your new vehicle, except for the emissions control systems and accessories, against defects in materials and workmanship.

#### Emissions Control Systems Defects Warranty and Emissions Performance

**Warranty** – these two warranties cover your vehicle's emissions control systems. Time, mileage, and coverage are conditional. Please read your warranty booklet for exact information.

**Seat Belt Limited Warranty** – a seat belt that fails to function properly is covered by a limited warranty. Please read your warranty booklet for details.

**Rust Perforation Limited Warranty** – all exterior body panels are covered against rusting from the inside out for the specified time period, regardless of mileage.

**Accessory Limited Warranty** – Acura accessories are covered under this warranty. Time and mileage limits depend on the type of accessory and other factors. Please read your warranty booklet for details.

**Replacement Parts Limited Warranty** – covers all Acura replacement parts against defects in materials and workmanship.

**Replacement Battery Limited Warranty** – provides prorated coverage for a replacement battery purchased from your dealer.

**Replacement Muffler Lifetime Limited Warranty** – provides coverage for as long as the purchaser of the muffler owns the vehicle.

Restrictions and exclusions apply to all these warranties. Please read the Acura warranty information booklet that came with your vehicle for precise information on warranty coverages. Your vehicle's original tires are covered by their manufacturer. Tire warranty information is in a separate booklet.

#### Statement on Warranty Coverage for Aftermarket and Recycled Parts

The Magnuson-Moss Warranty Act, 15 U.S.C. s.2301 et seq., makes it illegal for motor vehicle manufacturers to void a motor vehicle warranty or deny warranty coverage solely because an aftermarket or recycled part has been used to repair the vehicle or someone other than the authorized service provider performed service on the vehicle.

This provision does not apply to a new motor vehicle purchased solely for commercial or industrial use.

Under federal law, a manufacturer may deny warranty coverage and charge for repairs to a vehicle if it is discovered that an aftermarket or recycled part installed on the vehicle is defective or was installed incorrectly and caused damage to another part of the vehicle otherwise covered under warranty. The Federal Trade Commission requires that a manufacturer demonstrate that an

aftermarket or recycled part or service performed by a person other than an authorized service provider caused damage to another part of the vehicle otherwise covered under warranty before denying warranty coverage.

Additionally, federal law allows a manufacturer to void a motor vehicle warranty or deny warranty coverage if the manufacturer provides the article or service to consumers free of charge under the warranty or the manufacturer has secured a waiver from the Federal Trade Commission.

#### Canadian Owners

Please refer to the warranty manual that came with your vehicle.

#### EPA Contact Information

An owner may obtain further information concerning emission warranties or report violations of the terms of the emission warranties by contacting:

Director, Light-Duty Vehicle Center, U.S. Environmental Protection Agency, Attention: Warranty Claim 2000 Traverwood Drive, Ann Arbor, MI 48105; complianceinfo@epa.gov

#### Service Express

For electronic copies of service publications, you can purchase a subscription to Service Express. Visit *www.techinfo.acura.com* for pricing and options.

#### For U.S. Owners

Manuals can be purchased from Helm Incorporated. You can order a manual by phone at 1 (800) 782-4356 (credit card orders only), or online at *www.helminc.com*.

#### For Canadian Owners

Please contact a dealer to order any manuals that you may require.

Acura dealership personnel are trained professionals able to deal with any problems you may encounter with your vehicle. If, however, you are faced with a problem that they cannot resolve to your satisfaction, contact Acura Client Relations/Services.

#### **U.S.** Owners

American Honda Motor Co., Inc. Acura Client Relations Mail Stop CHI-4 1919 Torrance Blvd. Torrance, CA 90501-2746 Tel: 1 (800) 382-2238

#### In Puerto Rico and the U.S. Virgin Islands

Bella International P.O. Box 190816 San Juan, PR 00919-0816 Tel: 1 (787) 620-7546

#### **Canadian Owners**

Honda Canada Inc. Acura Client Services 180 Honda Boulevard Markham, ON L6C 0H9 Tel: 1-888-9-ACURA-9 Fax: 1-877-939-0909 E-mail: acura\_cr@ch.honda.com

in In Guam: Triple J Autogroup 157 S. Marine Corps Drive Tamuning, GU 96913 (671) 648-2277

#### ➢Client Service Information

When you call or write, please give us the following information:

- Vehicle Identification Number
  - Vehicle Identification Number (VIN), Engine Number, and Transmission Number P. 692
- Date of purchase
- Odometer reading of your vehicle
- Your name, address, and telephone number
- A detailed description of the problem
- Name of the dealer who sold the vehicle to you

# Index

# Α

ABS (Anti-lock Brake System)	553
Accessories and Modifications	636
Accessory Power Socket	239
Acura Integrated Dynamics System	459
Dynamic Mode Switch	460
AcuraLink <sup>®</sup>	419
AcuraWatch <sup>™</sup>	483
Adaptive Cruise Control (ACC) with	
Low Speed Follow 102,	502
Additives	
Coolant	600
Engine Oil	595
Washer	604
Additives, Engine Oil	595
Adjusting	
Armrest	229
Front Seats	216
Head Restraints	225
Mirrors	213
Rear Seats	222
Steering Wheel	212
Agile Handling Assist	473
Air Conditioning System (Climate Contro	ol –
System)	247
Changing the Mode	247
Defrosting the Windshield and	
Windows	249
Dust and Pollen Filter	628
Rear Temperature Control Dial	251
Recirculation/Fresh Air Mode	247

Sensors	252
Synchronized Mode	250
Using Automatic Climate Control	247
Air Pressure	615, 691
Airbags	46
Advanced Airbags	52
After a Collision	49
Airbag Care	
Front Airbags (SRS)	49
Indicator	60, 95
Knee Airbags	54
Passenger Airbag Off Indicator	61
Sensors	46
Side Airbags	57
Side Curtain Airbags	59
AM/FM Radio	293
Amazon Alexa	
Android Auto <sup>™</sup>	327
Anti-lock Brake System (ABS)	553
Indicator	
Apple CarPlay	322
Armrest	229
AT&T Hotspot	321
Audio Remote Controls	258
Audio System	254
Adjusting the Sound	287
Audio/Information Screen	
Display Setup	288
Error Messages	332
General Information	336
Home Screen	269

How to Update Wirelessly	281
How to Update with a USB Device	285
iPod	310
Limitations for Manual Operation	288
MP3/WMA/AAC	313
Reactivating	257
Remote Controls	258
Security Code	257
Status Area	274
System Updates	281
Theft Protection	257
True Touchpad Interface	261
USB Flash Drives 313	, 338
USB Ports	255
Audio/Information Screen	264
Authorized Manuals	700
Auto Door Locking/Unlocking	172
Auto High-Beam	201
Indicator	98
Auto Idle Stop	464
OFF Button	466
Automatic Brake Hold	550
Indicator 85	, 550
Automatic Folding Door Mirror	215
Automatic Intermittent Wipers	205
Automatic Lighting	198
Automatic Transmission	450
Creeping	450
Fluid	602
Kickdown	450
Operating the Shift Button	453

Sequential Shift Mode	457
Shifting	451
Average Fuel Economy	141
AWD	474

# В

Battery	623
Charging System Indicator 87,	672
If the Battery Is Dead	667
Maintenance (Checking the Battery)	623
Belts (Seat)	. 37
Beverage Holders	235
Blind Spot Information System	479
Bluetooth® Audio	316
Bluetooth <sup>®</sup> HandsFreeLink <sup>®</sup>	389
Booster Seats (For Children)	. 76
Brake System	545
Anti-lock Brake System (ABS)	553
Automatic Brake Hold	550
Brake Assist System	554
Fluid	603
Foot Brake	549
Indicator 81, 82, 83,	673
Indicator (Red)	675
Parking Brake	545
Brightness Control (Instrument Panel)	208
Built-in Key	157
Bulb Replacement	605
Chicane <sup>™</sup> Taillights, Brake and Rear Side	
Marker Lights	607

Chicane <sup>™</sup> Taillights/Brake and Back-Up Lights	608
Fog Lights	605
Front Turn Signal, Parking/Chicane™	
Daytime Running and Front Side	
Marker Lights	605
Headlights	605
High-Mount Brake Light	608
Puddle Lights	608
Rear License Plate Light	608
Rear Turn Signal Light Bulbs	606
Side Turn Signal/Emergency Indicator	
Lights	605
Bulb Specifications	690

## С

CAMERA Button	568
Carbon Monoxide Gas	77
Carrying Cargo	131, 433
Certification Label	
Changing Bulbs	605
Charging System Indicator	
Chicane <sup>™</sup> Daytime Running Lights	200
Child Safety	64
Childproof Door Locks	171
Child Seat	64
Booster Seats	76
Child Seat for Infants	66
Child Seat for Small Children	67

Installing a Child Seat with a Lap/Shoulder	
Seat Belt	. 71
Larger Children	. 75
Rear-facing Child Seat	. 66
Selecting a Child Seat	. 68
Childproof Door Locks	171
Cleaning the Exterior	632
Cleaning the Interior	629
Client Service Information	701
Climate Control System	247
Changing the Mode	247
Defrosting the Windshield and	
Windows	249
Dust and Pollen Filter	628
Rear Temperature Control Dial	251
Recirculation/Fresh Air Mode	247
Sensors	252
Synchronized Mode	250
Using Automatic Climate Control	247
Clock	154
CMBS <sup>™</sup> (Collision Mitigation Braking	
System <sup>™</sup> )	486
Coat Hook	237
Collision Mitigation Braking System <sup>™</sup>	
(CMBS <sup>™</sup> )	486
Compact Spare Tire 641,	691
Console Compartment	234
Controls	153

# Index

Coolant (Engine)	600
Adding to the Radiator	601
Adding to the Reserve Tank	600
Overheating	669
Creeping (Automatic Transmission)	450
Cross Traffic Monitor	561
Cup Holders	235
Customized Features	359

# D

Dead Battery	667
Defaulting All the Settings	385
Defrosting the Windshield and	
Windows	249
Devices that Emit Radio Waves	693
Dimming	
Headlights	197
Rearview Mirror	213
Dipstick (Engine Oil)	596
Directional Signals (Turn Signal)	196
Door Mirrors	214
Doors	156
Auto Door Locking	172
Auto Door Unlocking	172
Keys	156
Locking/Unlocking the Doors from the	
Inside	169
Locking/Unlocking the Doors from the	
Outside	160
Lockout Prevention System	167

DOT Tire Quality Grading	617
Driving	429
Automatic Transmission	450
Braking	545
Off-Highway Driving Guidelines	441
Shifting Gear	451
Starting the Engine	443
Driving Position Memory System	210
Dust and Pollen Filter	628
Dynamic Mode Switch	460

## Ε

Electric Parking Brake	
Switch	545
Electric Power Steering (EPS) System	
Indicator	674
Electronic Stability Control (ESC)	471
Emergency	685
Emissions Testing (Readiness Codes)	
Engine	692
Coolant	600
If the Battery Is Dead	667
Oil	595
Remote Engine Start	445
Starting	443
Engine Compartment Cover	594
Engine Coolant	600
Adding to the Radiator	601
Adding to the Reserve Tank	600
Overheating	669

Temperature Gauge	136
Engine Oil	595
Adding	597
Checking	596
Displaying Oil Life	586
Engine Oil Pressure Low Warning	671
Recommended Engine Oil	595
ENGINE START/STOP Button	193
EPS (Electric Power Steering) System	674
Exhaust Gas Hazard (Carbon Monoxide).	. 77
Exterior Care (Cleaning)	632
Exterior Mirrors	214

## F

Features 25	53
Filters	
Dust and Pollen 62	28
Oil 59	98
Flat Tire 641, 64	19
Floor Mats	30
Fluids	
Automatic Transmission 60	)2
Brake 60	)3
Engine Coolant 60	)0
Windshield Washer 60	)4
FM/AM Radio 29	<del>)</del> 3
Fog Lights	
Indicator	98
Folding Down the Rear Seats 22	22
Foot Brake	19

Index

Front Airbags (SRS)	
Front Seats	216
Adjusting	216
Front Sensor Camera	541
Fuel	23, 575
Economy	578
Gauge	136
Instant Fuel Economy	141
Low Fuel Indicator	
Range	141
Recommendation	575
Refueling	575
Fuel Economy	578
Fuel Fill Door	23, 576
Fuses	678
Inspecting and Changing	684
Locations	678, 681, 682

# G

#### Gasoline (Fuel)

Economy 57	8
Gauge 13	6
Information 57	5
Instant Fuel Economy 14	1
Low Fuel Indicator 9	4
Refueling 57	5
Gauges 13	6
Gear Position Indicator 87, 45	3
Glass (care) 63	4
Glove Box 23	3

## Н

Handling of the Jack	663
Handling the Unexpected	639
HandsFreeLink <sup>®</sup> (HFL)	
Automatic Import of Phone Contacts and	
Call History	400
Automatic Transferring	
Displaying Messages	
Favorite Contacts	
HFL Buttons	
HFL Menus	
HFL Status Display	
In Case of Emergency	
Limitations for Manual Operation	
Making a Call	
Options During a Call	
Phone Setup	
Receiving a Call	
Receiving a Text Message	
Ring Tone	
Selecting a Phone	
To Set Up a Text Message Options	
Hazard Warning Button	
HD Radio <sup>™</sup>	296
Head Restraints	
Headlights	197
Auto High-Beam System	
Automatic Operation	198
Dimming 197,	200
Operating	
Head-Up Display	

Heated Steering Wheel	244
Heaters (Seat)	245
HFL (HandsFreeLink <sup>®</sup> )	389
High Beam Indicator	. 98
Hill Start Assist System	448
HomeLink <sup>®</sup> Universal Transceiver	386
Honda App License Agreement	339

## I

Identification Numbers	692
Engine and Transmission	692
Vehicle Identification	692
Illumination Control	208
Knob	208
Immobilizer System	183
Indicator	. 99

Indicators
Adaptive Cruise Control (ACC) with Low
Speed Follow (Amber) 102
Adaptive Cruise Control (ACC) with
Low Speed Follow (White/Green) 102, 503
Anti-lock Brake System (ABS)
Auto High-Beam
Auto Idle Stop (Green) 90
Auto Idle Stop OFF 90
Auto Idle Stop Suspend 90, 91, 92
Auto Idle Stop System (Amber)
Automatic Brake Hold 85, 550
Automatic Brake Hold System
Charging System 87, 672
Cruise Mode (White/Green) 101
Electric Power Steering (EPS) System 95, 674
Engine Oil Pressure Low Warning 671
Fog Light 98
Gear Position
High Beam
Immobilizer System 99
Lane Keeping Assist System (LKAS)
(Amber) 102
Lane Keeping Assist System (LKAS)
(White/Green) 102
Lights On
Low Fuel (Amber) 94
Low Tire Pressure/TPMS 97, 676
M (sequential mode) Indicator/Gear
Selection Indicator 87
Maintenance Minder 101

Malfunction Indicator Lamp 86, 672
Parking Brake and Brake System
(Amber) 83, 675
Parking Brake and Brake
System (Red) 81, 82, 673, 675
Safety Support (Amber) 103, 104, 105
Safety Support (Green/Gray) 106
Seat Belt Reminder 39, 93
Security System Alarm 99
Super Handling-All Wheel Drive <sup>™</sup>
(SH-AWD®) 101
Supplemental Restraint System
System Message 100
Transmission System 88, 677
Turn Signal and Hazard Warning
Vehicle Stability Assist <sup>™</sup> (VSA®) OFF
Vehicle Stability Assist <sup>™</sup> (VSA®)
System
VSA® OFF 472
Information
Instant Fuel Economy 141
Instrument Panel
Brightness Control 208
Interior Lights
Interior Rearview Mirror
iPad 337
iPhone
iPod 310, 337

## J

Jack (Wheel Nut Wrench)	645
Jump Starting	667

# Κ

Key Number Tag	158
Keyless Access System	160
Keyless Lockout Prevention	167
Keys	156
Lockout Prevention	167
Number Tag	158
Rear Door Won't Open	171
Remote Transmitter	165
Two-way Keyless Remote	168
Types and Functions	156
Kickdown (Automatic Transmission)	450
Knee Airbags	. 54

## L

Lane Keeping Assist System (LKAS)	522
LATCH (Child Seats)	69, 73
Legal Information	351
License Information	354
Lights	197, 605
Automatic	198
Bulb Replacement	605
Chicane <sup>™</sup> Daytime Running Lights	200
Fog Lights	200
High Beam Indicator	98

Interior	
Light Switches	
Lights On Indicator	98
Turn Signals and Hazard Warning	196
Load Limits	433
Locking/Unlocking	156
Auto Door Locking/Unlocking	172
Childproof Door Locks	171
From Inside	169
From Outside	
Keys	156
Using a Key	
Lockout Prevention System	
Low Battery Charge	672
Low Fuel Indicator	
Low Speed Braking Control	497
Lower Anchors	
Luggage (Maximum Load Limit)	433
Lumbar Support	216

# Μ

Maintenance 142	, 581
Battery	623
Brake Fluid	603
Cleaning	629
Climate Control System	627
Coolant	600
Maintenance Minder <sup>™</sup>	585
Oil	596
Precautions	582

Radiator	601
Remote Transmitter	625, 626
Replacing Light Bulbs	605
Safety	
Service Items	589
Tires	614
Transmission Fluid	
Under the Hood	
Malfunction Indicator Lamp	86, 672
Map Lights	
Maximum Load Limit	
Meters, Gauges	136
Mirrors	
Adjusting	213
Door	
Exterior	214
Interior Rearview	213
Modifications (and Accessories)	636
MP3	313
MP3/WMA/AAC	313
Multi-Information Display	137
Switching the Display	139
Warning and Information Messages	
Multi-View Rear Camera	

# Ν

Navigation	141
Numbers (Identification)	692

## 0

Odometer	137
Off-Highway Driving Guidelines	441
Oil (Engine)	595
Adding	597
Checking	596
Displaying Oil Life	586
Engine Oil Pressure Low Warning	671
Recommended Engine Oil 595,	691
Viscosity 595,	691
Open Source Licenses	353
Opening/Closing	
Hood	593
Panoramic Roof	189
Power Windows	186
Tailgate	173
Outside Temperature Display	137
Overheating	669

## Ρ

Paddle Shifters (Sequential Shift	
Mode) 45	57
Panic Mode 18	35
Panoramic Roof 18	39
Parking 55	55
Parking Brake 54	15
Parking Brake and Brake System	
Indicator	/3
Parking Brake and Brake System Indicator	
(Amber)	33

#### Parking Brake and Brake System

5	
Indicator (Red)	81, 82, 675
Parking Sensor System	557
Passenger Airbag Off Indicator	61
Passing Indicators	197
Playing Bluetooth® Audio	316
Power Tailgate	175
Power Windows	186
Precautions While Driving	449
Driving Guidelines for Your Utility	
Vehicle	449
Rain	450
Pregnant Women	44
Puncture (Tire)	641, 649

# R

Radar Sensor 543
Radiator
Radio (AM/FM)
Radio (SiriusXM®) 297
Range 141
Readiness Codes (Emissions Testing) 695
Rear Defogger/Heated Door Mirror
Button
Rear Seat Reminder 224
Rear Seats (Folding Down) 222
Rear Temperature Control Dial 251
Rearview Mirror 213
Refueling 575, 688
Fuel Gauge 136

Gasoline	575, 690
Low Fuel Indicator	
Regulations	477, 617, 693
Remote Engine Start	445
Remote Transmitter	165
Replacement	
Battery	625, 626
Bulbs	605
Fuses	678, 681, 682
Rear Wiper Blade Rubber	612
Tires	620
Wiper Blade Rubber	609
Reporting Safety Defects	694
Resetting a Trip Meter	140
Reverse Tilt Door Mirror	214
Road Departure Mitigation (RD	<b>M)</b> 530
On and Off	532

# S

Safe Driving
Safety Check
Safety Labels
Safety Message 3
Safety Support 146
Seat Belts
Adjusting the Shoulder Anchor 43
Automatic Seat Belt Tensioners 41
Checking 45
Fastening 42

Installing a Child Seat with a Lap/Should	der
Seat Belt	71
Pregnant Women	44
Reminder	39
Warning Indicator	39, 93
Seat Heaters	245
Seat Ventilators	245
Seats	216
Adjusting	216
Front Seats	216
Lumbar Support	216
Rear Seats	222
Seat Control Interface	218
Seat Heaters 24	5, 246
Ventilators	245
Security System	183
Immobilizer System Indicator	99
Security System Alarm Indicator	99
Selecting a Child Seat	68
Sequential Mode	457
Setting the Clock	154
SH-AWD <sup>®</sup> (Super Handling-All Wheel	
Drive <sup>™</sup> )	474
Shift Button 2	1, 451
Operation 2	1, 453
Shifting (Transmission) 2	1, 451
Shoulder Anchor	43
Side Airbags	57
Side Curtain Airbags	59
SiriusXM <sup>®</sup> Radio	297
Smart Shortcuts	278

Index

Snow Tires
Sonar Sensors
Spare Tire 641, 691
Spark Plugs 690
Specifications
Specified Fuel 575, 690
Speed Limit Information 138
Speed/Distance Units 142
Speedometer 136
Sport Gauge Settings 143
SRS Airbags (Airbags) 49
Starting Assist Brake Function 470
Starting the Engine 443
Does Not Start 664
If the Battery Is Dead 667
Remote Engine Start 445
Steering Wheel 212
Adjusting 212
Stopping 555
Summer Tires 622
Sunglasses Holder 238
Super Handling-All Wheel Drive™
(SH-AWD®)
Supplemental Restraint System (SRS) 49
Surround View Camera System 567
Switches (Around the Steering
Wheel) 6, 7, 193
Synchronized Mode 250
System Message Indicator 100
System Updates 281

I		
Fachometer		142
Failgate		173
Unable to Open		687
l'emperature		
Gauge		136
Outside Temperature Display		137
Temperature Sensor	137,	252
Temporary Tire Repair Kit		650
Tie-down Anchors		
Time (Setting)		154
Fire Fill Assist		676
Fire Pressure Monitoring System (TF	۹MS)	
with Tire Fill Assist		475
Indicator	97,	676
آنre Repair Kit		649
Tires		614
Air Pressure	615,	691
Checking and Maintaining		614
Inspection		614
Labeling		615
Puncture (Flat Tire)	641,	649
Regulations		617
Rotation		621
Spare Tire	641,	691
Summer		622
Temporary Tire Repair Kit		650
Tire Chains		622
Tire Repair Kit		649
Wear Indicators		619
Winter		622

\_

-

-

-

Tools	640
Towing a Trailer	435
Equipment and Accessories	437
Load Limits	
Towing Behind a Motorhome	440
Emergency	
TPMS (Tire Pressure Monitoring System)	
with Tire Fill Assist	475
Indicator	676
Traffic Sign Recognition System	
Transmission 21,	
Automatic 21,	451
Fluid	602
Gear Position Indicator	
Indicator	
Number	692
Sequential Shift Mode	457
Transmission System	
Indicator	. 88
Trip Computer	140
Trip Meter	
•	

Troubleshooting
Blown Fuse 678, 681, 682
Brake Pedal Vibrates 28
Buzzer Sounds When Opening Door
Emergency Towing 685
Engine Won't Start 664
Fuel Fill Door
Noise When Braking 30
Overheating 669
Puncture/Flat Tire 641, 649
Rear Door Won't Open 28, 171
Tailgate 687
Warning Indicators 80
True Touchpad Interface
Turbo Engine Vehicle 579
Turn Signals 196
Indicators (Instrument Panel)
Turn-by-Turn Directions 151
Two-way Keyless Remote 168

# U

Under-floor Storage Area 2	238
Unlocking the Doors 1	60
Unlocking the Front Doors from the	
Inside 15, 1	69
USB Flash Drives	38
USB Ports 2	255

## V

Vanity Mirrors	9
Vehicle Identification Number	692
Vehicle Speed	151
Vehicle Stability Assist <sup>™</sup> (VSA <sup>®</sup> )	471
Off Button	472
Off Indicator	
System Indicator	96, 471
Viscosity (Oil)	595, 691
Voice Control Operation	290
Voice Portal Screen	291
Voice Recognition	290
VSA <sup>®</sup> (Vehicle Stability Assist <sup>™</sup> )	471

## W

Warning and Information Messages 107
Warning Indicator On/Blinking 671
Warning Labels
Warnings 142
Warranties (Warranty Manual provided
separately) 697
Watts
Wear Indicators (Tire) 619
Wheel Nut Wrench (Jack Handle)
Wi-Fi Connection
Window Washers 204
Adding/Refilling Fluid 604
Switch 204
Windows (Opening and Closing) 186

Windshield	204
Cleaning	634
Defrosting/Defogging	249
Washer Fluid	604
Wiper Blades	609
Wipers and Washers	204
Winter Tires	622
Snow Tires	622
Tire Chains	622
Wipers and Washers	204
Automatic Intermittent Wipers	205
Checking and Replacing Wiper Blades	609
Front	204
Rear	206
Wireless Charger	240
WMA	313
Worn Tires	614

Index



# mygarage.acura.com (U.S.A.) acura.ca (Canada)

31TJB641 OM-22782 00X31-TJB-6410

2023 Acura RDX Owner's Manual © 2023 Honda Motor Co., Ltd. — All Rights Reserved

Printed in the U.S.A.